

SHIPCONSTRUCTOR®

2013

Featuring: Database Driven Relational Object Model™ (DDROM™).
Copyright 2012 ShipConstructor Software Inc. All Rights Reserved.

Pipe

www.ShipConstructor.com

© Copyright 2012 ShipConstructor Software Inc. – Jan. 31, 13

ShipConstructor 2012 Pipe
Published 2013-01-31

Copyright

Copyright © 2012 ShipConstructor Software Inc.

Information in this ShipConstructor manual is the property of ShipConstructor Software Inc. No part of it can be reproduced, translated, resold, rented, adapted, modified, stored in a retrieval system or transmitted in any form or by any means, in whole or in part. All Rights Reserved.

Trademarks

ShipConstructor
AutoMagic
SmartParts
Database Driven Relational Object Model
DDROM

Are all registered trademarks of ShipConstructor Software Inc.

ShipConstructor Software Inc.

Suite 304
3960 Quadra Street
Victoria, BC
Canada V8X 4A3

Toll Free: 1-888-210-7420
Phone: 1-250-479-3638
Fax: 1-250-479-0868

Information: info@ShipConstructor.com
Support: support@ShipConstructor.com
Sales: SSI@ShipConstructor.com

Website: www.ShipConstructor.com

SHIPCONSTRUCTOR LICENSE AGREEMENT

BEFORE PROCEEDING WITH THE INSTALLATION, YOU MUST ACCEPT THE TERMS OF THIS AGREEMENT. INDICATE YOUR ACCEPTANCE OR REJECTION OF THIS AGREEMENT BY CLICKING ON THE APPROPRIATE BUTTON. IF YOU CLICK ON "REJECT," INSTALLATION WILL ABORT.

1. License Grant. ShipConstructor Software Inc., #304 – 3960 Quadra Street, Victoria, B.C. Canada, V8X 4A3 ("SSI") grants to the person accepting this Agreement (the "Licensee") a non-exclusive, non-transferable right to use (the "License") in object code form those program modules, application programming interface ("API"), any other materials provided by SSI under this Agreement, and all upgrades, revisions, fixes, updates or enhancements to any of the foregoing ("Licensed Materials") specified in the Licensee's purchase order or request ("Invoice) solely on the software and hardware listed in the Licensed Materials manual ("System Configuration").
2. Academic Institutions/Trial Versions.
 - A. In the event that the Licensee qualifies as an academic institution user in accordance with SSI's specifications (an "Academic Licensee"), the Academic Licensee and its faculty, employees and students may use the Licensed Materials for the singular purpose of either teaching, training users or undertaking research provided that the Licensed Materials, and all copies of the Licensed Materials, remain at all times at the Academic Licensee's premises and the Licensed Materials are used for no other purpose than that set forth above. The above restrictions are in addition to the restrictions on use set out in Section 5 below.
 - B. In the event that the Licensee receives a trial version of the Licensed Materials for evaluation purposes, the terms and conditions of this Agreement, excluding Sections 15-19, shall continue to apply subject to the following provisions:
 - (a) the License pursuant to Section 1 above shall terminate at the end of the specified trial period;
 - (b) the Licensee shall return the Hardware Key to SSI immediately upon expiry of the specified trial period and in any event within 28 days of the expiry of the specified trial period;
 - (c) in the event that the Licensee does not return the Hardware Key in accordance with Section 2B.(b) above, SSI shall be entitled to invoice the Licensee for and the Licensee shall pay for the costs of the Hardware Key plus all shipping and handling expenses and SSI administrative charges; and
 - (d) in the event that the Licensee elects to and does acquire a License, the terms and conditions of this Agreement, excluding Section 2B herein, shall continue on and apply.

3. Ownership. All rights, title and interests in and to the Licensed Materials and related documentation shall remain the sole property of SSI. Licensee shall not remove or alter any proprietary rights notices on the Licensed Materials and the documentation, and shall reproduce such notices on any copies that it makes. Licensee shall be liable for the security of the Licensed Materials and the documentation in its possession.
4. Expertise Required. Licensee is responsible for evaluating whether the Licensed Materials meets Licensee's requirements, and for operating the Licensed Materials and the results obtained. The Licensed Materials are intended for ship modeling and construction purposes only, and must be used by a person who has expertise and knowledge in this field. The Licensed Materials requires independent confirmation of the reliability and accuracy of all designs, drawings and other Licensed Materials output. An SSI representative may be made available under a separate consulting agreement, at the Licensee's request to provide training and consultation on the operation or integration of licensed materials.
5. Limitations on Use.

Licensee shall:

- (a) not make more copies of the Licensed Materials than are necessary for the Licensee's installation of the Licensed Materials and shall only create backup copies for archival or emergency restart purposes;
 - (b) maintain a log of the number of and location of all originals and copies of the Licensed Materials;
 - (c) include SSI's copyright, trademark and proprietary notices on any complete or partial copies of the Licensed Materials in the same form and location as the notice on any original work;
 - (d) not attempt to defeat any copy protection;
 - (e) not modify, any documentation, including any user manuals;
 - (f) not modify, translate, reverse engineer, decompile or disassemble the Licensed Materials;
 - (g) not sublicense, transfer, assign, sell, loan, rent or lease the Licensed Materials other than as permitted in this Agreement;
 - (h) use the Licensed Materials for its own internal use only;
 - (i) not permit any third party to use the Licensed Materials; and
 - (j) thoroughly test any and all custom interfaces in accordance with general engineering principles.
6. Delivery and Installation. All Licensed Materials will be delivered in an electronic format by media or method as SSI may elect and will be sent to the Licensee's

designated email address or shipping address as specified in the Invoice. Licensee agrees to be responsible for installation of the Licensed Materials.

7. Term of License. The License term commences on the delivery of the Licensed Materials to the Licensee, and, subject to Section 2B above, is either perpetual if so requested on the Order, or on a month to month rental or lease basis. If Licensee chooses a lease option the license converts to a perpetual term on Licensee's payment of the balance of the perpetual License fee (prior monthly payments receiving 80% credit). All Licenses are subject to termination in accordance with this Agreement.
8. System Configuration. Operation of the Licensed Materials requires use of the specified System Configuration, which Licensee shall acquire and implement. SSI shall not be responsible for any operational problems caused by the System Configuration.
9. Security. The Licensed Materials includes security elements which support the detection of unauthorized use or copying of the software and which may (a) report such unauthorized use or copying to the Licensee, and (b) if applicable based on Licensee's configuration, may report back specific user information such as User name and email address.
10. Hardware Keys. Licensed Materials use requires "Hardware Keys" supplied by SSI, which can be used only at the site(s) authorized by SSI. In the event of a failure of the Licensee's System Configuration, the Licensee may upon advising SSI use the Hardware Keys and Licensed Materials on another system and/or location.
11. License Fees. Licensee shall pay to SSI the License fees applicable for the Licensed Materials as set out in and in accordance with SSI's Invoice.
12. Services. Support services after the Warranty Period (as defined in Section 15 below) are provided by SSI under the terms of the SSI Subscription Agreement. Installation, consulting, training and implementation services, if requested by the Licensee, shall be provided by separate agreement and at an additional charge.

13. Taxes. All amounts payable by Licensee to SSI are exclusive of all commodity taxes, including but not limited to applicable sales, use, value added, custom duties, excise taxes and other similar government charges, all of which will be paid by Licensee. If Licensee is required by law to withhold any taxes, then Licensee shall pay SSI a gross amount of money such that the net amount received by SSI after deducting or withholding the required taxes is equal to the amount of the fee originally charged by SSI.
14. Interest Charges. If any amount payable under this Agreement is not paid within 30 days of becoming due, SSI shall have the right to impose a charge of 2% per month (24% annually) on the unpaid balance of the amount, from the due date until the date of receipt of all amounts in arrears including interest.
15. Purchase Orders. Any purchase order (an "Order") delivered by Licensee shall at all times be deemed to incorporate this Agreement by reference and shall be subject to the applicable provisions of this Agreement. Any provisions of an Order shall not apply and shall not be binding upon SSI unless they relate to information which was requested by SSI. In the event of a conflict or an inconsistency between the provisions of an Order and the terms and conditions of this Agreement, this Agreement shall govern and supersede to the extent of such conflict or inconsistency.
16. Limited Warranty. SSI warrants that during a period of 90 days from the date of delivery of the Licensed Materials to Licensee (the "Warranty Period"), the Licensed Materials will perform substantially in accordance with the Licensed Materials documentation specifications, when used in accordance with this Agreement on a properly operating System Configuration. SSI's sole obligation under this Warranty, and Licensee's exclusive remedy, shall be to use reasonable commercial efforts to correct Errors (a bug, defect or other problem incurred by a user in operating the Software that prevents the Software from performing in a manner consistent with the applicable specifications set out in the User Manual) that the Licensee identifies to SSI through fixes or workarounds free of charge. If SSI determines that it is unable to make the Licensed Materials perform substantially as warranted, Licensee may terminate the License and receive a refund of a portion of the License Fees paid to date.
17. WARRANTY EXCLUSIONS. THE LIMITED WARRANTY CONTAINED IN SECTION 15 IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. ALL OTHER CONDITIONS, WARRANTIES, AND REPRESENTATIONS, EITHER EXPRESS OR IMPLIED, ARE EXCLUDED, INCLUDING BUT NOT LIMITED TO CONDITIONS, REPRESENTATIONS AND WARRANTIES RELATING TO MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SSI DOES NOT WARRANT THAT THE LICENSED MATERIALS ARE COMPLETELY ERROR FREE OR THAT ITS OPERATION WILL BE CONTINUOUS AND UNINTERRUPTED.

18. Maintenance Services. Licensee may elect, to obtain maintenance, support and upgrade services from SSI in accordance with and subject to the terms of SSI's standard Subscription Agreement.
19. Loss of Data. SSI shall not be responsible for any loss of or damage to files or data caused by the Licensed Materials, or be required to restore or rebuild files or data. Licensee shall implementing adequate backup procedures to avoid any loss of files and data.
20. Modifications. SSI may, from time to time, provide the Licensee with revisions to the Licensed Materials (the "Revised Licensed Materials"). The Licensee shall test any external applications using the revised API before implementing the new version. While it is SSI's intention that the Revised Licensed Materials shall be backward-compatible with the immediately prior version of the Licensed Materials, SSI does not guarantee or warrant that this shall be so, and SSI shall have no liability whatsoever to the Licensee for any failure of the Revised Licensed Materials to be backward compatible with any prior version of the Licensed Materials. Modifications requested by the Licensee shall be subject to prior written agreement as to scope and fees payable. Ownership of all Licensed Materials modifications shall vest in SSI. SSI does not warrant, guarantee or otherwise commit to supporting Licensed Materials that has been superseded by Revised Licensed Materials.
21. Confidential Information. Each party will not use the confidential information of the other party for any purpose except for the purpose described in this Agreement, and shall not disclose it to any other person except on a confidential basis to its employees and representatives who have a need-to-know the confidential information for such purposes. This Section 23 shall not apply to confidential information which (a) is or has become readily available to the public in the same form other than by an act or omission of the receiving party, (b) was lawfully obtained in the same form by the receiving party from a third party not under an obligation of confidence to the disclosing party, (c) was in the receiving party's possession in the same and material form prior to its receipt from the disclosing party and did not otherwise originate from the disclosing party, or (d) is required to be disclosed by operation of law.

22. Audit Rights. Upon reasonable notice by SSI, which shall be delivered on no more than an (annual?) basis, Licensee shall provide a signed statement verifying its compliance with the terms of this Agreement. SSI shall also have the right, upon reasonable notice and no more than on an annual basis, to inspect Licensee's facilities to verify Licensee's compliance with such terms. Any such inspection or audit shall be conducted either by SSI or by representatives authorized by SSI to complete the inspection. If such inspections or audits disclose that the Licensee has installed, accessed or permitted access to the Licensed Materials in a manner that is not permitted under this Agreement, then Licensee shall be liable to pay for any unpaid license fees as well as the reasonable costs of the audit.
23. Termination. This Agreement may be terminated by either party, immediately by written notice, if the other party commits a breach of any material provision of this Agreement, including a failure to make payment when due, and fails to correct or rectify such breach within 30 days of receipt of the notice requesting it to do so. SSI shall be entitled to place time-lock devices and other disabling features in the Licensed Materials that become effective in the event that the Licensee has failed to comply with its payment obligations hereunder and as set out in SSI Invoices.
24. Effect of Termination. Upon termination of this Agreement Licensee shall immediately cease using the Licensed Materials, and within 14 days of termination return all Hardware Keys to SSI.
25. CONSEQUENTIAL DAMAGES. IN NO EVENT SHALL SSI BE LIABLE FOR ANY LOSS OF DATA OR PROFITS, ECONOMIC LOSS OR SPECIAL, INDIRECT, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES WITH RESPECT TO THIS AGREEMENT OR THE LICENSED MATERIALS, HOWEVER CAUSED, EVEN IF SSI HAD OR SHOULD HAVE HAD ANY KNOWLEDGE OF THE POSSIBILITY OF SUCH DAMAGES.
26. DAMAGES LIMITATION. THE MAXIMUM LIABILITY OF SSI FOR ALL CLAIMS AND DAMAGES OF ANY KIND, WHETHER FOR FUNDAMENTAL BREACH OR ANY OTHER CAUSE UNDER THIS AGREEMENT, SHALL BE LIMITED IN THE AGGREGATE TO THE TOTAL OF ALL FEES PAID BY LICENSEE.
27. LIMITATION OF NON-APPLICABILITY. IN SOME JURISDICTIONS THE EXCLUSION OR LIMITATION OF WARRANTIES OR LIABILITY MAY NOT BE APPLICABLE, AND IN SUCH JURISDICTIONS SSI HEREBY LIMITS ITS LIABILITY TO THE FULLEST EXTENT PERMITTED BY LAW.

28. Applicable Law. This Agreement shall be subject to and construed in accordance with the laws of the Province of British Columbia, Canada, excluding its conflict of laws rules and the application of the UN Convention on Contracts for the International Sale of Goods.
29. References. SSI shall be allowed to incorporate Licensee's name in SSI's customer reference list and to use it for marketing.
30. Dispute. If any dispute arises under this Agreement, a good faith attempt to resolve the dispute will be made by senior management of both parties at a mutually agreeable site and time. If the parties are unable to reach agreement within 30 days after a request for such meeting, the dispute shall be referred to arbitration in English, before one arbitrator in Victoria, British Columbia, Canada, in accordance with the Commercial Arbitration Act of the British Columbia.
31. Entire Agreement. This Agreement contains the entire agreement between the parties and shall supersede all prior discussions and agreements between the parties regarding its subject matter.
32. Amendment. Any amendment of this Agreement must be in writing and signed by duly authorized representatives of the parties.
33. Waiver. The waiver by any party of a breach by the other party of this Agreement shall not be construed as a waiver by such party of any succeeding breach by the other party of the same or another provision.
34. Assignments. Licensee may not assign or transfer the License or Licensee's rights or obligations under this Agreement without SSI's prior written consent, and any such assignment or transfer without consent shall be null and void. A transfer of all or substantially all of the voting stock of the Licensee shall constitute a transfer for these purposes and shall be subject to SSI's prior written consent.
35. Successors and Assigns. This Agreement will bind and enure to the benefit of the parties and their respective successors and permitted assigns.
36. Severability. In the event that any provision of this Agreement is declared invalid, illegal or unenforceable by a court having jurisdiction, then the remaining provisions shall continue in full force and effect.
37. Force Majeure. Except as related to Licensee's obligation to make payments to SSI, neither party shall be liable for delays or non-performance if such delays or non-performance are beyond such party's reasonable control. A delayed party shall promptly notify the other party in writing stating the cause of the delay and its expected duration and shall use commercially reasonable efforts to remedy a delay or non-performance as soon as reasonably possible.

38. Survival. The provisions of Sections 3, 5, 11, 13, 14, 17 and 20-30 shall survive the expiry or termination of this Agreement.

39. Language. It is the express will of the parties that this Agreement and related documents have been prepared in English. C'est la volonté expresse des parties que la présente Convention ainsi que les documents qui s'y rattachent soient rédigés en anglais.

Contents

Pipe Library Setup	1
Standards	2
Create a Standard	3
Edit a Standard	4
Delete a Standard	4
Create a Pressure Rating	4
Edit a Pressure Rating	4
Associate a Pressure Rating with a Geometric Standard	5
Delete a Pressure Rating	5
Associate a Stock Type with a Geometric Standard	5
Nominal Sizes	5
Create a Nominal Size	6
Edit a Nominal Size	6
Delete a Nominal Size	7
Size Definitions	7
Create a Size Definition	7
Create a 'New Next Size' Size Definition	7
Edit a Size Definition	8
Delete a Size Definition	8
Filter Size Definitions	8
Import Size Definitions	9
Export Size Definitions	9
End Treatments	10
Create an End Treatment Type	10
Edit an End Treatment Type	10
Delete an End Treatment Type	10
Create a LineMode Icon	11
Edit a LineMode Icon	11
Delete a LineMode Icon	12
Set Up End Treatment Properties	12
Create an End Treatment	12
Edit an End Treatment	13
Delete an End Treatment	14
Usage Log	14
Filter End Treatments	14
Import End Treatments	15
Export End Treatments	15
Specifications	16
Create a Spec	16
Delete a Spec	17

Edit a Spec	17
Catalogs	17
Create a Catalog	17
Delete a Catalog	18
Edit a Catalog	18
Manufacturers.....	18
Materials.....	19
Pipe Stock	19
Filter Pipe Stocks.....	19
Create a Stock.....	19
Create a 'New Next Size' Stock	30
Valve Handles.....	30
Add or Remove Pipe Stocks To or From a Spec	33
Add or Remove Pipe Stocks To or From a Catalog	33
Edit a Pipe Stock.....	33
Change Stock Subtype.....	34
Stock Usage.....	34
Import Pipe Stock.....	36
Export Pipe Stock.....	37
Accessory Packages	37
Create an Accessory Type.....	37
Create an Accessory Package	38
Create an Accessory.....	38
Copy an Accessory Package	38
Delete an Accessory Package	39
Delete an Accessory or Accessory Type	39
Add or Remove an Accessory To or From an Accessory Package	39
Add or Remove an Accessory Package To or From a Spec	39
Import Accessory Packages.....	40
Export Accessory Packages	40
Connections.....	40
Create a Connection Type.....	41
Create a Connection.....	41
Create a 'New Next Size' Connection.....	42
Edit a Connection.....	42
Delete a Connection or Connection Type.....	42
Add an Accessory Package To a Connection	43
Remove an Accessory Package From a Connection.....	43
Import Connections.....	43
Export Connections.....	44
Auto-Part Insertion Setup.....	44
Stock Setup	44
Allowable Connection Setup	44
Pipe Bending Machines.....	44
Create a Pipe Bending Machine.....	44
Edit a Pipe Bending Machine.....	45
Delete a Pipe Bending Machine	45

Add a Size Definition to a Pipe Bending Machine's Bender Information	46
Edit Pipe Bending Machine's Bender Information Size Definition Settings.....	46
Remove a Size Definition Setting From a Pipe Bending Machine's Bender Information	46
Add a Size Definition to a Pipe Bending Machine's Cutting Information	47
Edit Pipe Bending Machine's Cutting Information Size Definition Settings.....	47
Remove a Size Definition Setting From a Pipe Bending Machine's Cutting Information	47
Delete a Pipe Bending Machine	47
Import Pipe Bending Machines	47
Export Pipe Bending Machines.....	48
User-Defined Attributes	48
Excel Pipe Library Editor ("Flatsheet")	48
Overview	48
Getting Started.....	49
The Help Tab.....	49
General Information	49
Pipe Hanger Stocks.....	50
Supported Hanger Types	50
Create a Hanger Stock.....	67
Edit a Hanger Stock.....	68
Delete a Hanger Stock.....	68
Assign Allowable Nominal Sizes to a Hanger Stock.....	68
Assign Allowable Material Grades to a Hanger Stock	69
Edit Hanger Stock Catalogs.....	70
Assign Hanger Stocks to a Hanger Stock Catalog.....	70
Support Templates.....	71
Support Template Types.....	71
Create a Support Template.....	76
Edit Support Template Tiers.....	77
Edit a Support Template.....	78
Assign Allowable Hangers to a Support Template	78

Pipe Modeling 81

Pipe Drawings.....	81
Create a Pipe Drawing	81
Upon Opening a Pipe Drawing	81
Set Up Pipe Systems.....	82
Create a System.....	82
Create a Branch	83
Modify a System or Branch	83
Delete a System or Branch	83
Set the Current System for Pipes.....	83
Change the System for Pipes.....	84
Set Up Pipe Defaults, Display, and Performance.....	84
Display Options for Pipe	84
Change the NavAid Options	85
Set the Transform Options	86
Set the Routing Options.....	87

Set the Behavior Options.....	88
Set the Constraints Options.....	89
Insert Pipes.....	90
Selecting a Pipe Part to Insert.....	90
The NavAid.....	91
Required Custom Attributes	92
No Spool Parts.....	92
Straight Pipe.....	93
Bent Pipe.....	94
Generic Pipes	96
Fittings.....	96
Auto Part Insertion Mode	102
Inline Fitting Insert.....	102
Insert Connector Set Command.....	103
Routing Options	103
Creating Connections While Routing In End Mode.....	104
Create a Saddle.....	104
Offset Routing	109
Object Snaps.....	110
Custom Object Snaps.....	111
Modify Pipes.....	113
Anchor Pipes.....	113
Unanchor a Pipe.....	114
Lock a Pipe	114
Grip Points	114
Toggle Transform Mode.....	115
Toggle Constraining Mode.....	124
Break a Pipe	124
Disconnect Pipes	124
Connect Pipes.....	124
Remove Saddle.....	125
Mark All Exceeding Maximum Length.....	125
Cut to Maximum Length.....	125
Extract Center Line	125
Merge To Bent.....	125
Change Connection Accessory Package.....	126
Transfer parts to another drawing / unit	127
Copy parts to another drawing / unit	127
Pipe Spools.....	127
Creating Spools.....	127
OPM.....	140
Weight	142
Activate UCS from Parts.....	142
Pipe-UCS Intersection	143
Add Pipe-UCS Intersection.....	143
Toggle UCS Intersection Line	144
Erase Pipe-UCS Intersection.....	144
Erase All Pipe-UCS Intersections.....	144

Hanger Modeling 144

Hanger Drawings	144
Create an Hanger Drawing	145
Upon Opening an Hanger Drawing	145
Set Up Hanger Defaults, Display, and Performance	145
Display Options for Hangers	145
NavAid Options	146
Insert Hangers	146
Selecting a Hanger Part to Place	147
NavAid	148
Place Hanger	148
Hanger Routing Options	150
Object Snaps	150
Modify Hangers	153
Name Hangers	153
Move Hangers to Drawing	154
Move Attached Hangers to Current Drawing	154
Grip-points	154
OPM	155

Support Modeling 157

Support Drawings	157
Create a Support Drawing	157
Upon Opening a Support Drawing	157
Set Up Support Defaults, Display, and Performance	158
Display Options for Supports	158
NavAid Options	158
Insert Supports	159
Bare Support	159
Auto Support	163
Modify Hangers	164
Name Supports	164
Move Supports to Drawing	164
Attach Pipes to Supports	164
Copy Supports along Supported Objects	165
Grip Points	165
OPM	167

Distributed Systems Production Drawings 169

Creating a Spool Drawing	169
Set Up Spool Naming Convention	169
Set an Active Naming Convention	170

Set Up a Spool Template Drawing	170
Generate Spool Drawings.....	176
Edit Spool Drawings.....	179
Rotate a Dimension	179
Align Dimension Text to View	180
Re-dimension a Spool Drawing	180
Label Connecting Spool/Assembly.....	181
Update Spool Drawings.....	181
Identifying Drawings that Require Updating	181
Updating an Existing Spool Drawing.....	182
Create Arrangement Drawings.....	184
Set Up an Arrangement Drawing Template.....	184
Generate Arrangement Drawings	187
Edit Arrangement Drawings.....	193
Update Arrangement Drawings.....	193
Identifying Drawings that Require Updating	193
Updating an Existing Arrangement Drawing	194
Labeling	198
Manual Labeling from BOM.....	198
Copy Label from BOM	198
Relabel All.....	198
Relabel from a selected BOM.....	198
Relabel from Parts	199
Label to part edges.....	199
Common Production Drawing Functions.....	201
Insert an Orientation Icon.....	201
Viewport Options.....	201
Update BOMs.....	201
Purge BOMs.....	202
Clear All BOMs.....	202
Unlink All BOMS	202
Edit BOM Collector Options	202
Update All Keywords	202
Viewport Display Options.....	202
List only Visible.....	202
Viewport Clipping	203
Remove clip.....	205

Support Construction Drawings 205

Set Up Support Construction Drawings.....	206
Set Up a Support Construction Drawing Template.....	206
Set Up a Support Construction Drawing BOM Style	208
Generate Support Construction Drawings.....	209
Generating Support Construction Drawings.....	209

Edit Support Construction Drawings	212
Update Support Construction Drawings.....	213
Identifying Drawings that Require Updating	213
Updating an Existing Support Construction Drawing	214
Insert Keywords in a Support Construction Drawing.....	215
Plot Support Construction Drawings	215
Plot a Support Construction Drawing	215
Inspect a Plotted Support Construction Drawing.....	216

Appendix A: Pipe Command Reference 217

Manager Pipe Menu.....	217
Pipe > Pipe Benders.....	217
Pipe > Stock Catalog.....	218
Toolbars	225
Pipe Toolbar.....	225
Distributed Systems Utilities Toolbar	227
ShipConstructor Menu	227
ShipConstructor > Navigator.....	227
ShipConstructor > Export Pipe Bending Data	228
SC Pipe Menu.....	228
SC Pipe > Straight Pipe.....	228
SC Pipe > Bent Pipe	228
SC Pipe > Elbow.....	229
SC Pipe > Reducer.....	229
SC Pipe > Caps.....	229
SC Pipe > Cross.....	229
SC Pipe > Branches > Lateral.....	230
SC Pipe > Branches > Tee.....	230
SC Pipe > Branches > Wye.....	230
SC Pipe > Branches > Misc	230
SC Pipe > Connectors > Union.....	231
SC Pipe > Connectors > Flange.....	231
SC Pipe > Connectors > Coupling.....	231
SC Pipe > Connectors > Weldolet	231
SC Pipe > Connectors > Thredolet.....	232
SC Pipe > Connectors > Adapter.....	232
SC Pipe > Connectors > Misc.....	232
SC Pipe > Valves > Ball.....	232
SC Pipe > Valves > Butterfly.....	233
SC Pipe > Valves > Check.....	233
SC Pipe > Valves > Diaphragm.....	233
SC Pipe > Valves > Gate	233
SC Pipe > Valves > Globe	234
SC Pipe > Valves > Plug.....	234
SC Pipe > Valves > Relief	234
SC Pipe > Valves > SDNR	234
SC Pipe > Valves > Misc.....	235

SC Pipe > Insert Connector Set	235
SC Pipe > Equipment	235
SC Pipe > Spools > Spool Manager	235
SC Pipe > Spools > Set No-Spool	236
SC Pipe > Spools > Remove No-Spool	236
SC Pipe > Spools > Add Spool Break	236
SC Pipe > Spools > Remove Spool Break	237
SC Pipe > System > System Manager	237
SC Pipe > System > Set Current System From Pipe Part	237
SC Pipe > System > Set System	237
SC Pipe > Saddles > Create Saddle	238
SC Pipe > Saddles > Remove Saddle	238
SC Pipe > Insulation and Finishes > Add Insulation	238
SC Pipe > Insulation and Finishes > View Finishes	238
SC Pipe > Insulation and Finishes > Apply Finishes	239
SC Pipe > Utilities > Merge To Bent	239
SC Pipe > Utilities > Route on Polyline	239
SC Pipe > Utilities > Cut to Max Length	239
SC Pipe > Utilities > Extract Center Line	240
SC Pipe > Pipe-UCS Intersection > Add Pipe-UCS Intersection	240
SC Pipe > Pipe-UCS Intersection > Toggle Highlight on all HEP-UCS Intersection	241
SC Pipe > Pipe-UCS Intersection > Erase HEP-UCS Intersection	241
SC Pipe > Pipe-UCS Intersection > Erase All HEP-UCS Intersection	241
SC Pipe > Connect	241
SC Pipe > Disconnect	242
SC Pipe > Break Pipe at Point	242
SC Pipe > Anchor Part	242
SC Pipe > Unanchor Part	242
SC Pipe > Lock Part	243
SC Pipe > Toggle Constrain Enforcement	243
SC Pipe > Unlock Part	243
SC Pipe > Toggle Transform Mode	243
SC Pipe > Pipe Options	244
SC Pipe > Insert Penetration	244
SC Pipe > Change Connection Accessory Package	244
Individual Drawing Display Settings Commands	245
Shared HEP Commands	246
SCHEPTransferPartToDrawing	246
SCHEPReplicateToDrawing	247
Supports & Hanger Commands	247
SC Supports & Hangers > New Hanger	247
SC Supports & Hangers > Name Hangers	247
SC Supports & Hangers > Move Hanger to Drawing	247
SC Supports & Hangers > Move Attached Hanger to Drawing	248
SC Supports & Hangers > Insert Bare Support	248
SC Supports & Hangers > Insert Auto Support	248
SC Supports & Hangers > Insert LF Auto Support	248
SC Supports & Hangers > Insert I Auto Support	249
SC Supports & Hangers > Insert TN Auto Support	249
SC Supports & Hangers > Insert MN Auto Support	249
SC Supports & Hangers > Attach Pipes to Support	249

SC Supports & Hangers > Transfer Supports to Drawing.....	250
SC Supports & Hangers > Name Supports In Order.....	250
SC Supports & Hangers > Copy Supports Along Supported Parts.....	250
SC Supports & Hangers > Hanger and Support Drawing Options.....	250

Appendix B: Pipe Modeling Reference 251

Pipe Navigator Page	251
Pipe Spool Navigator Page	252
System Manager	254
Pipe Options.....	255
The Display Tab.....	255
The NavAid Tab	261
The Transform Tab.....	262
The Routing Tab.....	264
The Behavior Tab	265
The Constraints Tab.....	266
Stock Selection Window Reference	266
Required Custom Attributes Reference	267
Insulation Reference.....	268
Finishes Reference.....	269
Pipe Part Right-Click Menu	271
Select UCS Options Reference	272
Scenario Wizard Dialog	273
Hanger Stock Selection Window Reference	274
Hanger & Support Drawing Options	275
Hangers	275
Supports	276
Support Template Selection Window Reference	276

Appendix C: Pipe Production Command Reference 279

Toolbars	279
Spool Toolbar.....	279
SC Arrangement Menu	279
SC Arrangement > Update Drawing.....	279
SC Arrangement > Silent Update Drawing	279
SC Arrangement > Insert Keywords.....	280
SC Arrangement > Update All Keywords.....	280
SC Arrangement > Pipe Drawing Options.....	280
SC Arrangement > HVAC Drawing Options.....	280
SC Arrangement > Equipment Drawing Options	280

SC Arrangement > Viewport Options.....	281
SC Arrangement > Set Viewport Display Options.....	281
SC Arrangement > Insert BOM Table.....	281
SC Arrangement > Update BOMs.....	281
SC Arrangement > Edit Collector Options.....	281
SC Arrangement > Toggle List Only Visible	282
SC Arrangement > Label > Manual Label from BOM	282
SC Arrangement > Label > Copy Label from BOM.....	282
SC Arrangement > Label > Relabel All.....	282
SC Arrangement > Label > Relabel from BOM.....	283
SC Arrangement > Label > Relabel from Parts.....	283
SC Arrangement > Label > Label on Visible Edge On/Off.....	283
SC Arrangement > Label > Curved Plates in Visible Edge Detection On/Off.....	283
SC Arrangement > Label > Adjacent Part Edge Tolerance	284
SC Arrangement > Label > Edge Length Filter.....	284
SC Arrangement > Label > Edge Determination Minimum Angle.....	284
SC Arrangement > Label > Label Reset Automatic Settings.....	284
SC Arrangement > BOM Revisions > New BOM Revision in Current Layout	285
SC Arrangement > BOM Revisions > New BOM Revision in All Layouts.....	285
SC Arrangement > BOM Revisions > Delete BOM Revision in Current Layout.....	285
SC Arrangement > BOM Revisions > Delete BOM Revision in All Layouts.....	285
SC Arrangement > BOM Revisions > Delete All BOM Revision in Current Layout	286
SC Arrangement > BOM Revisions > Delete All BOM Revision in All Layouts	286
SC Arrangement > BOM Revisions > List BOM Revisions.....	286
SC Arrangement > Global Dimension to Point.....	286
SC Spool Drawing Menu.....	286
SC Spool Drawing > Update Spool Drawing	287
SC Spool Drawing > Rotate Dimension.....	287
SC Spool Drawing > Align Dimension Text to Current View.....	287
SC Spool Drawing > Re-Dimension.....	287
SC Spool Drawing > CG Point	287
SC Spool Drawing > Orientation Icon	288
SC Spool Drawing > Label Connecting Spool/Assembly.....	288
SC Spool Drawing > Insert Keywords	288
SC Spool Drawing > Update All Keywords	288
SC Spool Drawing > Drawing Options	288
SC Spool Drawing > Viewport Options.....	289
SC Spool Drawing > Set Viewport Display Options.....	289
SC Spool Drawing > Insert BOM Table	289
SC Spool Drawing > Update BOMs.....	289
SC Spool Drawing > Edit Collector Options.....	289
SC Spool Drawing > Toggle List Only Visible	290
SC Spool Drawing > Label > Manual Label from BOM	290
SC Spool Drawing > Label > Copy Label from BOM.....	290
SC Spool Drawing > Label > Relabel All	290
SC Spool Drawing > Label > Relabel from BOM.....	291
SC Spool Drawing > Label > Relabel from Parts.....	291
SC Spool Drawing > BOM Revisions > New BOM Revision in Current Layout.....	291
SC Spool Drawing > BOM Revisions > New BOM Revision in All Layouts	291
SC Spool Drawing > BOM Revisions > Delete BOM Revision in Current Layout.....	292
SC Spool Drawing > BOM Revisions > Delete BOM Revision in All Layouts.....	292
SC Spool Drawing > BOM Revisions > Delete All BOM Revision in Current Layout	292

SC Spool Drawing > BOM Revisions > Delete All BOM Revision in All Layouts.....	292
SC Spool Drawing > BOM Revisions > List BOM Revisions.....	293
SC Spool Drawing > Global Dimension to Point	293
SC Arrangement Template Menu	293
SC Arrangement Template > Orientation Icon.....	293
SC Arrangement Template > Insert Keywords.....	293
SC Arrangement Template > Pipe Drawing Options.....	294
SC Arrangement Template > HVAC Drawing Options.....	294
SC Arrangement Template > Equipment Drawing Options	294
SC Arrangement Template > Viewport Options.....	294
SC Arrangement Template > Set Viewport Display Options.....	294
SC Arrangement Template > Insert BOM Table.....	295
SC Arrangement Template > Edit Collector Options.....	295
SC Arrangement Template > Toggle List Only Visible.....	295
SC Arrangement Template > Update from a Previous Version	295
SC Spool Template Menu.....	295
SC Spool Template > Orientation Icon	295
SC Spool Template > Insert Keywords	296
SC Spool Template > Drawing Options	296
SC Spool Template > Viewport Options	296
SC Spool Template > Set Viewport Display Options	296
SC Spool Template > Insert BOM Table	296
SC Spool Template > Edit Collector Options	297
SC Spool Template > Toggle List Only Visible.....	297
SC Spool Template > Update from a Previous Version.....	297

Appendix D: Distributed Systems Production Command Reference 299

SC Support Const Menu	299
SC Support Const > Update Drawing.....	299
SC Support Const > Silent Update Drawing.....	299
SC Support Const > Insert Keywords.....	299
SC Support Const > Update All Keywords.....	299
SC Support Const > Re-Dimension	300
SC Support Const > Structure Drawing Options.....	302
SC Support Const > Hanger Drawing Options.....	302
SC Support Const > Viewport Options	302
SC Support Const > Set Viewport Display Options	302
SC Support Const > Insert BOM Table.....	302
SC Support Const > Update BOMs.....	303
SC Support Const > Edit Collector Options.....	303
SC Support Const > Toggle list only visible.....	303
SC Support Const > Label > Manual Label from BOM.....	303
SC Support Const > Label > Copy Label from BOM	303
SC Support Const > Label > Relabel All.....	304
SC Support Const > Label > Relabel from BOM	304
SC Support Const > Label > Relabel from Parts.....	304
SC Support Const > Label > Label on Visible Edge On/Off.....	304
SC Support Const > Label > Curved Plates in Visible Edge Detection On/Off	305
SC Support Const > Label > Adjacent Part Edge Tolerance.....	305
SC Support Const > Label > Edge Length Filter.....	305

SC Support Const > Label > Edge Determination Minimum Angle	305
SC Support Const > Label > Label Reset Automatic Settings.....	306
SC Support Const > BOM Revisions > New BOM Revision in Current Layout.....	306
SC Support Const > BOM Revisions > New BOM Revision in All Layouts.....	306
SC Support Const > BOM Revisions > Delete BOM Revision in Current Layout	306
SC Support Const > BOM Revisions > Delete BOM Revision in All Layouts.....	307
SC Support Const > BOM Revisions > Delete All BOM Revision in Current Layout.....	307
SC Support Const > BOM Revisions > Delete All BOM Revision in All Layouts.....	307
SC Support Const > BOM Revisions > List BOM Revisions	307
SC Support Const > Global Dimension to Point.....	308
SC Support Const Template Menu.....	308
SC Support Const Template > Insert Keywords.....	308
SC Support Const Template > Structure Drawing Options.....	308
SC Support Const Template > Hanger Drawing Options	308
SC Support Const Template > Viewport Options	308
SC Support Const Template > Set Viewport Display Options	309
SC Support Const Template > Insert BOM Table.....	309
SC Support Const Template > Edit Collector Options	309
SC Support Const Template > Toggle list only visible.....	309

Appendix E: Distributed Systems Production Reference 311

Bill of Materials.....	311
BOM Functionality Overview	311
BOM Definitions Manager.....	313
Properties and Functions Explained.....	313
BOM Fields.....	314
Merging Rows.....	317
Merging Columns.....	317
Collectors	317
Creating a New BOM Definition	319
Insert Empty BOM Wizard	320
Manual Label from BOM.....	322
Copy Label from BOM.....	322
Bending Data – XML Output.....	322
Raw	322
Formatted	324
Excel Import.....	325
Choosing Pipes for XML Data Generation.....	326
Bend Information and Location Tables.....	327
Corner Point.....	327
Global Position	328
Bending Tables.....	328
Bending and Location Tables Example.....	328
Spool Manager Reference	329

Right-Click Menu for the Spool Manager	332
Drag and Drop Feature for the Spool Manager.....	333
Spool Properties Reference.....	333
Keywords Reference.....	336
Create Spool Drawing Wizard Reference	339
Spool Styles Reference	341
Create Arrangement Drawing Wizard Reference.....	344
Modified Part Information Reference	349
Layer Conflict Resolution Reference.....	350
Update Arrangement Drawing Wizard Reference.....	351
Label Styles.....	354
BOM Revisions.....	355
New Revision	356
Delete Revision	356
Delete All Revisions.....	357
List Revisions.....	357
Global Dimension to Point.....	357
Cut Length Dimensions.....	361
Elbow Radius Dimension	361
Flange Rotation Angles.....	362
Spool Drawings – Valves Icons	363
Spool Drawings – Penetrations.....	364

Index

367


Pipe Library Setup

Each project contains various libraries that hold the stocks, materials, and other things you need to use in the project. Before you begin work on a project, you must set up these project libraries. You can also import project libraries from another project or from an XML file that you have exported from another project.

This manual describes how to set up pipe libraries, equipment libraries, and hanger libraries. See the Structure manual for details on setting up general and structural libraries. See the HVAC manual for details on setting up HVAC libraries.

Pipe stocks are managed through the Pipe Stock Catalog in Manager. The main interface for the Pipe Stock Catalog involves four tabs; [Size Definitions Tab](#) (page 220), [End Treatments Tab](#) (page 221), [Create/Edit Pipe Tab](#) (page 222), and [Connections Tab](#) (page 223). Each tab, along with a number of sub-dialogs, helps you manage a different area of the pipe stocks catalog.

Hanger stocks are managed through the Hanger Stock Catalog in Manager. Stocks are managed through the main hangers grid and several smaller sub-dialogs.



Standards

A standard is a combination of the following:

- An international standard (for example, ANSI) is the name of a governing international standard body.
- A geometric standard (for example, B16.9) is the section of the associated international standard.
- A pipe schedule or pressure rating (for example, 10S) represents the pipe's wall thickness.


Examples of standards include:

- ANSI – B16.9 – 10S
- ASME – B36.19 – 40S
- ANSI – B16.5 – STD

Create a Standard

To create a standard

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog. See [Pipe > Stock Catalog](#) (page 218) for details.
3. Select the Size Definitions tab.
4. Click Edit Standards to open the Standards window.



Standards lists all international standards and geometric standards. (Each geometric standard is listed under its associated international standard.)

- To create an international standard, click New International and enter a Name and Description.
- To create a geometric standard, select an international standard, click New Geometric, and enter a Name and Description.
- To rename an international standard or geometric standard, double-click the standard name, enter a new name, and press Enter.
- To delete an international standard or geometric standard, select the standard you want to delete and click Delete.

Pressure Ratings lists all pipe schedules.

- To create a pipe schedule, click New and enter a name (Pressure Rating).
- To associate a pressure rating with a standard, select the standard and then check the check box of the pressure ratings that will belong to the standard.

Pipe Stock Types lists all pipe stock types.

- To associate a standard with a specific stock type, select the standard and then check the check box of the pipe stock types you want to be available in the standard.

5. Click Apply to create the standard, click OK to create the standard and close the Standards window, or click Cancel to close the window without saving any of your changes.

Edit a Standard

To edit a standard

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Click Edit Standards to open the Standards window.
5. Select the international standard you want to edit and change its properties as needed, or select the geometric standard you want to edit and change its properties, the Stock Types it is associated with, or Pressure Ratings assigned to it as needed.
6. Click Apply to save the changes, click OK to save the changes and close the Standards window, or click Cancel to close the window without saving any of your changes.

Delete a Standard

To delete a standard

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Click Edit Standards to open the Standards window.
5. Select the geometric or international standard you want to delete and click Delete Standard.
6. Click Apply to delete the standard, click OK to delete the standard and close the Standards window, or click Cancel to close the window without saving any of your changes.

Create a Pressure Rating

To create a pressure rating

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Click Edit Standards to open the Standards window.
5. Select the geometric standard you want to add a pressure rating for and click New under Pressure Ratings.
6. Enter a name for the pressure rating and check the Assigned check box to associate it with the currently selected geometric standard.
7. Click Apply to save the changes, click OK to save the changes and close the Standards window, or click Cancel to close the window without saving any of your changes.

Edit a Pressure Rating

To edit a pressure rating

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Click Edit Standards to open the Standards window.
5. Select a geometric standard under Standards and then select the pressure rating you want to edit under Pressure Ratings.
6. Edit the pressure rating's name as necessary.

7. Click **Apply** to save the changes, click **OK** to save the changes and close the Standards window, or click **Cancel** to close the window without saving any of your changes.

Associate a Pressure Rating with a Geometric Standard

To associate a pressure rating with a geometric standard

1. Choose **ShipConstructor > Manager** to open Manager.
2. Choose **Piping > Stock Catalog** to open the Pipe Stock Catalog.
3. Select the **Size Definitions** tab.
4. Click **Edit Standards** to open the Standards window.
5. Select the geometric standard you want to associate the pressure rating with from the Standards list.
6. Select the pressure rating you want from the Pressure Ratings list.
7. Check the **Assigned** check box beside the pressure rating name.
8. Click **Apply** to save the changes, click **OK** to save the changes and close the Standards window, or click **Cancel** to close the window without saving any of your changes.

Delete a Pressure Rating

To delete a pressure rating

1. Choose **ShipConstructor > Manager** to open Manager.
2. Choose **Piping > Stock Catalog** to open the Pipe Stock Catalog.
3. Select the **Size Definitions** tab.
4. Click **Edit Standards** to open the Standards window.
5. Select a geometric standard and then select the pressure rating you want to delete and click **Delete**.
6. Click **Apply** to save the changes, click **OK** to save the changes and close the Standards window, or click **Cancel** to close the window without saving any of your changes.

Associate a Stock Type with a Geometric Standard

To associate a stock type with a geometric standard

1. Choose **ShipConstructor > Manager** to open Manager.
2. Choose **Piping > Stock Catalog** to open the Pipe Stock Catalog.
3. Select the **Size Definitions** tab.
4. Click **Edit Standards** to open the Standards window.
5. Select a geometric standard from the Standards list.
6. Select a stock type from the Pipe Stock Types list and check the **Assigned** check box beside the stock type name.
7. Click **Apply** to save the changes, click **OK** to save the changes and close the Standards window, or click **Cancel** to close the window without saving any of your changes.


Nominal Sizes

The nominal size of a pipe is the name that it is identified by. Although the nominal size is a measurement, the measurement does not necessarily correspond exactly to the pipe's actual inside or outside diameter.

Create a Nominal Size

To create a nominal size

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Click Edit Nominal Sizes to open the Nominal Sizes window.



5. Click New.
6. Enter the Primary Size and Units.
You can also enter an Alternate Size and Units.
7. Click OK to close the Nominal Sizes window.
8. Click Apply Changes to save the change or click Done to save the change and close the Pipe Stock Catalog window.

Edit a Nominal Size

To edit a nominal size

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Click Edit Nominal Sizes to open the Nominal Sizes window.
5. Double-click the field you want to edit and enter a new value.
6. Click OK to close the Nominal Sizes window.
7. Click Apply Changes to save the change or click Done to save the change and close the Pipe Stock Catalog.

Note: A warning appears if the nominal size is currently in use. If you click OK, ShipConstructor will save the change to the nominal size and will automatically change all items based on the nominal size. If you click Cancel, ShipConstructor will not save the change to the nominal size.

Delete a Nominal Size

To delete a nominal size

Note: You cannot delete a nominal size that is in use by a size definition or end treatment.

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Click Edit Nominal Sizes to open the Nominal Sizes window.
5. Select the nominal size you want to delete.
6. Click Delete.
7. Click OK to close the Nominal Sizes window.
8. Click Apply Changes to save the change or click Done to save the change and close the Pipe Stock Catalog.

Size Definitions

A size definition is a combination of a standard and a nominal size.

Create a Size Definition

To create a size definition

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Click New to create a new size definition entry.
5. Set the values for the size definition:
 - DN/ND (nominal size)
 - Standard – Pressure Rating (standard)
 - Outer Diameter
 - Inner Diameter
 - Wall Thickness
 - 2nd Size in Name (if you want the secondary size used in the name)
6. Click Apply Changes to save the new size definition or click Done to save the new size definition and close the Pipe Stock Catalog.

Create a 'New Next Size' Size Definition

To create a 'New Next Size' size definition:

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Select an existing size definition to use as a base for the 'new next size' size definition.
5. Click New Next Size to create a new size definition with the next available nominal size greater than the nominal size of the currently selected size definition, and with the same standard, pressure rating, outer diameter, inner diameter, and wall thickness as the currently selected size definition.

6. Click **Apply Changes** to save the new size definition or click **Done** to save the new size definition and close the Pipe Stock Catalog.

Edit a Size Definition

To edit a size definition

Note: Changing a size definition's outer diameter or wall thickness will automatically change all pipe using the size definition.

1. Choose **ShipConstructor > Manager** to open Manager.
2. Choose **Piping > Stock Catalog** to open the Pipe Stock Catalog.
3. Select the **Size Definitions** tab.
4. Select the size definition you want to edit.
5. Set the values for the size definition.
6. Click **Apply Changes** to save the change or click **Done** to save the change and close the Pipe Stock Catalog.

Delete a Size Definition

To delete a size definition

Note: You cannot delete a size definition that is currently in use by a pipe stock or end treatment. You must delete the pipe stock or end treatment before deleting the size definition.

1. Choose **ShipConstructor > Manager** to open Manager.
2. Choose **Piping > Stock Catalog** to open the Pipe Stock Catalog.
3. Select the **Size Definitions** tab.
4. Select the size definition you want to delete.
5. Click **Delete**.
6. Click **Apply Changes** to save the change or click **Done** to save the change and close the Pipe Stock Catalog.

Filter Size Definitions

At the top of the catalog size definition list is the yellow filter row. This filter row lets you filter by any property in the size definition list to narrow down the number of size definitions that appear.

To filter by a property

1. Click on the filter row cell in the column that the filter should be applied for.
2. Enter a number, string, or any other characters to filter by.

Note: The filter row executes a contains filter. This means that if you filter using the string 13, you get hits for 13, 133, Stock13, and any other string containing 13.

3. Repeat Steps 1 and 2 to add additional filters to other columns to further narrow down the number of size definitions displayed.

Note: The filter is applied only to expanded nodes in the tree.

More filtering options

- Under **Units**, select whether to show size definitions that are measured in Metric units, size definitions that are measured in Imperial units, or size definitions measured in Both metric and imperial units.


- To change the order that size definitions are listed in the size definition list, click a column heading to order the list by that setting. (For example, to order the size definition list by outer diameter, click the Outer Diameter column heading.) To reverse the order, click the column heading again.

Import Size Definitions

When you import pipe stock from another project, the stock's associated size definitions are automatically imported with them. See [Import Pipe Stock](#) (page 36).

To import size definitions

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Click Import to open a File Browser.
5. Select a project file (*.PRO) or XML file (*.XML).
6. Click Open.
7. The Import Pipe Size Definitions from XML window appears, letting you select the size definitions (from the project or XML file) you want to import.



8. Check the Import box for the size definitions you want to import.
9. Click OK.

Export Size Definitions

Size definitions are exported to an XML file.

To export size definitions

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Size Definitions tab.
4. Check the Export check boxes for the size definitions you want to export.
5. Click Export XML to open a File Browser.
6. Enter a name for the XML file.
7. Click Save.

End Treatments

An end treatment is a definition of the end of a pipe or fitting. An end treatment consists of a nominal size, a type, several properties, and some geometric information that describes the end treatment. There is also the option to use the Secondary size, if defined, in the name.

Create an End Treatment Type

To make it easier to create and edit end treatments, you can set up end treatment types. An end treatment type has a name and icon (for display in linemode drawings and spool drawings) and can either be used for saddle stitch connection or not.

To create an end treatment type

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the End Treatments tab.
4. Click Treatment Types to open the Treatment Types window.
5. Click New.

A new end treatment type appears in the list.

6. Enter a name for the end treatment type.
7. In the LineMode Icon column, click and choose an icon type to show in linemode drawings (for example, spool drawings).

To create a new LineMode Icon type, click LineMode Icons to open the LineMode Icon window and click New. (For more information, see [End Treatments](#) (page 10).)

8. If you want the end treatment type to be used for a saddle stitch, o-let, or stub-in connection, check the check box for Is Saddle.
9. Click OK to close the Treatment Types window.
10. Click Apply Changes to save the change or click Done to save the change and close the Pipe Stock Catalog.

Edit an End Treatment Type

You can edit the name of an end treatment type, the icon type to show in linemode drawings, and whether the end treatment can be used for saddle stitch, o-let, or stub-in connections.

To edit an end treatment type

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the End Treatments tab.
4. Click Treatment Types to open the Treatment Types window.
5. Edit the values for an end treatment type.
6. Click OK to close the Treatment Types window.
7. Click Apply Changes to save the change or click Done to save the change and close the Pipe Stock Catalog.

Delete an End Treatment Type

To delete an end treatment type

Note: You cannot delete an end treatment type that is in use.

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.

3. Select the End Treatments tab.
4. Click Treatment Types to open the Treatment Types window.
5. Select the end treatment type you want to delete.
6. Click Delete.
7. Click OK to close the Treatment Types window.
8. Click Apply Changes to save the change or click Done to save the change and close the Pipe Stock Catalog.

Create a LineMode Icon

Linemode icons are used for displaying end treatments when only centerlines are being drawn (e.g. in spool drawings). Example icons are shown below. These are actually half-icons; when pipes are connected the two halves form a full icon. For example, the circle linemode icon shows up as a semicircle on one end of a pipe, but when that pipe is connected to another pipe that has the same end treatment, a full circle is shown. The two half-icons are drawn flush to each other even when the end treatment geometry is not exactly flush (i.e. when connections have gaps or the two ends only meet within an angular tolerance).



Linemode icons, left to right: Vertical line, Filled Rectangle, Rectangle, None, Cross, Filled Circle, Circle, and Socket.

To create a linemode icon

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the End Treatments tab.
4. Click LineMode Icons... or click Treatment Types to open the Treatment Types window and then click LineMode Icons... in the Treatment Types window to open the LineMode Icon window.
5. Click New.
A new linemode icon appears in the list.
6. Enter a name for the linemode icon and set the Fill check box and LineMode Icon drop-down menu for the new linemode icon.
7. Under Scale, set options for fixed or relative scale.
8. Click Done to save your changes and close the LineMode Icon window.

Edit a LineMode Icon

You can edit the name of the linemode icon, whether or not it should be filled, the type of icon to display, and how the icon should be scaled.

To edit a linemode icon

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the End Treatments tab.
4. Click LineMode Icons... or click Treatment Types to open the Treatment Types window and then click LineMode Icons... in the Treatment Types window to open the LineMode Icon window.
5. Select the linemode icon you want to edit and change its Name, Fill, or LindeMode Icon in the list or change its scaling properties under Scale.
6. Click Done to save your changes and close the LineMode Icon window.

Delete a LineMode Icon

To delete a linemode icon

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the End Treatments tab.
4. Click LineMode Icons... or click Treatment Types to open the Treatment Types window and then click LineMode Icons... in the Treatment Types window to open the LineMode Icon window.
5. Select the linemode icon you want to delete in the LineMode Icons list.
6. Click Delete.
7. Click Done to save your changes and close the LineMode Icon window.

Set Up End Treatment Properties

You can enter extended data for an end treatment, such as flange type, class, or facing property, using three settings: general property, descriptive property, and facing property. You can also use these properties to specify thread type, pitch, class, and any other information that is required but not contained in other fields.

To set up end treatment properties

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the End Treatments tab.
4. Click Edit Properties to open the End Treatment Properties window.

General Properties	
In Use	Property
<input checked="" type="checkbox"/>	BLD
<input checked="" type="checkbox"/>	BUSHING
<input checked="" type="checkbox"/>	CAP
<input checked="" type="checkbox"/>	CPLG

Desc. Properties	
In Use	Property
<input checked="" type="checkbox"/>	125LB
<input checked="" type="checkbox"/>	150LB
<input checked="" type="checkbox"/>	2000LB
<input checked="" type="checkbox"/>	200LB

Facing Properties	
In Use	Property
<input checked="" type="checkbox"/>	200LB
<input checked="" type="checkbox"/>	FF
<input checked="" type="checkbox"/>	RF

5. To create a new general property, under General Properties click New and enter a name for the property.
To create a new descriptive property, under Desc. Properties click New and enter a name for the property.
To create a new facing property, under Facing Properties click New and enter a name for the property.
6. Click OK to close the End Treatment Properties window.
7. Click Apply Changes to save the change or Done to save the change and close the Pipe Stock Catalog.

Create an End Treatment

When creating an end treatment, you define an end treatment type, a nominal size, and geometric information about the end treatment, the type of geometry (box, cylinder, or cone), and the dimensions of the geometry. You can also define general, facing, and descriptive properties to provide further information about the end treatment.


To create an end treatment

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.

3. Select the End Treatments tab.
4. Do one of the following:
 - To create one end treatment, click New. (If you do not see the New button, click the down arrow beside New – All Sizes or New – From Range and select New.)
 - To create end treatments for a range of nominal sizes, click New – From Range. (If you do not see the New – From Range button, click the down arrow beside New or New – All Sizes and select New – From Range.) The End Treatment Range window appears. Set the Min and Max values to specify the range of nominal sizes and then click OK.
 - To create end treatments for all nominal sizes, click New – All Sizes. (If you don't see the New – All Sizes button, click the down arrow beside New or New – From Range and select New – All Sizes.)

Tip: You can also right-click and choose New, New – From Range, or New – All Sizes.

The Edit End Treatments window appears listing the end treatments that will be created.



5. Set the values for the End Treatment Type, the Geometry, and A, B, and C to specify the size of the geometry type for each end treatment. (The images along the top of the window indicate the meaning of each value.) These values have no effect on the length or diameter of pipes or fittings; they are for display and interference checking purposes only. The General Property, Desc. Property, Facing Property, and 2nd Size in Name can also be set now.

Tip: Click the Fill Down check box to enable the Edit Endtreatments dialog's fill down functionality, when enabled any change made to an end treatment will change the same property in all end treatments below the selected end treatment to the same value. This allows for quickly changing a large number of end treatments to have the same values.

6. Click OK to close the New End Treatment window.
The new end treatments are listed in the Pipe Stock Catalog.
7. Click Apply Changes to save the change or click Done to save the change and close the Pipe Stock Catalog.

Edit an End Treatment

To edit an end treatment

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the End Treatments tab.
End treatments are grouped by nominal size.

To filter the list of end treatments, under Filter select Metric, Imperial, or Both.

4. Select the end treatment or end treatments to edit and click Edit. The Edit End Treatments window appears listing the end treatments to be edited.
5. Edit the values for the end treatments as desired.
6. Click OK to close the Edit End Treatment window.
7. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Note: Editing the non-geometric properties of "In Use" stocks is now possible. To do this you require the Edit In-Use Stock Non-Geometric Properties permission under Pipe->Manager in the User Permissions dialog. Changes made to stocks that are in use in production drawings will cause the production drawings to be flagged as out of date.

Delete an End Treatment

To delete an end treatment

Note: You cannot delete an end treatment that is in use by a connection or stock item.

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the End Treatments tab.
End treatments are grouped by nominal size.
To filter the list of end treatments, under Filter select Metric, Imperial, or Both.
4. Select the end treatment you want to delete.
5. Click Delete.
6. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Usage Log

The Usage Log button on the End Treatments tab generates a log file detailing all of the different stocks using the selected end treatment.

To create a usage log

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the End Treatments tab.
4. Select the end treatment you want to create a usage log for.
5. Click Usage Log, a text file will be created, and displayed in your computer's default .txt file editor, detailing which stocks are using the selected end treatment.

Filter End Treatments

At the top of the catalog end treatment list is the yellow filter row. This filter row lets you filter by any property in the end treatment list to narrow down the number of end treatments displayed.

To filter by a property

1. Click on the filter row cell in the column that the filter should be applied for.
2. Enter a number, string, or any other characters to filter by.

Note: The filter row executes a contains filter. This means if you filter using the string 13, you get hits for 13, 133, Stock13, and any other string containing 13.

- Repeat Steps 1 and 2 to add additional filters to other columns to further narrow down the number of end treatments displayed.

Note: The filter is applied only to expanded nodes in the tree.

More filtering options


- Under Units, select whether to show only end treatments that are measured in Metric units, end treatments that are measured in Imperial units, or end treatments measured in Both metric and imperial units.
- To change the order that end treatments are listed in the end treatment list, click a column heading to order the list by that setting. (For example, to order the end treatment list by geometry, click the Geometry column heading.) To reverse the order, click the column heading again.

Import End Treatments

When you import pipe stock from another project, the stock's associated end treatments are automatically imported. See [Import Pipe Stock](#) (page 36).

To import end treatments

- Choose ShipConstructor > Manager to open Manager.
- Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
- Select the End Treatments tab.
- Click Import to open a File Browser.
- Select a project file (*.PRO) or XML file (*.XML).
- Click Open.
- The Import Pipe End Treatments from XML window appears, letting you select the end treatments you want to import.



- Check the Import box for the end treatments you want to import.
- Click OK.

Export End Treatments


To export end treatments

- Choose ShipConstructor > Manager to open Manager.
- Choose Piping > Stock Catalog to open the Pipe Stock Catalog.

3. Select the End Treatments tab.
4. Check the Export check boxes for the end treatments you want to export.
5. Click Export XML to open a File Browser.
6. Enter a name for the XML file.
7. Click Save.

Specifications


A specification, or spec, is a collection of stocks. You typically use specs as a way of limiting the stocks that designers can use. For example, you can create a spec for each pipe system. Each spec would contain only the stocks that you want used for that system. Whenever designers are working on that system, they can only choose stocks from the associated spec.



Create a Spec

To create a spec

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Edit Specs to open the Pipe Specs window.



5. Click New.
6. Enter a name and, optionally, a description for the spec and then press Enter.
7. Click OK to close the Pipe Specs window.
8. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Delete a Spec

To delete a spec

Note: You cannot delete a spec that contains catalog stocks.

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Edit Specs to open the Pipe Specs window.
5. Select the spec you want to delete.
6. Click Delete.
7. Click OK to close the Pipe Specs window.
8. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Edit a Spec

To edit a spec

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Edit Specs to open the Pipe Specs window.
5. Double-click the name or description of the spec you want to edit and enter a new value.
6. Click OK to close the Pipe Specs window.
7. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.


Catalogs

A catalog is a collection of pipe stocks, similar to the physical catalog of a supplier that you purchase pipe stock from. By setting up catalogs of pipe stock in ShipConstructor, you can reproduce your supplier's physical catalogs or categorize pipe stock into logical groups, such as carbon steel.

Create a Catalog

To create a catalog

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Edit Catalogs to open the Pipe Catalogs window.



5. Click New.
6. Enter a name and, optionally, a description for the catalog and press Enter.
7. Click OK to close the Pipe Catalogs window.
8. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Delete a Catalog

Note: You cannot delete a catalog that contains stocks.

To delete a catalog

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Edit Catalogs to open the Pipe Catalogs window.
5. Select the catalog you want to delete.
6. Click Delete.
7. Click OK to close the Pipe Catalogs window.
8. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Edit a Catalog

To edit a catalog

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Edit Catalogs to open the Pipe Catalogs window.
5. Double-click the name or description of the catalog you want to edit and enter a new value.
6. Click OK to close the Pipe Catalogs window.
7. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Manufacturers

See Manufacturers in the Structure manual.

Materials

See Materials in the Structure manual.

Pipe Stock

A pipe stock is a standard pipe or fitting that you are able to purchase or manufacture and that you want to use in your project.

Filter Pipe Stocks

At the top of the catalog stock list is the yellow filter row. This filter row lets you filter by any property in the stock list to narrow down the number of stocks displayed.

To filter by a property

1. Click on the filter row cell in the column that the filter should be applied for.
2. Enter a number, string, or any other characters to filter by.

Note: The filter row executes a contains filter. This means that if you filter using the string 13, you get hits for 13, 133, Stock13, and any other string containing 13.

3. Repeat Steps 1 and 2 to add additional filters to other columns to further narrow down the number of stocks displayed.

Note: The filter is applied only to expanded nodes in the tree.

More filtering options

- Under Units, select whether to show only stocks that are measured in Metric units, stocks that are measured in Imperial units, or stocks measured in Both metric and imperial units.
- To change the order that stocks are listed in the stock list, click a column heading to order the list by that setting. (For example, to order the stock list by weight, click the Weight column heading.) To reverse the order, click the column heading again.

Create a Stock

To create a stock

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
Pipe stocks are grouped by type.
4. Select the type of pipe stock you want to create (for example, Pipe, Elbow, or Cross) or select a pipe stock of the type you want to create.
5. Click New.
6. Enter a name for the pipe stock and press Enter.
7. Set the pipe stock properties (see below).
8. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Common Properties

Stock Name

The name of the stock. You can enter any name you want. The name is what you will see most often when modeling and selecting items to add to the model and in your BOMs. When editing a stock in the Edit Stock window, you can click in the

name cell and bring up a list of the currently defined naming conventions that are valid for the stock type. Choosing one of the naming conventions in the list will generate a name for the stock based on the selected naming convention.

Schedule

The stock's schedule or pressure rating.

Description

A full description of the stock.

Material

The material grade that the stock is made of.

Manufacturer

The manufacturer that produces the stock.

Additional Thickness

Adds external thickness to the pipes and fittings using the Outer Diameter as defined in the Size Definitions tab. In some cases this may not be the correct outside diameter for the fitting. For example, a coupling generally has an outside diameter greater than that of the pipe. To make sure the coupling is the right size, extra material thickness can be added.

Weight

The weight of the stock. For straight pipes the units are weight per foot and weight per meter, depending whether the stock is being viewed with metric or imperial properties.

Wet Weight

The weight of the stock when filled with fluid. Wet weight applies to all stock types except for straight pipes.

End N Treatment

The end treatment for the Nth end of the stock. When you select the end treatment for a given end, you will also be required to select an end treatment size definition for the end. Select the definition using the end treatment drop-down tree-control, which lists end treatments organized by end treatment type, nominal size, end treatment, and then size definitions. The listing of size definitions below the end treatment provides you with a method of setting a size definition for the end other than the size definition of the stock itself. This is necessary for representing some types of stocks. The end treatments and size definitions available to a given stock depend on the stock type and the size definition of the stock. You will find details of what end treatments are available for a given stock type under the Properties listing for the specific type.

Tip: End Treatments in the Pipe Stock Grid and Pipe Stock Edit dialogs now "Fill Down", this means that when changing an end treatment all further ends of the stock are changed to the same value. For example if the 2nd end of a cross is changed to a PL 2" end treatment, the 3rd and 4th ends of the cross will also be changed to the same PL 2" end treatment, but the 1st end will be unchanged.

Custom Attributes


User defined attributes, set up in Manager, appear last in the stock edit dialog. User defined attributes also appear in the pipe stock grid at the end of the stock property columns, in the stock grid the properties are not editable but can be filtered or sorted against.

Tip: User defined attributes are also available in the Select Stock dialog when creating a pipe part, this allows for filtering and sorting based on the attributes, making finding the right stock easier.

Preview Control

The preview window will display the abbreviations of each end by the corresponding end. This allows the user to easily determine which ends need modifying and which end is being modified.

Branch Properties




Stock Editor - Tee

Properties

Property	Value
Common Properties	
Stock Name	T-CN_02.0_200-B466
Schedule	2" ANSI B16.9
Description	-NI CLS 200 BW STRAIGHT TEE
Weight	635.03 g
Wet Weight	0 g
Additional Thickness	0 mm
Manufacturer	COM
Material	ASTM B-466
End 1 Length	63.5 mm
End 2 Length	63.5 mm
End 3 Length	63.5 mm
Specific Properties	
EndTreatment 1	BW 2"
EndTreatment 2	BW 2"
EndTreatment 3	BW 2"
End 1 Trimmable	<input checked="" type="checkbox"/>
End 2 Trimmable	<input checked="" type="checkbox"/>
End 3 Trimmable	<input checked="" type="checkbox"/>
Angle A	180
Angle B	0

Preview



OK Cancel

See [Common Properties](#) (page 19) for a description of properties common to all stock types.

End Treatments

Branch end treatments are constrained so that End 1 must have an end treatment with a nominal size equal to the nominal size of the schedule of the stock, and Ends 2 and 3 must have end treatments with nominal sizes equal to or less than the nominal size of the schedule of the stock.

End 1, 2, and 3 Length

The lengths measured from the intersection of the three centerline axes to the end faces.


End 1, 2, and 3 Trimmable

A flag indicating whether or not the given end can be trimmed back.

Angle A and Angle B

Angle A defines the total swept angle from End 1 to End 2, and Angle B defines the total swept angle from End 1 to End 3.

Cap Properties



Stock Editor - Cap

Property	Value
Common Properties	
Stock Name	CAP-CS_02.5_ST-A234
Schedule	2 1/2" ANSI B16.9 STD
Description	STD BUTTWELDED PIPE CAP
Material	ASTM A-234
Manufacturer	COM
Weight	362.87 g
Wet Weight	0 g
Additional Thickness	0 mm
Length	38.1 mm
Specific Properties	
Cap Type	Round
End Treatment	BW 2 1/2"
Flat Length	0 mm
Custom Attributes	
Order Number	
Model Number	
User Number	

Preview

E 1

OK Cancel

See [Common Properties](#) (page 19) for a description of properties common to all stock types.

Cap Type

The cap type defines how the geometry, specifically the Flat Length, of the cap is interpreted. The available cap types are Round, Square Plug, and Recessed Square.

End Treatment

The end treatment of the cap must have the same nominal size as the schedule of the stock.

Length

The length of the cap from base to end, not including the flat length.

Flat Length

The flat length defines the height or depth, relative to the end of the cap, for the plug in square plug and recessed square caps.


Connector Properties

SC 2004 Stock Editor - Weldolet

Properties

Property	Value
Common Properties	
Stock Name	SOCKOLET-CS_2.0-A105
Schedule	2" MFR
Description	SOCKOLET
Material	ASTM A-105
Manufacturer	COM
Weight	231.33 g
Wet Weight	0 g
Additional Thickness	0 mm
Specific Properties	
Length	38.1 mm
End 1 Treatment	WB 2" - SOCKOLET
End 2 Treatment	SW 2" - SOCKOLET
Custom Attributes	
Order Number	
Model Number	
User Number	

Preview



OK Cancel

See [Common Properties](#) (page 19) for a description of properties common to all stock types.

Length

The length is the overall length of the connector. The end treatments draw themselves inward.

End 1 and 2 Treatment


Connector end treatments are constrained so that the end treatments for both ends must have the same nominal size as the nominal size of the schedule of the stock. The only exception to this is the adapter connector type, which has no restrictions on which end treatments can be assigned to which ends.

Cross Properties

SC 2003 Stock Editor - Cross

Property	Value
Common Properties	
Stock Name	Cross_B16_1.25_A351
Schedule	3/4" ANSI B16.11 2000LB
Description	
Material	ASTM A-351, GR CF8M
Manufacturer	WARREN
Weight	1.2 lb
Wet Weight	1.2 lb
Additional Thickness	0 mm
End 1 Length	1.5 in
End 2 Length	1.5 in
End 3 Length	1.5 in
End 4 Length	1.5 in
Specific Properties	
End 1 Treatment	PL 3/4"
End 2 Treatment	PL 3/4"
End 3 Treatment	PL 3/4"
End 4 Treatment	PL 3/4"
End 1 Trimmable	<input type="checkbox"/>
End 2 Trimmable	<input type="checkbox"/>
End 3 Trimmable	<input type="checkbox"/>

Preview



OK Cancel

See [Common Properties](#) (page 19) for a description of properties common to all stock types.

End Treatments

The end treatments for a cross are constrained so that End 1 must have an end treatment with the same nominal size as the nominal size of the schedule of the stock, while Ends 2, 3, and 4 can have end treatments with a nominal size less than or equal to that of the schedule of the stock.

End 1, 2, 3, and 4 Length

The lengths measure from the intersection of the four centerline axes to the end faces.

End 1, 2, 3, and 4 Trimmable


A flag indicating whether or not the given end can be trimmed back.

Elbow Properties

SC 2004 Stock Editor - Elbow

Property	Value
Common Properties	
Stock Name	E-45LR-CN_02.0_B-466
Schedule	2" ANSI B16.9
Description	-NI CLS 200 LR BW 45° ELBOW
Material	ASTM B-466
Manufacturer	COM
Weight	217.72 g
Wet Weight	0 g
Additional Thickness	0 mm
Specific Properties	
End 1 Total Length	34.93 mm
End 2 Total Length	34.93 mm
End 1 Straight Length	3.36 mm
End 2 Straight Length	3.36 mm
Radius	76.2 mm
Radius(x Nominal Size)	1.5
Minimize Straight Length	<input type="checkbox"/>
Angle	45
Number of Segments	1
End 1 Trimmable	<input checked="" type="checkbox"/>
End 2 Trimmable	<input checked="" type="checkbox"/>

Preview



OK Cancel

See [Common Properties](#) (page 19) for a description of properties common to all stock types.

End Treatments

Elbow end treatments are constrained so that End 1 must have an end treatment with the same nominal size as the schedule of the stock, while End 2 can have a nominal size less than or equal to the nominal size of the schedule of the stock. Assigning End 2 an end treatment with a smaller nominal size than the schedule of the stock makes it possible to create reducing elbows.

End 1 and End 2 Total Length

Total length measures the length of the elbow from the intersection of the two centerline axes to the end of the elbow including any additional straight length.

Note: Since the intersection of the two centerline axes becomes much further away as the angle increases past 90 degrees, when the angle of the corner is greater than 90 degrees then the end lengths are calculated as if the angle was 90 degrees.

Tip: Elbow geometry is linked, modifying one geometric property will cause changes in the other geometric properties of the elbow. Increasing total length results in gains to the straight length value of the given end, decreasing total length will result in decreases in the straight length and if necessary changes to the elbow's radius, which will in turn result in changes to the other end's total length and/or straight length as necessary to match the new radius. If you want increases in total length to affect the radius of the elbow instead of the straight length of the end, check the Minimize Straight Length check-box. Changes to the radius property will affect straight length of the ends first, and then if necessary it may also affect the total length values.

End 1 and End 2 Straight Length

Straight length is the length that is added to the given end of the elbow, measured from the face of the end.

Radius

The radius of the elbow. The radius cannot exceed either of the end lengths.

Radius (x Nominal Size)

The radius defined as a multiple of the nominal size of the elbow.

Minimize Straight Length

Checking the Minimize Straight Length check-box changes the way geometric values react to each other when you make changes to them. The straight length values of the elbow will never be increased when this is checked, this means that you can change the angle or total end length values and the radius will be changed to automatically to match instead of the straight length being changed, this allows elbow geometry to be defined using just angle and end length values.

Angle

The total swept angle of the elbow. Valid angles are between 0° and 360°.

Number of Segments

The number of segments used for modeling the bent section of the elbow. You can create a mitered elbow by setting the number of segments to a value greater than one.

End 1 and End 2 Trimmable

A flag indicating whether or not the given end can be trimmed back.

Pipe Properties

Property	Value
Common Properties	
Stock Name	P-ERW-CS_02.0_160_A53-A
Schedule	2" ASME B36.10 160
Description	SCH 160 ERW PIPE
Material	ASTM A-53, GR. A
Manufacturer	COM
Additional Thickness	0 mm
Weight per M	11.1 kg
Specific Properties	
Minimum Length	50.8 mm
Maximum Length	6096 mm
Minimum Usable Remnant	0 mm
End 1 Treatment	PL 2"
End 2 Treatment	PL 2"
Custom Attributes	
Order Number	
Model Number	
User Number	

Preview: 3D model of a pipe with ends labeled E1 and E2.

Buttons: OK, Cancel

See [Common Properties](#) (page 19) for a description of properties common to all stock types.

End Treatments

Both ends of a pipe stock are constrained so that the nominal size of the end treatments must be equal to the nominal size of the stock's schedule.

You can also specify generic end treatments for pipe stocks. To do this add allowable end treatments to existing stocks by clicking the End Types button and selecting end treatment types in the dialog that is shown. The end treatments that are then available to be applied to parts using this stock are any that are of a type that was added and that the nominal size matches the schedule of the stock. The End Types button is only enabled when a straight pipe stock is selected. The two figures below show how to add allowable end treatments to pipe stocks.

End 1 Type	End 2 Type	Allowable End Types	Minimum Length	Maximum Length
PL 1"	PL 1"		50.8 mm	6096 mm
PL 1/8"	PL 1/8"		50.8 mm	6096 mm
PL 1/8"	PL 1/8"		50.8 mm	6096 mm
PL 1/4"	PL 1/4"		50.8 mm	6096 mm
PL 1/4"	PL 1/4"		50.8 mm	6096 mm
PL 3/8"	PL 3/8"		50.8 mm	6096 mm
PL 3/8"	PL 3/8"		50.8 mm	6096 mm
PL 1/2"	PL 1/2"		50.8 mm	6096 mm
PL 1/2"	PL 1/2"		50.8 mm	6096 mm
PL 1/2"	PL 1/2"		50.8 mm	6096 mm
PL 3/4"	PL 3/4"		50.8 mm	6096 mm
PL 3/4"	PL 3/4"		50.8 mm	6096 mm
PL 3/4"	PL 3/4"		50.8 mm	6096 mm
PL 1"	PL 1"	SOF;PL;FL;NONE	50.8 mm	6096 mm
PL 1"	PL 1"		50.8 mm	6096 mm

Stock Functions


- ☒ Edit new stocks
- New
- New Next Size
- Edit
- Delete
- Stock Usage
- End Types**

Spec Functions

- Assign To Spec
- Edit Specs

Catalog Functions

- Assign To Cat.
- Edit Catalogs



Min and Max Length

The minimum and maximum length the stock can be purchased or handled. For straight pipe, the minimum length must be less than the maximum length. When you are placing pipes, ShipConstructor takes these lengths into account (preventing you from placing pipes that are less than the minimum length or greater than the maximum length).

Minimum Usable Remnant

This value is the minimum length that a piece of leftover pipe must be to be considered reusable.

Reducer Properties

Property	Value
Common Properties	
Stock Name	R-CON-CN_02.0X01.0_200-B466
Schedule	2" ANSI B16.9
Description	LS200 BW CONCENTRIC REDUCER
Material	ASTM B-466
Manufacturer	COM
Weight	317.51 g
Wet Weight	0 g
Additional Thickness	0 mm
End 1 Length	0 mm
End 2 Length	0 mm
Specific Properties	
Offset	0 mm
Transition Length	76.2 mm
End 1 Treatment	BW 2"
End 2 Treatment	BW 1"
Custom Attributes	
Order Number	
Model Number	
User Number	

See [Common Properties](#) (page 19) for a description of properties common to all stock types.

End Treatments

The ends of a reducer stock are constrained so that End 1 must have an end treatment with a nominal size equal to that of the stock's schedule, and End 2 must have an end treatment with a nominal size less than the nominal size of the schedule of the stock.

Offset

The offset makes it possible for the user to create eccentric reducers. That is, reducers with the centerline of the pipe at one end offset from the centerline of the pipe at the other end.


Transition Length

The length of the body of the reducer or the length of the reducing section of the reducer. This does not include the lengths of the two ends.

End 1 and End 2 Length

The length of the specified end of the reducer measured from the face of the end of the reducer corresponding to the end number.

Valve Properties



Stock Editor - Gate

Properties

Property	Value
Common Properties	
Stock Name	V-GAT-FL-CS_02.0_CL5150
Schedule	2" ANSI B16.34 150LB
Description	ONZE TRIM, NON RISING STEM
Material	ASTM A-216, GR. WCB
Manufacturer	SPACE
Weight	22226.02 g
Wet Weight	0 g
Additional Thickness	19.05 mm
End Information	
End 1 Treatment	FL 4" - 150LB - RF
End 2 Treatment	FL 4" - 150LB - RF
End 3 Treatment	(none)
End 1 Length	88.9 mm
End 2 Length	88.9 mm
End 2 Theta	0
End 3 Length	219.08 mm
End 3 Position	219.08 mm
End 3 Theta	0
End 3 Phi	0
Handle	

Preview

3D model of a gate valve showing ends E1 and E2.

OK Cancel

See [Common Properties](#) (page 19) for a description of properties common to all stock types.

A valve consists of two or three ends and a handle. Each end is defined by a cone where the base of the cone is the opening of the end and the tip of the cone is the start point of the end. Everything cons The opening of End 1 is considered the origin of all points in the valve. The start point of End 2 is always coincident with the start point of End 1.

End 1, 2, and 3 Length

The length of each valve end from its opening to the center of the valve, where the ends meet.

End 2 and End 3 Theta

End 2 Theta is the angle between the centerline of End 1 and the centerline of End 2. If there is an End 3 in the valve, its centerline will also connect to the centerline of End 1 and provide End 3 Theta.

End 3 Phi

The angle for End 2 will always rotate in the plane of the valve. Because a third end can be in a different plane from the first two ends, End 3 must be defined by two angles. End 3 Phi is the angle that End 3 centreline rotates about the centerline of End 1.

End 3 Position

End 1 and End 2 will always have a coincident start point. End 3 is not as constrained. End 3 start point is measured along the centerline of End 1 a distance from the valve origin (the opening of End 1).

Handle Type

The handle types in ShipConstructor are defined by individual users. For each valve in a drawing, you pick a handle type from the drop-down menu.

Handle Position

To position the handle of the valve, you must enter a length that starts at the valve origin and runs along the centerline of End 1.

Handle Theta

Like Ends 2 and 3 Theta, the centerline of the valve handle will form an angle with the centerline of End 1, rotating in the plane of the valve.

Handle Phi

Like End 3, the handle direction must be defined by two angles. Handle Phi is the angle formed between the centerline of the handle and the centerline of End 1 rotated about the centerline of End 1.

Handle Rotation

If the handle has more than a simple stem, it has a rotation. If the handle is not symmetrical about the stem, the handle rotation is defined as the handle's rotation about handle axis or stem.

CG Point (X, Y, Z)

Each valve will have a different centre of gravity (CG) depending on the physical properties of the valve. The CG is measured from valve origin, and the information might be found in your parts catalog. If you cannot find a CG for your valve, create a value based on your valve's density and weight.

Create a 'New Next Size' Stock

To create a 'New Next Size' stock

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Select the desired base stock from the Stocks Grid.
5. Click New Next Size to create a stock based on the currently selected stock but with the next available size definition and the next available sizes for each end of the stock. All other end treatment information (Treatment Type, General Prop., etc) are maintained as closely as possible, if they cannot be maintained no new stock will be created and an error will notify the user of the problem.
6. Enter a name for the new stock.
7. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Valve Handles

Create a Valve Handle

To create a valve handle

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Valve Handles to open the Valve Handle Editor.
5. Select the desired valve handle type from the Valve Handles grid and click New.

6. Enter a name for the valve handle and set the properties A – H and the angles A and B to values appropriate for the handle type you are creating.
7. Click OK to close the Valve Handles window.
8. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Edit a Valve Handle

To edit a valve handle

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Valve Handles to open the Valve Handle Editor.
5. Select the desired valve handle from the Valve Handles grid.
6. Modify the valve handle's properties in the Handle Properties grid.
7. Click OK to close the Valve Handles window.
8. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Delete a Valve Handle

To delete a valve handle

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Valve Handles to open the Valve Handle Editor.
5. Select the desired valve handle from the Valve Handles grid.
6. Click Delete to delete the selected valve handle.
7. Click OK to close the Valve Handles window.
8. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Edit a Valve Type


To edit a valve type

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Valve Types to open the Valve Types window.
5. Select a valve type you want to edit and change its draw icon using the drop-down list on the right.
6. Click OK to close the Valve Types window.
7. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Create a Valve Handle 2D drawing


To create a valve handle 2D Drawing

1. Create a new AutoCAD drawing file.
2. Draw the geometry that will be used to represent the valve handle in a spool drawing.
 - a. The handle geometry starts at the origin.
 - b. The handle geometry must be drawn in the XY plane.

- c. The handle will be drawn in the Y direction.
 - d. When the geometry is inserted into a spool drawing it will be scaled based on the length of the handle.
3. Save the drawing file to a known location.
4. Choose ShipConstructor > Manager to open Manager.
5. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
6. Select the Create/Edit Pipe tab.
7. Click Valve Handles to open the Valve Handle Editor.
8. Select the desired valve handle type from the Valve Handles grid.
9. Select the 2D Geometry row.
10. Click the import button. 
11. Select the saved drawing file.
 - a. The 2D Geometry row will display <LOADED> to indicate that a drawing file has been loaded.
 - b. The drawing will be stored in the database. Changes to the drawing file will not affect the geometry of the icon unless the file is imported again.
 - c. All valve handles of the same type will use the same 2D geometry.


Edit a Valve Handle 2D Drawing

To edit a valve handle 2D drawing

1. Open a drawing file containing the geometry to use for the valve handle
2. Make the necessary changes to the geometry.
 - a. Must start at the origin, drawn in the XY plane, with the handle direction in the Y direction.
3. Save the drawing file to a known location.
4. Choose ShipConstructor > Manager to open Manager.
5. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
6. Select the Create/Edit Pipe tab.
7. Click Valve Handles to open the Valve Handle Editor.
8. Select the desired valve handle type from the Valve Handles grid.
9. Select the 2D Geometry row.
10. Click the import button. 
11. Select the saved geometry file.
12. The handle icon will be updated in the drawings where it is used the next time the drawing is opened or when an update is performed on the drawing

Deleting a Valve Handle 2D Drawing

To delete a valve handle 2D drawing

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Valve Handles to open the Valve Handle Editor.
5. Select the desired valve handle type from the Valve Handles grid.
6. Select the 2D Geometry row.
7. Click the delete button. 

- a. The 2D Geometry row will display <NONE> to indicate that no valve handle drawing has been loaded.

Add or Remove Pipe Stocks To or From a Spec

To add or remove a stock to and from a spec

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Select the stocks you want to add or remove to or from a spec.
5. Click Assign To Spec to open the Assign To Spec window.
6. Under Assign, check the check box for the specs that you want to add the stocks to. Uncheck the check box for the specs to remove the stocks from.
7. Click OK to close the Assign To Spec window.
8. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Add or Remove Pipe Stocks To or From a Catalog

To add or remove a stock to and from a catalog

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Select the stocks you want to add or remove to or from a catalog.
5. Click Assign To Cat. to open the Assign To Catalog window.
6. Under Assign, check the check box for the catalogs that you want to add the stocks to. Uncheck the check box for the catalogs to remove the stocks from.
7. Click OK to close the Assign To Catalog window.
8. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Edit a Pipe Stock

To edit a pipe stock

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Edit the values of any stocks or select the desired stock and click Edit to bring up the Edit Stock window.
5. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Note: Stock end treatments now “fill over”, so changing an end treatment will change the stocks subsequent end treatments to match.

Note: Editing the non-geometric properties of “In Use” stocks is now possible. To do this you require the Edit In-Use Stock Non-Geometric Properties permission under Pipe->Manager in the User Permissions dialog. Changes made to stocks that are in use in production drawings will cause the production drawings to be flagged as out of date.

Change Stock Subtype

This feature allows for stocks of a given sub-type to be changed to any other sub-type with the same parent type. This means any branch stock can be changed to any of the branch stock sub-types; Lateral, Misc, Tee, or Wye, this allow applies to Connector and Valve types.

To change a stock's subtype


1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Select the stock or stocks to have their subtype changed.
5. Click the right mouse button over one of the selected stocks to access the context menu.
6. Select the Change Subtype menu option and click on the subtype to change the stocks to.
7. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Stock Usage


This powerful feature lets you easily find all part instances that are using a certain stock. In addition to creating a report where the stock is used, you can interactively open drawings and inspect the parts using the selected stock.

To check stock usage

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Select a stock that is in use.
5. Click Stock Usage. The Drawings using stock window appears.



6. All drawings that contain parts using this stock you selected are listed.
7. Select a drawing node and double-click or click the Open Drawing button to open the drawing. The Parts using stock window appears.



8. You can inspect the parts in the drawing by clicking on the part in the window. Click OK to close the drawing and return to the Drawings using stock window.

To create a stock usage log


1. Open the Drawings using stock window.
2. Click Create Log. A log file summarizing where the stock is used is created and displayed. The log file is stored in the LogFiles / Pipe / Stock Usage folder.

Import Pipe Stock

You can import pipe stock from another project. You can also set up pipe stock in an XML file (using Export XML) and import the XML file into ShipConstructor.

To import pipe stock

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Click Import to open a File Browser.
5. Select a project file (*.PRO) or XML file (*.XML).
6. Click Open.
7. The Import Pipe Stock from XML window appears, letting you select the pipe stocks you want to import.



8. Check the Import check box for each stock that you want to import.
9. Click OK.

Set Up Pipe Stock in an XML File (Using XML)

To set up pipe stock in an XML file (using XML)

1. Use the schema <http://www.shipconstructor.com/XMLSchemas/ARLLibraryV2.32.xsd> and generate an XML file conforming to the schema containing the desired pipe stocks.

Export Pipe Stock

To export pipe stock

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Create/Edit Pipe tab.
4. Check the Export check boxes for the pipe stocks to export.
5. Click Export XML to open a File Browser.
6. Enter a name for the XML file.
7. Click Save.

Accessory Packages

An accessory package is a collection of accessories (for example, nuts, bolts, gaskets, and washers) that accompany a penetration package, a pipe hanger, a pipe connection, or an HVAC connection. Accessory packages are not displayed in drawings but are listed in BOMs and reports.

When setting up accessory packages, you first define accessory types. Accessory types are groups or categories of similar types of accessories. For example, you can define an accessory type named bolts. After defining accessory types, you can then define specific accessories. Finally, you create accessory packages and add accessories to them.

Create an Accessory Type


To create an accessory type

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Accessory Packages to open the Accessory Packages window.
3. Under Accessories, click New Type to create a new accessory type.
4. Enter a name for the accessory type (for example, Bolts, Gaskets, Nuts, or Washers) and press Enter.

Create an Accessory Package

To create an accessory package

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Accessory Packages to open the Accessory Packages window.



3. Set Type to the type of accessory package you want to create.
4. Click New to create a new accessory package.
5. Enter a name for the accessory package and press Enter.

Create an Accessory

To create an accessory

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Accessory Packages to open the Accessory Packages window.
3. Under Accessories, select the accessory type.
4. Click New Acces. to create a new accessory of the selected type.

Note: The New Access. button changes to the name of the selected accessory type.

5. Enter a name for the accessory and press Enter.
6. Enter a Description and Weight for the accessory.

Copy an Accessory Package

To copy an accessory package

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Accessory Packages to open the Accessory Packages window.
3. Set Type to the type of accessory packages to list.

Tip: Use the Spec Filter to filter the lists under Accessory Packages by spec.

4. Select the accessory package you want to copy.
5. Click Copy to copy the accessory package.
6. Enter a name for the copied accessory package and press Enter.

Delete an Accessory Package

To delete an accessory package

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Accessory Packages to open the Accessory Packages window.
3. Set Type to the type of accessory packages you want to list.

Tip: Use the Spec Filter to filter the lists under Accessory Packages by spec.

4. Select the accessory package you want to delete.
5. Click Delete to delete the accessory package.

Delete an Accessory or Accessory Type

To delete an accessory or accessory type

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Accessory Packages to open the Accessory Packages window.
3. Under Accessories, select the accessory or accessory type that you want to delete.
4. Click Delete.

Add or Remove an Accessory To or From an Accessory Package

To add or remove an accessory to or from an accessory package

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Accessory Packages to open the Accessory Packages window.
3. Set Type to the type of accessory packages you want to list.

Tip: Use the Spec Filter to filter the lists under Accessory Packages by spec.

4. Select the accessory package you want to add or remove an accessory to or from.
Accessories that currently belong to the accessory package are listed under Spec Filter.
5. To add an accessory to the accessory package, under Accessories select the desired accessory and click Add.

Note: To add several of the same type of accessory, add the accessory once and set the Qty value.

To remove an accessory from the accessory package, under Spec Filter select the desired accessory and click Remove.

Add or Remove an Accessory Package To or From a Spec

To add or remove an accessory package to or from a spec

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Accessory Packages to open the Accessory Packages window.
3. Set Type to the type of accessory packages you want to list.

Tip: Use the Spec Filter to filter the lists under Accessory Packages by spec.

4. Select the accessory package you want to add or remove to or from a spec.
5. Click Assign Spec to open the Accessory Package Specs window.
6. Check the check box of the specs you want to add the accessory package to.
To remove an accessory package from a spec, uncheck its check box.
7. Click OK to close the Accessory Package Specs window.

Import Accessory Packages

You can import accessory packages from another project or from an XML file that was exported from another project.

To import accessory packages

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Accessory Packages to open the Accessory Packages window.
3. Click Import to open a File Browser.
4. Select a project file (*.PRO) or XML file (*.XML).
5. Click Open.
6. Click OK to close the Accessory Packages window.

Export Accessory Packages

You can export accessory packages to an XML file (for example, to import into another project or to edit using other software).

To export accessory packages

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Accessory Packages to open the Accessory Packages window.
3. Set Type to the type of accessory packages you want to list.

Tip: Use the Spec Filter to filter the lists under Accessory Packages by spec.


4. Check the Export check boxes for the accessory packages you want to export.
5. Click Export XML to open a File Browser.
6. Enter a name for the XML file.
7. Click Save.
8. Click OK to close the Accessory Packages window.

Connections

A pipe connection is a definition of how two end treatments from two different pipes can connect together. Pipe connections let you control the types of connections possible between pipe entities, making it faster for modelers to connect pipe and modify connected pipes with fewer errors.

A pipe connection consists of the following information:

- The type of end treatment for each connecting pipe
- Whether there is a gap or overlap between connecting pipes
- The display properties of the connection (how it appears in drawings)



A connection can also have any number of accessory packages associated with it. See [Accessory Packages](#) (page 37) for details.

Create a Connection Type

Start by creating the connection types that will define your connections.

To create a connection type

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Click the Connections tab.
4. Click New Type.

If you do not see the New Type button, click the down arrow beside the New Connection button and select New Type.

Tip: You can also create a new connection type by double-clicking * <New Type> in the list of connections.

5. Enter a name for the connection type and press Enter.
6. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Create a Connection

To create a connection

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Connections tab.
4. Select the type of connection you want to create or select a connection of the type you want to create.
5. Click New Connection.

If you do not see the New Connection button, click the down arrow beside the New Type button and select New Connection.

Tip: You can also create a new connection by double-clicking * <New Connection> in the list of connections.

6. Set the connection properties:
 - End Treatment 1, End Treatment 2 – The two end treatments required to make the connection.
 - Gap – The distance between the ends of the two pipes or fittings. A positive value indicates a gap; a negative value indicates an overlap. For example, a butt weld connection might require a gap of 0.125" for welding, a flanged connection might require a gap of 0.25" to accommodate a gasket 0.25" in thickness, and a slip-on flange needs to slide over the plain end of a pipe by -1.25".
 - Angular Tolerance – The maximum allowable angle between the axes of the two pipes or fittings.
7. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Create a 'New Next Size' Connection

To create a 'New Next Size' connection

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Connections tab.
4. Select the connection you want to use as the base for the new connection.
5. Click New Next Size and a new connection with the next available end treatment sizes is created. The size difference between the end treatments, as well as the specific end treatment types, are maintained.
6. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Edit a Connection

To edit a connection

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Connections tab.
4. Select the connection you want to edit.
5. Change the desired values of the connection.

Note: changing End Treatment 1 in a connection will automatically change End Treatment 2 to match the new value of End Treatment 1.

6. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Delete a Connection or Connection Type

To delete a connection or connection type

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Select the Connections tab.
4. Select the connection or connection type you want to delete.
5. Click Delete.
6. Click Apply Changes to save the changes or Done to save the changes and close the Pipe Stock Catalog.

Add an Accessory Package To a Connection

A connection can have any number of associated accessory packages. When modeling pipe and inserting a connection, ShipConstructor prompts you to select an accessory package from a list of possible accessory packages for that connection. For information on creating and editing accessory packages, see [Accessory Packages](#) (page 37).

To add an accessory package to a connection

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Click the Connections tab.
4. Select the connection you want.
5. Click Add to open the Select Accessory Packages window.
6. Check the check box for the accessory packages you want to add to the connection.
7. Click OK to close the Select Accessory Packages window.

The accessory packages are listed under Connection Accessories.

Note: You can add the same accessory package to a connection more than once, as long as each accessory package belongs to a different spec.

Remove an Accessory Package From a Connection

Note: You cannot remove an accessory package from a connection that is in use. If you try, a warning message and a report listing the drawings and pipe entities using the connection appear. Before you can remove the accessory package from the connection, you must first break the connection between the pipe entities. See [Disconnect Pipes](#) (page 124).

To remove an accessory package from a connection

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Click the Connections tab.
4. Select the desired connection.
5. Under Connection Accessories, select the accessory package you want to remove.
6. Click Remove.

Import Connections

To import connections

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Click the Connections tab.
4. Click Import to open a File Browser.
5. Select a project file (*.PRO) or XML file (*.XML).
6. Click Open.

Note: When importing connections, you can optionally import their accessory packages and the package's related specs. When you choose this option, the accessory package is automatically reassigned to the related spec in the destination database.

Export Connections

To export connections

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Stock Catalog to open the Pipe Stock Catalog.
3. Click the Connections tab.
4. Check the Export check boxes for the connections you want to export.
5. Click Export XML to open a File Browser.
6. Enter a name for the XML file.
7. Click Save.

Auto-Part Insertion Setup

To use the [Auto Part Insertion Mode](#) (page 102) (AP mode) tools to their full potential, several important considerations need to be made when setting up a projects catalog. The stocks and allowable connections need to be very well defined with no unnecessary allowable connections.

Stock Setup

When setting up stocks for the AP the main thing to consider is to keep ambiguities to a minimum. Ideally, there should be only one connector or reducer with a given pair of end treatments. Having more than one with a given pair leads to multiple solutions when the system is attempting to decide which parts to add to the model to facilitate connections. Also adding unneeded allowable end treatment types to generic pipes could potentially limit the AP's usefulness.

Allowable Connection Setup

The most important part of catalog setup is the allowable connections. These should be kept to a minimum and be tightly constrained. For each end treatment, keep the number of allowable connections to a minimum to prevent multiple solutions. Every extra allowable connection using an end treatment adds another branch to possible solutions.


Pipe Bending Machines

You must create pipe bending machines to use for your project and give them capabilities. This is done in Manager. Creating and defining a pipe bending machine constrains what bending can be done for your projects. All limitations you want to impose are created here.

Create a Pipe Bending Machine

To create a pipe bending machine


1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.



3. Click New to open the Bending Machine window.
4. Enter a Name and Description for the pipe bending machine and set the Type and Units (the units you will use later to specify values for this pipe bending machine). See [Pipe > Pipe Benders](#) (page 217) for details.
5. Click OK to close the Bending Machine window.

Edit a Pipe Bending Machine

To edit a pipe bending machine

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.
3. Select the pipe bending machine you want to edit.
4. Click the  button to the right of the pipe bending machine name to open the Pipe Bending Machine window.
5. Edit the settings.
6. Click OK to close the Pipe Bending Machine window.

Delete a Pipe Bending Machine

You can remove a pipe bending machine from the list of options in the Pipe Bending Machines window.

To delete a pipe bending machine

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.
3. Select the pipe bending machine you want to delete.
4. Click Delete.


Add a Size Definition to a Pipe Bending Machine's Bender Information

To add a size definition to a pipe bending machine's bending information

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.
3. Select the pipe bending machine from the Pipe Bending/Cutting Machines list.
4. Select a size definition from the Size Definitions list.

Click Add under Bender Information.

The Bender Size Definition Settings window appears.



5. Set the values for the size definition.
You can specify the Centerline Radius as a multiple of the nominal size (Size Multiplier) or as a fixed value (Fixed Radius).
6. Click OK to close the Bender Size Definition Settings window.
The size definition settings appear under Pipe Bender Schedule Settings.

Edit Pipe Bending Machine's Bender Information Size Definition Settings

To edit a pipe bending machine's bender information size definition settings

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.
3. Select the pipe bending machine from the Pipe Bending/Cutting Machines list.
4. Select the size definition setting you want to edit under Bender Information.
5. Click Edit to open the Bender Size Definition Settings window.
6. Set the new values.
7. Click OK to close the Bender Size Definition Settings window.

Remove a Size Definition Setting From a Pipe Bending Machine's Bender Information

To remove a size definition from a pipe bending machine's cutting information

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.

3. Select the pipe bending machine you want from the Pipe Bending Machines list.
4. Select the size definition setting you want to remove under Pipe Bender Schedule Settings.
5. Click Remove.

Add a Size Definition to a Pipe Bending Machine's Cutting Information

To add a size definition to a pipe bending machine's cutting information

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.
3. Select the pipe bending machine you want from the Pipe Bending/Cutting Machines list.
4. Select a size definition you want to add from the Size Definitions list.
5. Click Add under Cutting Information.
6. Set the Kerf value.
7. Click OK to save your changes and close the Pipe Bending/Cutting Machines window.

Edit Pipe Bending Machine's Cutting Information Size Definition Settings

To edit a pipe bending machine's cutting information size definition settings

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.
3. Select the pipe bending machine you want from the Pipe Bending/Cutting Machines list.
4. Select the cutting information entry you want to change from the Cutting Information list.
5. Change the Cutting Information values as desired.
6. Click OK to save your changes and close the Pipe Bending/Cutting Machines window.

Remove a Size Definition Setting From a Pipe Bending Machine's Cutting Information

To remove a pipe bending machine's cutting information size definition setting.

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.
3. Select the pipe bending machine from the Pipe Bending/Cutting Machines list.
4. Select the cutting information entry you want to remove.
5. Click Remove under Cutting Information.
6. Click OK to save your changes and close the Pipe Bending/Cutting Machines window.

Delete a Pipe Bending Machine

To delete a pipe bending machine

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.
3. Select the pipe bending machine from the Pipe Bending/Cutting Machines list.
4. Click Delete.

Import Pipe Bending Machines

You can import pipe bending machines from another project or from an XML file exported from another project.

To import pipe bending machines

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.
3. Click Import to open a File Browser.
4. Select a project file (*.PRO) or XML file (*.XML).
5. Click Open.

Export Pipe Bending Machines

You can export pipe bending machines to an XML file (for example, to import into another project or to edit using other software).

To export pipe bending machines

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Pipe Benders to open the Pipe Bending/Cutting Machines window.
3. Check the Export check boxes for the pipe bending machines you want to export.
4. Click Export XML to open a File Browser.
5. Enter a name for the XML file.
6. Click Save.

User-Defined Attributes

See User-Defined Attributes in the Structure manual.

Excel Pipe Library Editor ("Flatsheet")

Overview

Some users find it easiest to edit their pipe stock catalogs in Excel. To facilitate this, we provide an Excel document that will import and export XML files compatible with ShipConstructor's Manager.

Excel is quite powerful and allows the user to define the stocks using formulae.



Getting Started

To import a pipe stock library, select the Help tab and click on the Import XML File button. Then select the desired file. This file should have been created by ShipConstructor or the Excel sheet. Importing will overwrite the contents of the workbook. To get a feel for how this works, try loading one of the Pipe Catalogs that are installed with ShipConstructor. They are located in C:\Program Files\ShipConstructor2009\ProjectTemplates\

To save the pipe stock library to XML, select the Help tab and click on the Export XML File button. Then select the desired location and file name. The resulting file can then be imported into ShipConstructor in Manager.

The Help Tab

The Import XML File button loads a dialog which allows you to select an XML file to load. Importing will overwrite the contents of the workbook.

The Export XML File button launches a dialog which allows you to select a location and name for the exported file. That file can then be imported into ShipConstructor using Manager.

When the Verify XML checkbox is enabled the validity of the XML files will be verified. This is generally recommended however for very large files it can take a prohibitive amount of time.

The Clear All Worksheets button will clear the data from the workbook. It launches a verification dialog. In this dialog a checkbox allows you to clear hidden tabs (see below for details on hidden tabs).

The Revive Workbook button is sometimes necessary if an error occurs while importing or exporting. The most common symptom is that the generated and derived columns will cease updating. If this happens, click on the Revive Workbook button and normal behavior should resume.

There is an option to hide the units in Size Definition names. ShipConstructor displays the units, so we default this to No. If you choose to change this to yes, it will not update the names currently in the workbook. Due to this, you should export any data you have, make the change, and then import it afterward.

The rest of the Help tab explains some of the basics necessary to use the Excel Pipe Library Editor.

General Information

Column Headers

Underlined columns are required fields. These cannot be left blank.

If the headers in a group are grey, then the whole group is optional. Required fields within the group cannot be blank if any entry in the group is non-blank.

Read-Only Columns

Columns that are generated will have an italicized header.

Columns with grey backgrounds are lookups to other worksheets. Usually the column to their left will reference another worksheet, and these lookup columns will show relevant information from the referenced column.

Columns with blue backgrounds are generated names. These are usually used to identify the entry on another worksheet (eg. Referencing a Geometric Standard when making a Size Definition). These cannot be moved from the first column.

Attempting to modify a read-only item should have no effect. If it does change the entry, then the workbook is in a bad state. To fix this, select the Help tab and click on the Revive Workbook button.

Hidden Tabs

By default the End Treatment Type and Connection Display tabs are hidden. They can be edited by right-clicking on any of the tabs and selecting Unhide... Likewise any tab can be hidden using Hide. When Clearing All Worksheets hidden tabs will not be cleared by default.

User Defined Attributes

Columns can be added under the User Defined heading to create new User Defined Attributes.

Make sure that the User Defined cell stretches across all of the columns to be used. Inserting a column when selecting the last User Defined column should produce the correct results.

Pipe Hanger Stocks


A pipe hanger stock is made up of several key parts; a hanger type that defines the geometric makeup of the stock, several geometric properties which define how the model of a given stock will look, a list of nominal sizes that the hanger is valid for, a list of material types that the hanger is valid for, and a list of allowable accessory packages that can be used with the hanger stock. The geometric properties required from the user will define the major pieces of the hanger stock, the goal being to ensure bolts, bolt holes, etc. are placed properly in the model, some less critical geometry is determined by ShipConstructor based on the nominal size of the pipe connected to the hanger and the geometric properties defined for the hanger stock. The allowable nominal size and allowable material lists define what types of pipes are allowed to attach to a given hanger stock. Hanger stocks can belong to hanger stock catalogs and the stocks can also have user defined attributes associated with them.

Supported Hanger Types

ShipConstructor supports several different hanger types, these types and the geometric properties required to define them are listed below. There is also a set of properties common to all hanger types:


- Name
- Description
- Weight
- Manufacturer
- Allowable Accessory Packages
- Nominal Size(s) that the hanger is applicable for.
- Material(s) that the hanger is applicable for.

U-Bolt




- A – Rod Thickness
- B – Edge to Pipe Center
- C – Overall Width (rod center to rod center)

Pipe Strap



- H – Hole Diameter
- G – Edge to Bolt Center
- C – Overall Width
- W – Stock Width
- T – Stock Thickness

Range with Elastic Insert



C – Overall Width


D – Overall Height

E – Overall Depth

I – Bolt Center to Bolt Center

H – Hole Diameter

Pipe Clamp



H – Hole Diameter

B – Edge to Pipe Center


F – Center of Pipe to Center of Bolts

J – Distance between Clamps

W – Stock Width

T – Stock Thickness

Offset Pipe Clamp



I – Bolt Center to Bolt Center

B – Edge to Pipe Center


G – Edge to Bolt Center

H – Hole Diameter

T – Stock Thickness

W – Stock Width

Split Ring Extension




A – Rod Diameter

W – Split Ring Width


T – Split Ring Thickness

Hinged Extension Split Pipe Clamp




A – Rod Thickness
T – Stock Thickness
W – Stock Width

Adjustable Swivel Ring




- A – Rod Thickness
- B – Edge to Pipe Center
- K – Center of Pipe to End of Rod
- T – Stock Thickness
- W – Stock Width

Adjustable J-Hanger




- A – Rod Thickness
- B – Edge to Pipe Center
- K – Center of Pipe to End of Rod
- T – Stock Thickness
- W – Stock Width

Adjustable Clevis Hanger




- A – Rod Thickness
- B – Edge to Pipe Center
- K – Center of Pipe to End of Rod
- T – Stock Thickness
- W – Stock Width

Flat Top Clevis Hanger



- A – Rod Thickness
- B – Edge to Pipe Center
- K – Center of Pipe to End of Rod
- T – Stock Thickness
- W – Stock Width

Vee-Bottom Clevis Hanger



A – Rod Thickness


B – Edge to Pipe Center

K – Center of Pipe to End of Rod

T – Stock Thickness

W – Stock Width

J-Hook



D – Overall Height


F – Center of Pipe to Center of Bolts

H – Hole Diameter

T – Stock Thickness

W – Stock Width

Adjustable Roller Hanger



A – Rod Thickness

C – Overall Width


D – Overall Height

K – Center of Pipe to End of Rod

T – Stock Thickness


W – Stock Width

Trapeze Roller Hanger



- A – Rod Thickness
- B – Edge to Pipe Center
- C – Overall Width
- D – Overall Height
- I – Bolt Center to Bolt Center

Roller Chair



B – Edge to Pipe Center

C – Overall Width

D – Overall Height


I – Bolt Center to Bolt Center

H – Hole Diameter

T – Stock Thickness

W – Stock Width

Adjustable Roller Stand with Base



B – Edge to Pipe Center

C – Overall Width

E – Overall Depth


I – Bolt Center to Bolt Center

H – Hole Diameter

Create a Hanger Stock

To create a Hanger Stock

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Hanger Stock Catalog to open the Hanger Stock Catalog.



3. Select the type of hanger stock you want to create or select an existing hanger stock of the type you want to create.
4. Click New.
5. Enter a name for the hanger stock and press Enter.
6. Set the hanger stock properties required.
7. Click Apply to save changes, or OK to save changes and close the Hanger Stock Catalog.

Edit a Hanger Stock

To edit a Hanger Stock

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Hanger Stock Catalog to open the Hanger Stock Catalog.
3. Select the hanger stock you want to change and edit the desired values in the Hanger Stocks grid.
4. Click Apply to save changed or OK to save changes and close the Hanger Stock Catalog.

Delete a Hanger Stock

To delete a Hanger Stock


1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Hanger Stock Catalog to open the Hanger Stock Catalog.
3. Select the hanger stock you want to delete and click Delete.
4. Click Apply to save changes or OK to save changes and close the Hanger Stock Catalog.

Assign Allowable Nominal Sizes to a Hanger Stock

To assign allowable Nominal Sizes to a Hanger Stock

1. Choose ShipConstructor > Manager to open Manager.

2. Choose Piping > Hanger Stock Catalog to open the Hanger Stock Catalog.
3. Select the hanger stock you want to assign the allowable nominal sizes to.
4. Click Allowable Nominal Sizes to open the Allowable Nominal Sizes dialog.




5. Check the Selected check box for the nominal sizes you want to associate with the selected hanger stock.
6. Click OK to return to the Hanger Stock Catalog.
7. Click Apply to save changes or OK to save changes and close the Hanger Stock Catalog.

Assign Allowable Material Grades to a Hanger Stock

To assign allowable Material Grades to a Hanger Stock

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Hanger Stock Catalog to open the Hanger Stock Catalog.
3. Select the hanger stock you want to assign the allowable material grades to.
4. Click Allowable Material Grades to open the Allowable Material Grades dialog.



5. Check the Selected check box for the material grades you want to associate with the selected hanger stock.
6. Click OK to return to the Hanger Stock Catalog.
7. Click Apply to save changes or OK to save changes and close the Hanger Stock Catalog.

Edit Hanger Stock Catalogs

To edit Hanger Stock Catalogs

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Hanger Stock Catalog to open the Hanger Stock Catalog.
3. Click Edit Catalogs to open the Hanger Catalogs dialog.
4. Click New to create a new hanger catalog, click Delete to delete the selected hanger catalog, to edit the name of an existing hanger catalog simply edit it in the Catalogs grid.
5. Click OK to return to the Hanger Stock Catalog.
6. Click Apply to save changes or OK to save changes and close the Hanger Stock Catalog.

Assign Hanger Stocks to a Hanger Stock Catalog

To assign Hanger Stocks to a Hanger Stock Catalog

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Hanger Stock Catalog to open the Hanger Stock Catalog.
3. Select the hanger stock you want to assign the hanger stock catalogs to.
4. Click Assign To Catalogs to open the Assign Hanger Catalogs dialog.

5. Check the Selected check box for the hanger catalogs you want to associate with the selected hanger stock.
6. Click OK to return to the Hanger Stock Catalog.
7. Click Apply to save changed or OK to save changes and close the Hanger Stock Catalog.

Support Templates

A support template is made up of several key parts; a support type which defines the geometric makeup of the support, several geometric properties which define how the model of the template will look, and a list of supported hanger stocks.

The geometric properties required from the user will define the shape and size of the support, the goal being to ensure the correct structural stocks are used, the number of tiers is correct, and the maximum and minimum constraints of the support are met. The support hanger stocks will define what sizes and types of pipes will be allowed to connect to the support.


Support Template Types

ShipConstructor supports several different support types, these types the geometric properties required to define them are listed below. There is also a set of properties common to all support types.

- Name
- Min Overall Height
- Max Overall Height
- Min Distance To First Hanger
- Min Distance Between Hangers
- Max Distance Between Hangers
- Min Distance From Last Hanger
- Vertical Extrusion Stock
- Vertical Base End Extrusion Stock Endcut Standard
- Vertical Open End Extrusion Stock Endcut Standard
- Vertical Base Plate Stock
- Vertical Base Plate Type
- Vertical Base Plate Length
- Vertical Base Plate Width
- Vertical Base Plate Radius.
- Maximum Number of Hangers


I Type

The I Types can only have 1 vertical tier and no horizontal tiers.



LF Type


The LF Type can only have 1 vertical tier and 1 or more horizontal tiers.



- Cross Tier Extrusion Stock
- Cross Tier Start Extrusion Stock Endcut Standard
- Cross Tier End Extrusion Stock Endcut Standard
- Extrusion Direction Opposite
- Min Overall Width
- Max Overall Width

T Type


The T Type can only have 1 vertical tier and 1 or more horizontal tiers. The vertical tier will initially be in the center of the horizontal tiers.



- Cross Tier Extrusion Stock
- Cross Tier Start Extrusion Stock Endcut Standard
- Cross Tier End Extrusion Stock Endcut Standard
- Min Overall Width
- Max Overall Width

Two by N Type


The Two by N Type will have 2 vertical tiers and 1 or more horizontal tiers.



- Cross Tier Extrusion Stock
- Cross Tier Start Extrusion Stock Endcut Standard
- Cross Tier End Extrusion Stock Endcut Standard
- Extrusion Direction Opposite
- Min Overall Width
- Max Overall Width
- Angle

M by N Type

The M by N Type will have 2 or more vertical tiers and 1 or more horizontal tiers.




- Cross Tier Extrusion Stock
- Cross Tier Start Extrusion Stock Endcut Standard
- Cross Tier End Extrusion Stock Endcut Standard
- Extrusion Direction Opposite
- Min Overall Width
- Max Overall Width
- Angle

Create a Support Template

To create a Support Template

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Support Template Catalog to open the Support Template Catalog.




3. Select the type of support you would like to create or select an existing support template of the type you would like to create.
4. Click New Support.
5. Enter a name for the support template and press Enter.
6. Set the support template properties required.
7. Click Apply to save the changes, or click OK to save the changes and close the Support Template Catalog.

Edit Support Template Tiers

To edit Support Template Tiers

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Support Template Catalog to open the Support Template Catalog.
3. Select the support template that you would like to edit tiers.
4. Click Edit Tiers and select whether to edit horizontal tiers or edit vertical tiers to display the Tier Editor window.



5. Click Add to add another tier to the support template or click Remove to remove a tier from the support template.
6. Click OK to return to the Support Template Catalog.
7. Click Apply to save changes or click OK to save changes and close the Support Template Catalog

Edit a Support Template

To edit a Support Template

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Support Template Catalog to open the Support Template Catalog.
3. Select the support template that you want to change and edit the desired values in the Support Template grid.
4. Click Apply to save changes or click OK to save changes and close the Support Template Catalog.

Delete a Support Template


To delete a Support Template

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Support Template Catalog to open the Support Template Catalog.
3. Select the support template you would like to delete and click Delete Support.
4. Click Apply to save changes or click OK to save changes and close the Support Template Catalog.

Assign Allowable Hangers to a Support Template

To assign Allowable Hangers to a Support Template

1. Choose ShipConstructor > Manager to open Manager.
2. Choose Piping > Support Template Catalog to open the Support Template Catalog.
3. Select the support template you would like to assign allowable hangers to.
4. Click Allowable Hangers to open the Allowable Hanger Stocks window.



5. Click the Allowed check box for the hanger stocks you would like to be available for this support type.

Note: Only pipe strap and UBolt hanger types can be attached to a support.

6. Click OK to return to the Support Template Catalog.
7. Click Apply to save changes or click OK to save changes and close the Support Template Catalog.

Pipe Modeling

All pipe modeling is done within system model drawings.

Pipe Drawings

You model pipe within pipe drawings. Because shipyards have different policies for organizing their projects, ShipConstructor does not have any constraints on pipe drawings. You can use either one drawing per system in a unit or multiple systems or branches in a drawing. You can also add equipment and model pipe in the same drawing.

For more information on drawings, see Drawings in the Structure manual.

Create a Pipe Drawing

To create a pipe drawing

1. Choose ShipConstructor > Navigator to open Navigator.

Note: To create a drawing for a unit other than the current unit, select the project at the top of the component list (for example, SC2009Demo) and then select the unit in the Unit list.

2. Select Pipe in the component list.
3. Select the Piping folder in the drawing list.
4. Click New Piping.

The New Drawing window appears.


5. Enter a File name for the drawing.

Note: To open the new drawing, check the Open new drawing check box.

6. Click OK.

Upon Opening a Pipe Drawing

When opening a Pipe drawing, if connected to the database, a synchronization occurs between the drawing and the database. If there are parts that are not in the database but are in the drawing, a window will appear asking if you would like to explode these parts.



If 'Yes' is clicked, the selected objects will be exploded. If 'No' is clicked, the selected objects will be erased.

Set Up Pipe Systems


A pipe system is a collection of pipe parts that together fulfill a specific purpose (for example, the bilge system, the ballast system, or the fire main system). Each system is composed of one or more sections or branches. Before you can begin modeling pipe, you must set up systems and branches.


Each system or branch is part of a specification (spec). You must set up at least one spec before you can create a system or branch. To set up a spec, see [Create A Spec](#) (page 16).


Create a System


To create a system

1. Choose [SC Pipe > System > System Manager](#) (page 237) to open the System Manager. See [System Manager](#) (page 254) for details.



2. Under Pipe System, select the spec, , that you want the new system to belong to. When you choose a spec, the New button at the bottom of the window is the New System button.
3. Click New System.
4. Enter a name for the new system and press Enter.
5. Set the system properties:

Finish – The finishes applied to pipes in the system. Click  to open the Finishes window and use the left and right arrow buttons to select finishes from the list of Available Finishes. The order of Selected Finishes is the order that the finishes will be applied to the pipe.

Insulation – The insulation applied to pipes in the system. Click  to open the Insulation window and use the left and right arrow buttons to select insulation from the list of Available Insulation. The order of Selected Insulation is the order that the insulation will be applied to the pipe.

Color – The color that ShipConstructor will display pipes in the system as.

Class – The class that pipes in the current system will be associated with.

Test Method – Enter a string field here based on what method you will use for testing.


Test Pressure – Enter a specific value in either pounds per square inch (psi) or kilopascals (kPa), depending on if you are in an imperial or metric project.

Density – The density of the pipe affects its wet weight (relative density multiplied by the weight of water). The density is entered based on each application and is entered on a branch or system level.

6. Click OK to close the System Manager.

Create a Branch



To create a branch

1. Choose [SC Pipe > System > System Manager](#) (page 237) to open the System Manager. See [System Manager](#) (page 254) for details.
2. Under Pipe System, select the system, , that you want the new branch to belong to. When you select a system, the New button at the bottom of the window becomes the New Branch button.
3. Click New Branch.
4. Enter a name for the new branch and press Enter. The name must be unique if the Pipe Unique Branch Name is set to 'yes' in Project Settings.
5. Set the branch properties (see [Create a System](#) (page 82)).
6. Click OK to close the System Manager.

Modify a System or Branch

You can modify a system or branch by modifying the properties of the system or branch, converting a branch to a system or a system to a branch, and re-assigning or deleting a system or branch.



To modify the properties of a system or branch

1. Choose [SC Pipe > System > System Manager](#) (page 237) to open the System Manager. See [System Manager](#) (page 254) for details.
2. Under Pipe System, select the system  or branch  you want to modify.
3. Modify the system or branch properties.
See [Create a System](#) (page 82) for details on property fields.
4. Click OK to close the System Manager.

Delete a System or Branch


To delete a system or branch

Note: You cannot delete a system or branch if pipes have been assigned to that system or branch.

1. Choose [SC Pipe > System > System Manager](#) (page 237) to open the System Manager. See [System Manager](#) (page 254) for details.
2. Select the system  or branch  you want to delete.
3. Click Delete.
4. Click OK to close the System Manager.

Set the Current System for Pipes


To set the current system for pipes

1. Choose [SC Pipe > System > System Manager](#) (page 237) to open the System Manager. See [System Manager](#) (page 254) for details.
 2. Select the branch, .
 3. Click OK to close the System Manager.
- OR-
1. Choose SC Pipe > Systems > Set System From Pipe Part.

2. Select an Pipe part from the current drawing.
 3. The current system is now set to be the same as the system of the part selected in step 2.
- OR-
1. Start routing a new Pipe part.
 2. Place first end connected to an existing Pipe part that is in a different system.
 3. You will be prompted to change the current system to that of the part you are connecting to.
 4. Click Yes.

Change the System for Pipes

To change the system for pipes


1. Choose [SC Pipe > System > Set System](#) (page 237) to open the System Manager. See [System Manager](#) (page 254) for details.
2. Select the branch, .
3. Click OK to close the System Manager.
4. A log file will be produced if any of the selected pipes cannot be set to the selected system. The log file will display which pipes cannot have their system changed and why they cannot change systems.

Set Up Pipe Defaults, Display, and Performance

Display Options for Pipe

To change the display options

1. Choose SC Pipe > Pipe Options to open the Pipe Drawing Options window.
2. Click the Display tab.




3. Set the display options. See [The Display Tab](#) (page 255) for a description of each option.
4. Click OK to close the Pipe Drawing Options window.

Change the NavAid Options

When you are placing pipes that require directional input, a visual aid called the NavAid appears, helping you to orient the component. You can adjust the size and snap behavior of the NavAid.

To change the NavAid options

1. Choose SC Pipe > Pipe Options to open the Pipe Drawing Options window.
2. Click the NavAid tab.




3. Set the options. See [The NavAid Tab](#) (page 261) for details.
4. Click OK to save the changes and close the Pipe Options window.

Set the Transform Options

The transform options are the display options that are particularly relevant when transforming parts (moving, stretching, etc.).

To set the transform options

1. Choose SC Pipe > Pipe Options to open the Pipe Drawing Options window.
2. Click the Transform tab.




3. Set the options. See [The Transform Tab](#) (page 262) for details.
4. Click OK to save your changes and close the Pipe Drawing Options window.

Set the Routing Options

The routing options allow you to control the visibility, color, and size of the flow direction arrow.

To set the routing options

1. Choose SC Pipe > Pipe Options to open the Pipe Drawing Options window.
2. Click the Routing tab.




3. Set the options. See [The Routing Tab](#) (page 264) for details.
4. Click OK to save your changes and close the Pipe Drawing Options window.

Set the Behavior Options

The behavior options let you set up how the stock lengths are enforced.

To set the behavior options

1. Choose [SC Pipe > Pipe Options](#) (page 244) to open the Pipe Drawing Options window.
2. Click the Behavior tab.




3. Set the options. See [The Behavior Tab](#) (page 265) for details.
4. Click OK to save your changes and close the Pipe Drawing Options window.

Set the Constraints Options

The constraints options let you set up how ShipConstructor handles bent pipes when bender information is present.

To set the constraints options

1. Choose [SC Pipe > Pipe Options](#) (page 244) to open the Pipe Drawing Options window.
2. Click the Constraints tab.



3. Set the options. See [The Constraints Tab](#) (page 266) for details.
4. Click OK to save your changes and close the Pipe Drawing Options window.

Insert Pipes

You create a pipe model by inserting pipes into a pipe drawing.


Routing a pipe usually involves selecting a stock and providing geometric information that determines where the pipe is located and how it is oriented. You input geometric information through a combination of clicking points in the model and using command line options.


Selecting a Pipe Part to Insert

Before laying down any pipe, you must first select which pipe to use. By clicking on the type of part you want, the Select Stock window will appear letting you select a stock of that type from the stocks you made in the [Pipe Stock](#) (page 19) Catalog for the current spec if there are any specs that meet these criteria. If there are not, you will be notified to assign stocks of this type to the spec.

To select a stock to insert

1. From the SC Pipe menu or the Pipe toolbar, choose the type of stock you would like to place in the drawing. The Stock Selection window will appear if there are any stocks of this type assigned to this spec. See [Stock Selection Window Reference](#) (page 266) for more information.

Note: If there are no stocks shown, clear all the filters by selecting the Clear Filter button , and make sure that there are stocks of the type selected created and assigned to the spec where the current system is.




2. Select a stock and click OK.

The NavAid

The NavAid is a tool intended to help you with several aspects of pipe routing. It can be helpful for three things:


- Visualizing the current UCS
- Modifying the current UCS in a way convenient for routing pipes
- Snapping input points to fixed angles

When visible, the NavAid is located at the current UCS origin, aligned to the UCS XY plane. The angle displayed by the NavAid is the polar angle of the current input point. The center of the NavAid is indicated by a small cross, with the longer axis in the X direction (0° angle).




Required Custom Attributes

After routing the pipe, if there are any required custom attributes or catalogs are assigned to the stock used, the catalog and custom attributes for this part must be set. ShipConstructor will attempt to do this automatically. If it cannot be done automatically the dialog below will be show. See [Required Custom Attributes Reference](#) (page 267).




No Spool Parts

If you are inserting a no spool part (Valve) and you have the Use Default Assembly project setting set to no, then you must select the assembly in which belongs. After selecting the hierarchy from the tree and pressing OK, you can then continue on to placing the part.



Straight Pipe

To route a straight pipe, you will select a stock and then provide two points indicating the start and end point of the pipe.



To insert a straight pipe

1. Choose SC Pipe > Straight.

A straight pipe appears with the first end at the cursor. Information about the pipe is shown on the command line.

2. You are prompted to pick the start point of the pipe or choose an option:

```
Please pick point : or [Stock/Next end <l>/XOffset/YOffset/Choose offset <0,0>
/Rotate/sAddle/Insulation]:
```

If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):

- Next end – Switches which end of the pipe will be placed at the picked point.
 - Rotate – Rotates the pipe around its own centerline (the NavAid is not affected).
3. Click anywhere in the model to select the start point of the pipe. You can connect to an existing unconnected pipe end by clicking on its end point, indicated by an arrow (see [Creating Connections While Routing In End Mode](#) (page 104)). The NavAid appears at the selected point and the end point of the pipe you are placing is anchored there.
 4. You are prompted to pick the second point or choose an option:

```
Please pick point : or [Forward/Aft/Port/Starboard/Up/Down/plaNE/XRotate/YRotate/ZRotate/
SNap<on>]:
```

See [General Options](#) (page 103) for explanation of the available options.


Note: If you created a connection to another pipe by clicking on a free end or by creating a saddle, several of the options shown above do not apply (for example, the direction options) and are not available.

5. Click anywhere in the model to select the end point of the pipe. If you connected the pipe in step 3, any point you pick (including OSNAPs) is projected onto the axis of the end you connected to.


Bent Pipe

To insert a bent pipe by picking points

To route a bent pipe with this method, you will select a sequence of points that form the path to which the segments of the bent pipe will be aligned.



1. Choose SC Pipe > Bent.
The first segment of a bent pipe appears with the first end at the cursor. If there is only a single bender associated with the bent pipe, skip to Step 3. Information about the pipe is shown on the command line.
2. If the size definition of the bent pipe you are creating has a single set of pipe bender values associated with it, the bender values will automatically be applied to the bent pipe as you place it. If there is more than one set of bender values associated with its size definition, you must select a pipe bender or a bend radius. The Select bend values window appears and you are prompted to select which bender values to use. Your bent pipe will be restricted by the properties of that bender. If there is no bender data associated with the size definition, you will be prompted to enter a Bend Radius. This value will be used to restrict the bent pipe as you route it.



Note: Information about the bend values can be seen in the OPM after the part has been placed.

3. You are prompted to pick the start point of the bent pipe or choose an option:

Please pick point : or [Stock/Next end <1>/XOffset/YOffset/Choose offset <0,0>/Toggle mitered <rounded>/Rotate/sAddle/Insulation]:

If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):

- Next end – Switches which end of the bent pipe will be placed at the picked point.
- Toggle mitered – Switch between rounded corners and mitered corners. The current setting is shown in <angle brackets>. If you switch to mitered corners, you must specify the number of miter segments per corner.
- Rotate – Rotates the pipe around its own centerline (the NavAid is not affected).

4. Click anywhere in the model to select the start point of the pipe.

You may also connect to an existing unconnected pipe end by clicking on its end point, indicated by an arrow (see [Creating Connections While Routing In End Mode](#) (page 104)). The NavAid appears at the selected point and the end point of the pipe you are placing is anchored there.

If you click on a snap point of an existing AutoCAD polyline, you are given the option to automatically route the pipe along the path of that polyline. If you choose No, continue from Step 5. If you choose Yes, the bent pipe is routed along the polyline (if for any reason the pipe cannot be routed exactly along the polyline, an explanation will be printed to the AutoCAD console). The end of the pipe that you are routing by is placed at the end of the polyline closest to the snap point you selected. If the pipe is successfully routed, you are done routing the pipe, and are given the option to delete the polyline.

5. You are prompted to pick the second point or choose an option:

Please pick point : or [Forward/Aft/Port/Starboard/Up/Down/plaNE/XRotate/YRotate/ZRotate/SNap<on>]:

See [General Options](#) (page 103) for explanation of the available options.

Note: If you created a connection to another pipe by clicking on a free end or by creating a saddle connection, several of the options shown above do not apply (for example, the direction options) and will not be available.

6. Click anywhere in the model to select the second point of the pipe. If you connected the pipe in step 4, any point you pick (including OSNAPS) is projected onto the axis of the end you connected to.

To choose a point along the axis of an existing end, click the existing end. Your next input point will be restricted to the axis.

The NavAid appears at the selected point and the first pipe bend appears.

7. To create a bend in the pipe, repeat Steps 5 and 6 for the bend points. Note that the command prompt has extra options for further points :

Please pick point : or [XOffset/YOffset/Choose offset <0,0>/Radius<200>/World plane/Initial plane/paRT plane/Align to part/Forward/Aft/Port/Starboard/Up/Down/plaNE/XRotate/YRotate/ZRotate/ SNaP<on>]:

If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):

- Radius – Changes the corner radius of the bend being manipulated. The current radius is shown in <angle brackets>.
- World plane – Aligns the NavAid to the world coordinates.
- Initial plane – Aligns the NavAid to the UCS that was active when the command started.
- Part plane – Aligns the NavAid to the plane of the most recently placed segment of bent.
- Align to part – Aligns the X-Axis of the NavAid (see [The NavAid](#) (page 91)) to the axis of the most recently placed segment of the bent.
- Unlock – If you clicked on an existing end in step 6 to restrict your picked point to the axis of that end, this option will remove the restriction.

To finish a bent pipe, press Enter.

To automatically route a bent pipe along a polyline

1. Choose [SC Pipe > Utilities > Route on Polyline](#) (page 239). You are prompted to select a polyline:

Please select a polyline to route the pipe on. The pipe will be routed from the end of the polyline closest to the selected point.


2. Select a polyline. If for any reason the pipe cannot be routed exactly along the polyline, an explanation will be printed to the AutoCAD console. You are asked if you would like to delete the polyline used to route along:

Delete source polyline? [Yes/No] <No> :

3. Enter a response. The pipe appears and routing is complete.

Generic Pipes

To apply one of the allowable ends to a generic pipe part, you must connect it. The allowable connections that can be used are the ones that match with the end treatments that are on the stock and those that are available to be applied to the stock. The following shows the Select Connection and Accessory Packages dialog when connecting two pipes of the stock that is shown in figure below. Whichever allowable connection is selected will apply the end treatment to the parts. For example, if the second allowable connection show below is chosen then the FL 1" – 150LB – FF end treatment will be applied to the two ends that are being connected. The ends of the pipe that are not being connected will not be affected.



Fittings

There are two means by which fittings can be placed. End Mode involves placing a fitting by specifying a location and orientation for one of its ends. Intersection Mode lets you place a fitting where two runs of pipe will meet.

End Mode

When placing a fitting in end mode, you initially only need to consider which end you are placing (or connecting to another pipe).

To insert a fitting in end mode

1. Choose the desired fitting you want to insert from the SC Pipe menu. The fitting appears at the cursor and information about it is shown on the command line.
2. You are prompted to pick the first point or choose an option from the end mode command line:

```
Please pick the first point of the end axis : or [Select stock/cOnnects To.../Next end
<l>/inTersection mode/XOffset/YOffset/Choose offset <0,0>/sAddle/Insulation]:
```


If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):

- Next end – Switches which end of the fitting will be placed at the picked point.
 - Intersection Mode – Switches the routing interface to intersection mode (see [Intersection Mode](#) (page 99)).
3. Click anywhere in the model to select the start point of the fitting. You can connect to an existing unconnected pipe end by clicking on its end point, indicated by an arrow (see [Creating Connections While Routing In End Mode](#) (page 104)). The NavAid appears at the selected point and the end point of the fitting you are placing is anchored there.
 4. If you connected the fitting to another pipe, continue from Step 6. Otherwise, you are prompted to pick a point indicating the direction of the end you just placed or choose an option:

```
Please pick the second point of the end axis : or [plane/XRotate/YRotate/ZRotate/SNap<on>]:
```

See [General Options](#) (page 103) for explanation of the available options.

5. Click anywhere in the model to specify the direction of the current end's axis (i.e. the end axis will be parallel to the line formed by this point and the point that you clicked in Step 3). The fitting is now restricted to rotation about this axis.



Specifying the location and normal of End 1.

6. You are prompted to pick a point indicating the direction of an orienting end of the fitting or to choose an option:


Please pick a point indicating a rotation about the defined end axis : or [Next end for orientation <1>/Forward/Aft/Port/Starboard/Up/Down/DEck align/FFrame align/Long align/Align to WCS/ZRotate/SNap<on>]:

Depending which end you placed in Step 3, not all ends will be available as an orienting end while cycling through ends with Next end for orientation. For example, if you placed a tee by one end of its trunk, the other end of the trunk is not useful to orient the tee with, but the branch is.

If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):

- Next end for orientation – Switches the end governing the orientation of the fitting.


7. Click anywhere in the model to specify the direction of the orienting end.




A cross that was placed by End 1 with points 1 and 2, and oriented with respect to End 3 with the 3rd input point.

Intersection mode

You will typically use intersection mode to place a fitting (or possibly multiple elbows) where two non-parallel pipe runs will meet (that is, where their centerlines will intersect).



If you are placing the fitting before the pipe runs on either side exist, you will directly specify the location of the intersection point and then set the orientation of the fitting.



Intersection point on a tee.

If one of the other pipe runs exists already, you will align one end of your fitting with that run and then specify how far from that existing run the fitting is placed. If both of the other runs exist already, you will align one end of your fitting to one pipe run and a second end of your fitting to the other run.

To insert a fitting in intersection mode when the connecting runs do not exist yet

1. Choose the desired fitting you want to insert from the SC Pipe menu. The fitting appears at the cursor and information about it is shown on the command line.
2. If end mode is active, switch to intersection mode (see step 2 of [End Mode](#) (page 97)); otherwise continue with Step 3.
3. You are prompted to pick the location of the intersection point or choose an option:

```
Please pick the first point of the end axis : or [Select stock/cConnects To.../Next end
<l>/neXt point <l>/End mode/Insulation]:
```

If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):

- Next end – Switches which end of the fitting will be aligned to the axis formed by the first two points you will choose in steps 4 and 6.
- Next point – Switches which intersection point of the fitting you want to place in step 4. You may not see this option if a fitting has only one intersection point (e.g. a non-offset elbow or basic tee).

- End mode – Switches the routing interface to end mode (see [End Mode](#) (page 97)).
4. Click anywhere in the model (except a free end) to specify a location for the current intersection point.
 5. You are prompted to pick a second point defining the axis to which the current end of the fitting will be aligned or to choose an option.

Please pick the second point of the end axis : or [orienting end <1>/plane/XRotate/YRotate/ZRotate/SNap<on>]:

If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):

- Orienting end – Switches which end of the fitting will be aligned to the axis formed by the point you picked in step 4 and the point you will pick in step 7.
6. Click anywhere in the model to specify the direction of the current end's axis (i.e. the end axis will be parallel to the line formed by this point and the point that you clicked in Step 3). The fitting is now restricted to rotation about this axis.
 7. You are prompted to pick a point indicating the direction of an orienting end of the fitting or to choose an option:

Please pick a point indicating a rotation about the defined end axis : or [Next end for orientation <1>/Forward/Aft/Port/Starboard/Up/Down/DEck align/FRame align/Long align/ALign to WCS/ZRotate/SNap<on>]:

Depending which end you placed in Step 3, not all ends will be available as an orienting end while cycling through ends with Next end for orientation. For example, if you placed a tee by one end of its trunk, the other end of the trunk is not useful to orient the tee with, but the branch is.

If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):

- Next end for orientation – Switches the end governing the orientation of the fitting.
8. Click anywhere in the model to specify the direction of the orienting end.

To insert a fitting in intersection mode when one or both of the connecting runs already exist

1. Choose the desired fitting you want to insert from the SC Pipe menu. The fitting appears at the cursor and information about it is shown on the command line.
2. If end mode is active, switch to intersection mode (see step 2 of [End Mode](#) (page 97)); otherwise continue with Step 3.
3. You are prompted to pick the first point or choose an option from the Intersection Mode line:

Please pick the first point of the end axis : or [Select stock/cConnects To.../Next end <1>/neXt point <1>/End mode/Insulation]:

If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):


- Next end – Switches which end of the fitting will be aligned to the axis of the end you will select in step 4.
 - Next point – You will be picking an existing end in step 4 (and not directly placing an intersection point); this option is not relevant to this routing method.
 - End mode – Switches the routing interface to end mode (see [End Mode](#) (page 97)).
4. Click any free end in the model to indicate the end axis you want to place the fitting on. The fitting is now restricted such that its end is aligned with the end you clicked on.
 5. You are prompted to pick a point indicating how far along the axis (chosen in step 4) the fitting should be placed.

Please pick a point indicating distance from the existing end : or [Next end for orientation <4>]:

If more than one end is available for orientation, you can switch the end:

- Next end for orientation – Switches the end governing how far along the chosen end axis the fitting is placed.
6. Click anywhere in the model to fix the distance between the fitting and the end you clicked in step 4.

If the second run you are looking to connect to already exists, you may click on its free end. Should the angle of the fitting differ from the angle between the two ends, a warning is printed. If you are routing an elbow, you may be given additional options to deal with the differing angle. If the elbow's angle is too large (and its orienting end is trimmable), you will be asked if you would like to cutback the elbow to the correct angle. If the elbow's angle is too small, you will be asked if you would like to insert multiple copies of the elbow (possibly trimming the last one) to fill the entire required angle.



The points clicked when placing a lateral at the intersection of two free ends

If you clicked an existing free end you are finished; otherwise the fitting's distance from the end you clicked in step 4 is fixed; continue with step 7.

7. You are prompted to pick a point indicating the direction of an orienting end of the fitting or to choose an option:

Please pick a point indicating a rotation about the defined end axis : or [Next end for orientation <1>/Forward/Aft/Port/Starboard/Up/Down /DEck align/FRame align/Long align/ALign to WCS/ZRotate/SNap<on>]:

Depending which end you placed in Step 3, not all ends will be available as an orienting end while cycling through ends with Next end for orientation. For example, if you placed a tee by one end of its trunk, the other end of the trunk is not useful to orient the tee with, but the branch is.

If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):

- Next end for orientation – Switches the end governing the orientation of the fitting.

8. Click anywhere in the model to specify the direction of the orienting end.

Auto Part Insertion Mode

In Auto Part Insertion(AP) mode, when a user attempt to make a connection and there are no allowable connections for the end treatments of the parts, then instead of just failing or selecting a new stock in the case when the user is jiggging, the Scenario Wizard attempts to add parts to make the connection work. The parts added will be one or two connectors if the ends to be connected are the same size or a reducer if they are not, and if there are multiple solutions at the simplest level that has a solution then the *Scenario Wizard Dialog* will be displayed.

Inline Fitting Insert

To insert a fitting into an existing run of pipe you first run the command for the type of part you want to insert. This starts the jig and where you select the command line option called *Inline Insert*. At this stage you then pick a point. You can select a point in the middle of a straight section of a pipe, a point on a pipe end that is connected, a point on two coincident pipe ends. For each of the three cases the parts will be inserted differently.

If you select a point in a straight section of pipe, that pipe will be broken and the parts will be inserted between the ends at the break. If you select a connected pipe end, the connection will be deleted and the parts will be inserted between the two previously connected parts. If you select two coincident pipe ends the parts will be inserted between them.

The parts inserted are determined by the Scenario Wizard. It finds a solution from one of the end treatments that we are inserting into, to the fitting being inserted, to the other bounding end. It uses the solution with the least number of parts, and if there are multiple solutions at the simplest level that has a solution then the [Scenario Wizard Dialog](#) (page 273) will be displayed.

After the parts have been inserted and connected then the fitting continues in jigging so you can orient it.

Insert Connector Set Command

Running the [SC Pipe > Insert Connector Set](#) (page 235) command or using the toolbar button will start functionality to insert one or two connectors into existing pipe. The point to insert is the same for [Inline Fitting Insert](#) (page 102). After this is done the scenario wizard will select parts to insert in a similar fashion to what was described earlier, and if there are multiple solutions at the simplest level that has a solution then the [Scenario Wizard Dialog](#) (page 273) will be displayed.

Routing Options

Several routing options are available in many different routing cases and serve more or less the same use in each case. To use the options, type their shortcuts (the letters that are capitalized when the options are displayed on the command line). Descriptions of each follow.

General options

- Select stock – Opens the Select Stock Pipe window, allowing you select a different stock pipe.
- Insulation – Displays the insulation window (see [Insulation Reference](#) (page 268)), allowing you to modify the insulation applied to the part you are routing.
- Saddle – Initiates the creation of a new saddle end on an existing pipe to which the pipe you are routing will be attached (see [Create a Saddle](#) (page 104)).

NavAid specific options

The following options affect the NavAid's behavior or orientation (see [The NavAid](#) (page 91)).

- Snap – Toggles snapping of picked points to fixed angles (shown as spikes on the NavAid). The current setting is displayed in the command line in <angle brackets>.
- Plane – Changes the NavAid plane to a perpendicular one (the plane formed by the Z and X axes of the current UCS); effectively cycles the NavAid plane between the 3 axial planes of the current UCS.
- XRotate/YRotate/ZRotate – These options rotate the NavAid (or equivalently, the current UCS) about the respective axis according to the right-hand rule.

World coordinate alignment options

The following options are often available at times when you are prompted to pick a point specifying a direction or rotation. They are a convenient way to get diagonally oriented runs pointing back along world-coordinate axes and planes.

- Forward/Aft/Port/Starboard/Up/Down – These options automatically provide input equivalent to a point in the respective direction (or as close as possible to that direction, depending on the situation).
If you are routing a trimmable elbow, it is often the case that trimming it will allow alignment to directions not otherwise possible. In these cases, options for all possible directions will be available; choosing one that requires trimming will result in a prompt asking if you wish to trim the elbow to allow the alignment.
- Deck align/Frame align/Long align – These options will automatically provide you with an alignment such that the end you are orienting points in a direction lying parallel to the ship's decks, frames, or longitudinal bulkheads, respectively. When there are 2 directions that result in the chosen alignment (which is usually the case), ShipConstructor will arbitrarily choose one of them and then ask you if you would like to use the other direction instead.
- Align to WCS – Aligns the NavAid such that its spikes are directed along world axes (only available in certain cases when the NavAid already lies in a world plane).

Offset routing options

These options affect your current routing offset (see [Offset Routing](#) (page 109)).

- XOffset/YOffset – Prompts you to type the new X or Y component of the routing offset, respectively.
- Choose offset – Allows you to choose a routing offset visually; you will type the letter corresponding to one of several named points on the bounding box of the pipe's profile at the current end.

Creating Connections While Routing In End Mode

Whether routing straights, bents, or fittings, connection creation is initiated by clicking an existing free pipe end when picking the first point. The choices you are prompted to make is dependent on whether or not the two ends can connect (that is, there are connections defined between the two involved end treatments).

If the end you are routing by cannot connect, but a different end on the part can, it is automatically used instead. If there is only one possible choice of connection and accessory package for the two involved end treatments, it is used automatically; otherwise the Select Connection and Accessory Package window will appear to allow you to choose which of each will be used. If no ends on the part you are routing can connect, the Stock Selection window will appear, allowing you to choose from a list of stocks that do have ends that can connect to the clicked end.

Special cases

It is possible to connect to a pipe that you have XRef'd in. This is called a remote connection and is always a spool break. A second special case is connecting to a pipe from another system, which also automatically becomes a spool break (a warning that an inter-system connection has been created will be displayed).


Create a Saddle

A saddle connection is made between a normal end of a branch part, and a saddle end on a second header part. There are two ways to create a saddle.

- Choose the Saddle option when initially routing a pipe
- Route the two involved pipes independently and use the Saddle command to create the saddle connection.


Extra material

Both means of saddle creation allow you to adjust the amount of extra material. This is the minimum length of the branch part beyond the intersection between its surface and the header part's surface.



Extra material applied to a branch part (branch part on the left, header part on the right, running into the page)

ShipConstructor can adjust the location of a branch part for a given amount of extra material only when the projection of the branch part's end (along its end axis) falls entirely on the header part. If a situation in which this not the case is desired, you may place both parts manually, and use the Saddle command to create the saddle, in which specification of extra material is optional.



Whether or not the end of a branch part projects entirely onto the header part

Create a saddle while routing a pipe

1. Choose the branch pipe that you want to route from a new saddle connection from the SC Pipe menu. The pipe appears at the cursor.
2. Type A (for sAddle) to begin creating the saddle and then press Enter. You are prompted to select the header part on which the saddle end will be created:


Please select a Header part:

3. Click on an existing header part on which the saddle will be created. You are prompted to pick a point on the header part. This point is the intersection between the header part's centerline and the connecting end axis of the branch part, or closest point between those two lines in the case that offsets are applied in later steps.

Pick closest point on center line : or [Point on OCS z-axis]:

Optionally, enter one of the keywords:


- Point on OCS z-axis – To specify a point relative to an object coordinate system on the header part, type O (for OCS) and press Enter. The object coordinate systems on the header part are displayed, with their z-axis' tangent to the part's centerline. Click the desired object coordinate system. You are prompted to enter a z-value in the selected object coordinate system; a positive or negative value is valid.



2 object coordinate systems, and the z-axis of the selected one on which a point is specified

Or click on an end:

- **Align to an existing free end** – To set the saddles location, direction, and orientation to line up with those of an existing part's end, click on the end. If it is not possible to create the saddle such that it is aligned with the existing end, an error is reported and saddle creation is aborted.




A saddle aligned to an existing free end, created by clicking the free end right after picking the header part

4. Click a point to determine the direction, or if you selected an object coordinate system on the header part, enter a distance along its z-axis. If you clicked on an existing end, skip to step 6.
The branch part and NavAid appear at the selected point. You are prompted to pick a point indicating the direction of the saddle end.

Please pick point : or [Center-offset<0>/Edge-offset/Flip-offset/Rotate90/World plane/Initial plane/paRt plane/Align to part/Forward/Aft/Port/Starboard/Up/Down/plaNE/XRotate/YRotate/ZRotate/ SNap<on>]:

Optionally, enter one of the keywords:

- Center-offset – To set an offset between the end axis of the branch part and the centerline of the header part (the current offset is shown in <angle brackets>), type C (for Center-offset) and press Enter. Type an offset value and press Enter.
- Edge-offset – To set an offset between the edge of the branch part's profile and the edge of the header part's profile (the current offset is shown in <angle brackets>), type E (for Edge-offset) and press Enter. Type an offset value and press Enter. This option is only available when the header part has a consistent profile in the area local to the saddle end.




Edge and center offsets (branch part on the left, header part on the right, running into the page)

- Flip-offset – To reverse the direction of the current center or edge offset, type FL (for FLip-offset).
- Rotate90 – To rotate the branch part about its own end axis by 90 degrees, type R (for Rotate90).
- World plane – To align the NavAid to the world coordinate axes, type W (for World plane) and press Enter.
- Initial plane – To align the NavAid to the UCS that was current when the command started, type I (for Initial plane) and press Enter.
- Part plane – To align the NavAid to the plane the header part lines in and the direction of its centerline closest to the saddle end, type RT (for paRT plane) and press Enter.
- Align to part – To rotate the NavAid within its own plane so that its zero angle is aligned with the nearest point on the header part's center line, type A (for Align to part) and press Enter.
- Forward – To set the direction of the orienting end as close as possible to forward, type F (for Forward) and press Enter.
- Aft – To set the direction of the orienting end as close as possible to aft, type A (for Aft) and press Enter.
- Port – To set the direction of the orienting end as close as possible to port, type P (for Port) and press Enter.
- Starboard – To set the direction of the orienting end as close as possible to starboard, type S (for Starboard) and press Enter.

- **Up** – To set the direction of the orienting end as close as possible to up, type U (for Up) and press Enter.
- **Down** – To set the direction of the orienting end as close as possible to down, type D (for Down) and press Enter.
- **Snap** – To turn on or off snapping of picked points to fixed angles (the current setting is displayed in the command line in <angle brackets>), type SN (for SNAp) and press Enter.

Or click on an end:

- **Align to an existing end** – To set the saddle's direction and orientation to match that of an existing part's end, click that end.



A saddle with its direction aligned to an existing free end, created by clicking the free end after specifying a point on the header part

5. Pick a point indicating the direction of the saddle end. If you are routing a branch part that has a surface forged to fit the header part's surface, you are prompted to enter the offset between it and the header pipe,

Enter the surface offset distance [Flush/Centerline] <Flush> :

or for a branch pipe that must be cut, the amount of extra material.

Enter the desired extra material length or extend to [Inner Diameter/Centerline] <0.0> :

Optionally, enter one of the keywords:

- **Flush** – Places the branch part such that its surface is flush to the surface of the header part.
 - **Centerline** – Places the branch part such that its centerline begins at the centerline of the header part.
 - **Inner Diameter** – Places the inner diameter of the branch part flush to the outer edge of the header part. The saddle hole cut in the header part is the same diameter as the inner diameter of the branch part.
6. Enter the surface offset (or extra material length). The branch part's end placement is now fully determined. If there is more than one possible connection, you are prompted to select one. The branch part's end treatment in combination with the selected connection determines the saddle's end treatment, and you may only choose from connections such that the saddle's end treatment is of the saddle type. If there is only one possible connection it is used automatically. If there are none, an error is reported and the saddle creation is aborted.


- Unless only one possible connection exists (and was used automatically), select the desired connection and click OK. The saddle end and connection are created. If routing a fitting, continue from Step 6 of the To insert a fitting in end mode procedure (see [End Mode](#) (page 97)); otherwise continue from Step 4 of the To insert a straight pipe or To insert a bent pipe procedure (see [Straight Pipe](#) (page 93) or [Bent Pipe](#) (page 94)).

Create a saddle connection between existing pipes


- Create both parts that will be involved in the saddle connection. They should be where you wish them to be after saddle creation with the exception of the branch' parts end; you will have the option to move that end along its own axis to achieve a desired extra material length in steps 5 and 6.
- Run the SCSADDLE command. You are prompted to select the branch part that will connect to the new saddle end.
- Click on the branch part. You are prompted to select the header part on which the new saddle end will be created.
- Click on the header part. You are prompted whether or not you wish to adjust the branch part's end location to achieve a desired amount of extra material.
- Enter Y or N for Yes or No, respectively. If you select No, skip entering the amount of extra material. If you select Yes, you are prompted to enter an amount of extra material.
- Enter the extra material length. If the branch part's end location needs to be adjusted to achieve the desired length, the branch part is moved using a multi-part transform on its end (see [Multi-Part Transforms](#) (page 117)). If there is more than one possible connection, you are prompted to select one. The branch part's end treatment in combination with the selected connection determines the saddle's end treatment, and you may only choose from connections such that the saddle's end treatment is of the saddle type. If there is only one possible connection it is used automatically. If there are none, an error is reported and the saddle creation is aborted.
- Unless only one possible connection exists (and was used automatically), select the desired connection and click OK. The saddle end and connection are created.

Offset Routing

Offset routing lets you route a pipe or fitting by specifying where it is relative to other geometry in the model. During typical use of offset routing, you specify offset values for a pipe, and then click on Object snap points of other geometry in the model (for example, structure parts, other pipes, or construction lines). A routing offset is specified as an X and Y value in a coordinate system perpendicular to the centerline of a pipe.



You can enter values separately for the X and Y offsets with the XOffset and YOffset options or choose an offset corresponding to a point on the bounding box of a pipe's profile with the Choose offset option. An example of how an offset vector affects the routing of a pipe is shown below.




Pipe routed with four input points from several line segments with a left offset of 500 (offset vector $\langle -500, 0 \rangle$).

Object Snaps

Pipes have several Object snap points that you might find useful when routing pipe or when transforming and existing pipe (see [Multi-Part Transforms](#) (page 117) or [Single-Part Transforms](#) (page 115)). The Object snaps can be enabled or disabled by clicking the OSNAP button on the AutoCAD status bar, by pressing F3, or by right clicking on the OSNAP button and click On or Off. To enable or disable the Object snaps types, right click on the OSNAP button and click Settings.


Endpoint Object Snaps

AutoCAD Endpoint Object snaps can be found at the end points of pipes and at the end points of the sub-segments of a bent pipe.



Midpoint Object Snaps

AutoCAD Midpoint Object snaps can be found on the midpoint of straight segments of pipe.




Nearest Object Snap

Pipes support AutoCAD's nearest Object snap by snapping points to each pipe's centerline.

Custom Object Snaps

In addition to the supported AutoCAD object snaps, several custom object snap types are supported. The custom Object snaps can be enabled or disabled by clicking the SCON OSNAP button (located beside the OSNAP button on the AutoCAD status bar), by pressing shift+F3, or by right clicking on the SCON OSNAP button and click On or Off. To enable or disable the custom Object snaps types, right click on the SCON OSNAP button and click Settings. The custom Object snap settings will be saved between ShipConstructor sessions.



All End Object Snaps


These are the points in the model where distributed systems ends exist.

Free End Object Snaps

These are the points in the model where unconnected distributed systems ends exist (a subset of the points provided by the EndPoint object snaps).

End Axis Intersections

End axis intersection snaps are points where end axes of a part meet. For branch fittings, you find these snaps where the centerline of a branch meets the centerline of the trunk. For an elbow, you find them where the two end axes meet (the intersection of the tangent lines defined by the centerline and the two end points of the elbow).



Profile Corners Object Snaps

Profile corner snaps are located on distributed systems ends. These points are the corners of the bounding box of the profile (see the points labeled Top-Left, Top-Right, Bottom-Left, and Bottom-Right in [Offset Routing](#) (page 109)).

Profile Edges Object Snaps

Profile edge snaps are located on distributed systems ends. These points are the mid-points of the edges of the bounding box of the profile (see the points labeled Left, Right, Top, and Bottom in [Offset Routing](#) (page 109)).

Modify Pipes

Anchor Pipes

It is possible to anchor some pipes in a system so that they do not move when you are transforming the system.

To anchor a pipe

1. Choose [SC Pipe > Anchor Part](#) (page 242).
2. Select all the pipes that you want to anchor.
3. Press Enter

The anchored pipes are marked with the anchor icon.

Note: An anchored pipe will not provide grips when selected.


Unanchor a Pipe

To unanchor pipes

1. Choose [SC Pipe > Unanchor Part](#) (page 242).
2. Select all the pipes that you want to unanchor.
3. Press Enter.

Lock a Pipe

Locked pipes are similar to anchored pipes, but with even more restrictions. You cannot modify or erase a locked pipe. Locked pipes show a lock icon on them. Reasons for the pipe being locked can be seen in AutoCAD's OPM (Object Property Manager). The most common locks in Pipe are a user lock and spool lock. The steps below describe the user lock.



To lock a pipe

1. Choose [SC Pipe > Lock Part](#) (page 243).
2. Select all pipes that you want to lock.
3. Press Enter.


To unlock a pipe

1. Choose [SC Pipe > Unlock Part](#) (page 243).
2. Select all pipes that you want to unlock.
3. Press Enter.

Grip Points

Grips are in the same locations regardless of which transform mode you are in, but they behave differently in each mode.

In single-part transform mode, there are three types of grips: end, corner, and middle grips. End grips are square, corner grips are round, and center grips are triangular. Their behavior is part-specific (see [Single-Part Transforms](#) (page 115)).




In multi-part mode, all grips look and behave similarly.

Toggle Transform Mode

There are two modes in which you can transform existing pipes. Single-part transform mode lets you make specialized changes to individual parts. Multi-part transform mode lets you move larger sections of a pipe system simultaneously. You can toggle between single-part and multi-part transform modes.

To toggle the current transform mode


1. Click the transform mode icon, , on the transform toolbar.

Single-Part Transforms

Bent Pipes


The middle grips can be used to translate the entire bent pipe without changing its geometry.

End and corner grips behave similarly for bent pipes. The points you initially clicked when creating the bent pipe are actually the same points as the end and corner grips. Moving a grip to a different location can be thought of as moving one of the input points and recreating the bent pipe. You can only move a grip point so that the locations of the other grips are not changed.




Fittings

With fittings, middle or center grips can be used for translations. Dragging an end grip point rotates a fitting about one of its connected ends, if possible.



Multi-Part Transforms


Multi-part transforms let you manipulate large sections of a pipe system simultaneously. Typical uses of multi-part transforms are tasks like fine-tuning the location of large sections of a pipe system or adjusting the location of branches (fittings or saddles) in the system.



Experimenting may be the most effective way to familiarize yourself with the behavior of these transforms, but it is also helpful to understand some of logic ShipConstructor uses to help you in cases where a particular transform is not behaving the way you expect it to.


Helpful things to know about multi-part transforms


- The only changes a multi-part transform makes to a system are pipe translations and the shortening or lengthening of straight segments. Fittings are rigid in that they only translate (their geometry does not change).
- It is best to think of a system as several rigid sections connected by straight segments. The notion of these rigid sections is important to understanding how the set of selected grips determine the selected portion of the pipe system.



The thicker black lines indicate the rigid sections of this system.


- Selecting a grip on a rigid section effectively selects the entire rigid section (that is, selecting more than one grip point on the same rigid section has no effect).






Given that a fitting, transition, and offset are directly connected here, these are equivalent selections.


- Selecting more than one grip point selects all of the connected piping between the grips. More specifically, selecting a set of grips is equivalent to selecting all grips points along all possible paths from every selected grip point to every other selected grip point.





Because of the connectivity between the parts with selected grip-points, these are equivalent selections.

- Anchored parts will not be moved. Free ends are treated similarly to anchors and will not move, unless they are part of the current selection.



An octagon with a cross is shown at points beyond which the system is constrained and cannot be moved.

- When multiple grips are dragged, the entire selected section will move by exactly the same amount and in the same direction. That is, the constraints governing how a set of grip points can move include the constraints imposed by each individual grip in the selected section.
- Within the above constraints, the primary goal of the multi-part transform solver is to determine a way to modify the system so that selected grips are moved as close as possible to where you drag them. The multi-part transform

engine will adjust as much of the system as necessary to accomplish this goal, which could mean transforming parts a significant distance away from the selected grips. Anchors are the best way to limit which portions of the system can be affected.

- The transform solver's secondary goal is to optimize the changes that are made to the system so that the changes to the system are as localized as possible. That is, changes to parts closer to the selected grips are preferred over changes to parts further away from the grips.

Toggle Constraining Mode

This option affects transforming bent pipes in both single-part and multi-part modes. If there is a bender associated with a pipe and constraining mode is on then you will be unable to modify a bent pipe in a way that would violate bender constraints.

This option also enforces minimum stock length constraint for all pipes. When constraint enforcement is off, you will be able to modify a pipe so that its length is less than minimum stock length.

To toggle constraining mode

1. Click on the  icon in the toolbar or choose [SC Pipe > Toggle Constrain Enforcement](#) (page 243).

Break a Pipe

Straight and bent pipes support the AutoCAD's native break command. See AutoCAD documentation for further information. ShipConstructor registers a command, through LISP, called SCBAP that automatically splits a pipe object at a given point leaving two full length pieces.

The SCBAP command also allows for the Spacebar or Enter keys to repeat the command unlike the AutoCAD toolbar command.

To break pipes

1. Select the Pipe object that you want to split.
2. Run [SC Pipe > Break Pipe at point](#) (page 242).
3. Choose point to split pipe.

Disconnect Pipes

To disconnect pipes

1. Select the connection that is connecting the two pipes you want to disconnect.
2. Delete the selected connection by pressing the Delete key or using the AutoCAD delete command.

OR

1. Choose [SC Pipe > Disconnect](#) (page 242).
2. Select all the pipes that you want to remove connections from.
3. Press Enter.

Connect Pipes

To connect pipes

1. Choose [SC Pipe > Connect](#) (page 241).
2. Select the first free end to connect.
3. Select an end to connect to the first selected end. This is the part that will be moved by the multi-part transform engine to facilitate the desired connection if it is necessary.

OR

3. If you chose two coincident ends in step 2, choose the part you wish to be moved to make the connection if it is necessary.

Remove Saddle

To remove a saddle

1. Choose [SC Pipe > Saddles > Remove Saddle](#) (page 238).
2. Click the saddle you want to remove.

Mark All Exceeding Maximum Length

The Behavior tab in the [Pipe Options](#) (page 255) window lets you choose whether or not to automatically cut pipes to the maximum allowable stock length. If you choose to not cut pipes to the maximum length, you have the option of labeling all pipes that exceed maximum length.

To label all pipes that are exceeding their maximum length

1. Choose [SC Pipe > Pipe Options](#) (page 244)
2. Select the Behaviour tab.
3. Check the Create warning labels for items exceeding stock length checkbox

Cut to Maximum Length

The Behavior tab in the [Pipe Options](#) (page 255) window lets you choose whether or not to automatically cut pipes to the maximum allowable stock length. If you choose to not cut pipes to the maximum length, you have the option of cutting pipes to their maximum length.

To cut a pipe to its maximum allowable length

1. Choose [SC Pipe > Utilities > Cut to max length](#) (page 239).
2. Select all pipes that you want to cut to their maximum allowable length. Press Enter.
3. ShipConstructor will attempt to cut each pipe to maximum stock length. For each selected pipe, you will be prompted to pick a connection to use to join the resulting segments. If the end treatments of a stock cannot be connected then pipes using that stock still split but the resulting segments will not be connected together.

Note: If the pipe that is cut contains green the End 1 Green will be applied to the first resulting cut pipe and the End 2 Green will be applied to the last resulting cut pipe. The green lengths will be included in the total length of the pipes.

Extract Center Line

Extracts the centerlines from a selection of pipe parts and places them as polylines on a centerline layer. The extracted centerlines can be used to create new pipe parts along the same path as the original parts. On the corners of bents, dotted lines will be drawn to the corner position so that a new bent can be easily placed in the same position as the old bent by selecting the same start point, the corner points, and the same end point.

To extract centerlines

1. Choose [SC Pipe > Utilities > Extract Center Line](#) (page 240)
2. Select all the Pipe parts that you want to extract the centerline from.
3. Press Enter.

Merge To Bent

Merge to Bent is used to create a single bent pipe out of a selection of straight pipes, bent pipes, and pipe elbows. The new bent pipe will follow the same route as the original selection of parts.

For a selection of pipe parts to be used to create the bent:

- They have to be connected to each other.
- They must not form a loop.
- They must not be anchored or locked.

When creating the bent pipe:

- If all the parts have similar properties then those properties will be used to create the new bent pipe. If the parts have different properties then the user will be asked to pick the appropriate property to use.
- If any of the pipes are spooled a message box will be displayed to ask to continue. If yes, then the affected spools will be undefined and all the affected parts will be written out and displayed in a log file.
- If multiple benders exist for the pipe stock the bender selection dialog will appear to select the appropriate bender. If no benders exist the user must have permissions to enter a manual radius to use for bending.
- If connections existed between the end parts of the selected pipes and other pipes, these connections will attempt to be transferred to the new bent pipe. If the connections cannot be transferred but valid connections exist between the new bent pipe and the other parts, the connection dialog will appear to select which connection to use. If no valid connections exist then parts will remain unconnected.

To merge pipe parts to a single bent

1. Choose [SC Pipe > Utilities > Merge To Bent](#) (page 239)
2. Select the straight pipes, bent pipes, and elbows to merge to a single bent.
3. If pipes belong to different systems, select the system that the new bent pipe will belong to.
4. If any of the pipes belong to spools, click yes to undefined all the affected, a log file will be displayed containing all the parts affected from undefining the spools.
5. If selected straight and bent pipes are from different stocks the stock selection dialog will be displayed to select the stock of the new bent pipe.
6. If connections are to be created between the bent pipe and other parts and valid connections exist the connection dialog will be displayed for each connection to select the appropriate connection and accessory packages to use.

Change Connection Accessory Package

Connection accessory packages can be changed after you have placed the connection, provided there are accessory packages defined for the particular connection type, and the accessory package has the same spec as the pipes that are using the connection. If the connected pipes are from two different systems, connection accessory packages from both specs will be listed to select from.

The accessory package that is assigned to a connection, can be seen at a quick glance in the OPM. Optionally from the steps described below, the accessory package can also be changed using the OPM.


To change a connection accessory package

1. Choose [SC Pipe > Change Connection Accessory Package](#) (page 244).
2. Select the connection you wish to change the package for.
3. Press Enter.

If the connected pipes are from two different specs, you will be warned to select your accessory package carefully.



The Select Accessory Package window will appear.



4. Select a connection accessory package and click OK.

Transfer parts to another drawing / unit

The SCHEPTransferPartToDrawing command allows the moving of HEP parts from one drawing / unit to another drawing / unit.

To transfer parts

1. Enter SCHEPTRANSFERPARTTODRAWING command.
2. Select all pipes that you want transferred. Press Enter.
3. Choose a drawing / unit in the selection dialog, and press OK to transfer the parts.

Copy parts to another drawing / unit

The SCHEPReplicateToDrawing command allows the copying of HEP parts from one drawing / unit to another drawing / unit.

To copy parts

1. Enter SCHEPREPLICATETODRAWING command.
2. Select all pipes that you want copied. Press Enter.
3. Choose a drawing / unit in the selection dialog, and press OK to copy the parts.

Pipe Spools

Creating Spools


To create a spool drawing, you must have at least one defined and approved spool. When finished modeling, it is easier to then start adding spool breaks, defining no-spool items, and define spools.

The Spool Manager helps you do this. The Spool Manager is a 'modeless' window which allows changes in the model drawing while being open. In ShipConstructor, there is now no need to refresh the Spool Manager while modeling, as it is automatically refreshed to reflect the changes made. For instance, if a part is added to a run of ducts, it is automatically added to the correct grouping in the Spool Manager as soon as the part has finished being placed.

To open the spool manager


1. Choose [SC Pipe > Spools > Spool Manager](#) (page 235) in Pipe drawings (See also [Spool Manager Reference](#) (page 329).)

Note: You must save your drawing to open the Spool Manager and undo will be disabled while it is open.



No-Spool Items

A No-spool item is a part that is not going to be spooled. No-spool items are displayed with a cross icon.




To set no-spool items

There are six ways to set a part as a no-spool part:

1. In the Spool Manager ([SC Pipe > Spools > Spool Manager](#) (page 235)), drag and drop an undefined part to the No Spool Parts folder.
OR
2. In the model drawing, right-click on the part you want and choose No Spool from the right-click menu. The next time you right-click on the part, a check mark should appear beside the property No Spool.
OR
3. In the model drawing, display the AutoCAD Object Property Manager for the part and change the No Spool property.
OR
4. Click on the Set No Spool toolbar button in the Distributed Systems toolbar.
OR
5. Choose [SC Pipe > Spools > Set No Spool](#) (page 236) from the menu.

Note: You cannot set a pipe to No-Spool if the pipe is part of a locked spool.

6. The Select Hierarchy Window appears.



7. Choose a valid hierarchy, and click OK.

Note: You cannot select the Project as a valid hierarchy. Typically, if the hierarchy is not known at modeling time, it should go into one of the Unassigned hierarchies so it is easier to find all the unassigned parts later.

Spool breaks will automatically be added at every connection the No-Spool item has.

To undefine no-spool items

There are six ways to undefine a no-spool part:

1. In the Spool Manager ([SC Pipe > Spools > Spool Manager](#) (page 235)), drag and drop a No Spool part to the Undefined Spools folder.
OR
2. In the Spool Manager ([SC Pipe > Spools > Spool Manager](#) (page 235)), select one or multiple No Spool parts and right-click on a No Spool part in the list and choose Undefine Part from the right-click menu.
OR
3. In the model drawing, right-click on the part you want and choose No Spool from the right-click menu. The next time you right-click on the part, no check mark should appear beside the property No Spool.
OR
4. In the model drawing, display the AutoCAD Object Property Manager for the part and change the No Spool property.
OR
5. Click on the Remove No Spool toolbar button in the Distributed Systems toolbar.
OR
6. Choose [SC Pipe > Spools > Remove No Spool](#) (page 236) from the menu.


To change the display properties of the no-spool icon

1. Choose [SC Pipe > Pipe Options](#) (page 244) to open the Pipe Options window in a Pipe drawing. See [Display Options for Pipe](#) (page 84).
2. In the Display tab, change the properties under Show No Spool.
3. Click OK.

Add and Remove Spool Breaks

Spool breaks let you logically split up your system into distinct spools. Connections can be turned into spool breaks with the aid of the Spool Manager or by clicking on the corresponding toolbar icon.

By default, spool breaks are indicated with a disk of rays. You can turn on or off the display of spool break indicators and change their size and color.



To add a spool break to a spool

1. In the Spool Manager click Add (under Spool Break).

ShipConstructor minimizes the Spool Manager and prompts:

Please select a Connection to add a Spool Break:

2. Select the connection where you want to break the spool. Parts that are not connections are temporarily locked, to make selecting a connection easier.

ShipConstructor inserts a spool break at the connection.

To add another spool break, select another connection.

Note: You can also window select. Window select will only select connections.

Tip: To make choosing a connection easier, use the OPM to see the properties of the connection. The properties list the part names of the connected parts.

To stop adding spool breaks, press Esc.

Note: There is also the menu command [SC Pipe > Spools > Add Spool Break](#) (page 236) and there is a toolbar button in the Distributed Systems Utilities toolbar.

3. If breaks are added that split defined spools, a prompt to select which section of the spool to remain spooled is displayed. Select a single part from each split spool.

Note: This step also is needed when deleting a connection in the middle of a defined spool.

To remove a spool break from a spool

1. In the Spool Manager click Remove (under Spool Break).

ShipConstructor minimizes the Spool Manager and prompts:

Pick select a Connection to remove a Spool Break:

2. Select the Pipe connection that has the spool break you want to remove. Parts that are not connections are temporarily locked, to make selecting a connection easier.

To remove another spool break, select another connection.

Note: You can also window select. Window select will only select connections.

To stop removing spool breaks, press Esc.

Note: There is also the menu command [SC Pipe > Spools > Remove Spool Break](#) (page 237) and there is a toolbar button in the Distributed Systems Utilities toolbar.

3. If breaks were removed between defined spools a prompt to select which spool you wish to keep for this joined section is displayed. Select a single part from the section of the original spool that you wish to keep.

To change the display properties of the spool break icon

1. Choose [SC Pipe > Pipe Options](#) (page 244) to open the Pipe Options window. See [Display Options for Pipe](#) (page 84).
2. In the Display tab, change the properties under Show Spool Break.
3. Click OK.

Define and Undefine a Spool

Permission: Pipe Spools – Create/Delete

To define a selected spools

1. Open the Spool Manager. (See [Creating Spools](#) (page 127).)
2. Under the Undefined Spools category, select one or multiple spools and right-click on an undefined spool and choose Define Spool.

The Spool Properties window appears. (See [Spool Properties Reference](#) (page 333).)

3. Choose a hierarchy level for the spool, a name, finishes, insulation and click OK.

Note: You cannot select the Project as a valid hierarchy. Typically, if the hierarchy is not known at modeling time, it should go into one of the Unassigned hierarchies so it is easier to find all the unassigned parts later.

The spool now appears under the Modified Spools heading.

Note: When a spool is defined, the spool will be put on a layer of the same name as the spool.

To define all undefined spools

1. Open the Spool Manager. (See [Creating Spools](#) (page 127).)
2. Right-click on the Undefined Spools category heading and choose Define All.
The Spool Properties window appears. (See [Spool Properties Reference](#) (page 333).)
3. Choose a hierarchy level for the spools and click OK.

ShipConstructor minimizes the Spool Manager and displays a prompt:

Please Select 1/x Spool to define

4. Select any pipe from the first spool that you want to define.

Note: Spools are automatically named based on the order you select them.

- Continue to select parts from each spool that you want to define in the order that you want the spools to be named.

Note: To stop defining spools, press Esc. Spools that you have already defined will remain defined. Spools that you have not yet defined will remain undefined.

- When you select a part from the last remaining undefined spool, the Spool Manager returns to normal.

Note: Initial defined spools appear in the Modified Spools category. Once a spool has been approved, it will move to the Defined category.

Tip: Use Override Color to change the color of the defined spools within the drawing. This makes it easier to see which spools you have not yet defined when using the Define All command.

Note: When a spool is defined, the spool will be put on a layer of the same name as the spool.

To undefine selected spools

Warning: You cannot undo this action, and all information related to the spool (database information) will be lost. If a spool drawing was associated with the spool, the drawing will be moved to the Deleted_Spool_Drawings folder under Pipe in the relevant unit.

- Open the Spool Manager. (See [Creating Spools](#) (page 127).)
- Select the spools you wish to undefine and right-click on a defined spool in your selection and choose Undefine Spool.

Note: You cannot undefine a locked spool.

ShipConstructor moves the spool from the Defined Spools , Modified Spools, or Empty Spools category to the Undefined Spools category.

Note: Empty spools occur when all the parts from a defined or modified spool are deleted. They can be treated like a modified spool, and usually should just be undefined to free up the spool name.

To undefine all spools in a category

Warning: You cannot undo this action, and all information related to the spool (database information) will be lost. If a spool drawing was associated with the spool, the drawing will be moved to the Deleted_Spool_Drawings folder under Pipe in the relevant unit.

- Open the Spool Manager. (See [Creating Spools](#) (page 127).)
- Right-click on the Defined Spools header or the Modified Spools header and choose Undefine All.

Note: You cannot undefine a locked spool.

ShipConstructor moves the spools from the Defined Spools or the Modified Spools category to the Undefined Spools category.

Note: Empty spools occur when all the parts from a defined or modified spool are deleted. They can be treated like a modified spool, and usually should just be undefined to free up the spool name.

Approve a Spool

Spools that are in the Modified Spools category are spools that have just been either created or modified. These are the spools that can be approved. A spool must be approved before it can be moved to the Defined Spools category.

Permission: Pipe Spools - Approve

To approve selected spools

1. Open the Spool Manager. (See [Creating Spools](#) (page 127).)
2. Select the spools in the Modified Spools category you wish it approve and right-click on a spool in your selection and chose Approve Spool from the right-click menu.

The spool automatically moves to the Defined Spools category.

To approve all spools

1. Open the Spool Manager. (See [Creating Spools](#) (page 127).)
2. Right-click on the Modified Spools category heading and select Approve All.

All the spools that were in the Modified Spools category now appear in the Defined Spools category.

Lock and Unlock Spools

You can lock a defined spool to prevent any editing of the parts in the spool that would change the spool (for example, erasing, moving, adding new parts to unconnected ends, or adding and removing breaks). Once a spool is finished, you should lock the spool to prevent a modeler from changing the spool without first checking with the project manager.

To lock selected spools

Permission: Pipe Spools - Lock

There are three methods available to lock a spool:

Open the Spool Manager. (See [Creating Spools](#) (page 127).)

1. Right-click on a selection of spools in the Defined Spools category and choose Lock Spool from the right-click menu.
OR
2. Click on the unlock icon beside a defined spool. The icon should change to a lock.
OR
3. Click on a defined spool. In the properties window at the bottom of the Spool Manager (see [Spool Manager Reference](#) (page 329)), click the unlock icon to change it to a lock icon.

To unlock a spool

Permission: Pipe Spools - Unlock

There are three methods available to unlock a spool:

Open the Spool Manager. (See [Creating Spools](#) (page 127).)

1. Right-click on a selection of spools in the Defined Spools category and choose Unlock Spool from the right-click menu.
OR
2. Click on the lock icon beside a defined spool. The icon should change to an unlocked icon.
OR
3. Click on a defined spool. In the properties window at the bottom of the Spool Manager (see [Spool Manager Reference](#) (page 329)), click the lock icon to change it to an unlocked icon.

Change Spool Properties

You can change the name, hierarchy level, and finishes of a defined spool.

Permission: Pipe Spools - Edit

To change the spool name


1. Open the Spool Manager. (See [Creating Spools](#) (page 127).)

2. Select the spool.
3. Make sure the properties section of the Spool Manager is open. (See [Spool Manager Reference](#) (page 329).)
4. There are two methods to change a spool's name: by changing the naming convention used by the spool, or by picking a different generated name, using the spool's current naming convention.
5. Select the naming convention in the Properties section and change it via the dropdown control. The next available name of the new naming convention is used.

OR

6. Click the (...) button beside the spool name in the Properties section.

A list of available names appears.




7. Select a name you want and click OK. The current name will not appear in the list.

To change the hierarchy level

1. Open the Spool Manager. (See [Creating Spools](#) (page 127).)
2. Select the spool.
3. Make sure the properties section of the Spool Manager is open. (See [Spool Manager Reference](#) (page 329).)
4. Click the (...) button beside the hierarchy name.


A hierarchy tree appears.




5. Select a hierarchy level and click OK.

Note: If you change the hierarchy level of your spool and your naming convention has a hierarchy level item in it, the name will not be updated. This means that you will have to re-name your spool to reflect these changes.

To change the finishes of a spool


1. Open the Spool Manager. (See [Creating Spools](#) (page 127).)
2. Select the spool.
3. Make sure the properties section of the Spool Manager is open. (See [Spool Manager Reference](#) (page 329).)
4. Click  beside the finishes list.


The Select Finishes window appears.



- When you finish changing the finishes, click OK. See [Finishes Reference](#) (page 269) for more details.

To change the insulation of a spool

- Open the Spool Manager. (See [Creating Spools](#) (page 127).)
- Select the spool.
- Make sure the properties section of the Spool Manager is open. (See [Spool Manager Reference](#) (page 329).)
- Click  beside the insulation list.
The Select Insulation window appears.




- When you finish changing the insulation, click OK. See [Insulation Reference](#) (page 268) for more details.

View Spool History


Spool history is created for every spool. Before saving a system model drawing, the spool history is updated based on the actions you perform in the drawing so you can keep track of what you have done before you save. After the drawing is saved and re-opened, the spool history changes to reflect the time when your drawing was saved. For example, if you modify the spool a few times, before saving the drawing the spool history will show each modification, after saving and re-opening the spool history will show one modification at the time the drawing is saved.

To view spool history

- Open the Spool Manager. (See [Creating Spools](#) (page 127).)
- Select the spool.
- Make sure the properties section of the Spool Manager is open. (See [Spool Manager Reference](#) (page 329).)
- Click  beside the revision history.

The Spool Revision History window appears.

Note: The Spool Revision History window will not appear if the spool has just been created. If a spool has just been created, the word Created will appear in the Revision History row in the Properties section of the Spool Manager.



Click OK to close the window.

OPM

The Object Properties Manager (OPM) in AutoCAD is a very powerful tool when used with ShipConstructor entities.

Each ShipConstructor entity has properties which can be seen in the OPM, many of which can be modified directly through the OPM without running separate commands.

In addition to the general OPM properties that all AutoCAD entities shared, ShipConstructor adds Solid LineType and Solid LineWeight. These properties allow you to set the line type and line weight of the solid separately from the centerline. The centerline line type and line weight will use the default LineType and LineWeight properties. As with all AutoCAD entity properties that aren't ShipConstructor properties, they will not transfer between drawings such as when creating a production drawing or regenerating a model drawing from the database.

SCONPIPEBENT

End 2 Nominal Size 5"

Data

Entity Status	OK
PWBS	PROJECT/U01/Unspooled Pipe
Part GUID	{A85137C7-FDDB-4C1D-967A-2CF836D...}
SWBS	Drain / New Pipe System0 / New Pipe Br...

Geometry

Length	3.12m
Surface Area	1386445.14 mm ²

End Point

X	74021.3527
Y	-9632.7753
Z	1500.0000

Start Point

X	70898.0790
Y	-9632.7753
Z	1500.0000

Part Attributes

CG Point	x=72459.7158,y=-9632.7753,z=1500....
Fill Ratio	1.0000
Finishes	<None>
Insulations	<None>
Model Number	25
Order Number	<DEFERRED>
Part Catalog	Carbon Steel
Part Name	PIPE-1241

Ends

End 1 Green	0mm
End 2 Green	0mm

Weight

Fluid Weight	69.197kg
Water Weight	32.951kg
Weight	125.68kg
Wet Weight	194.877kg

Spool Information

NoSpool	No
Spool Name	

Stock Attributes

Additional Thickness	0m
Description	SCH 120 ERW PIPE
Manufacturer	COM
Material	ASTM A-53, GR. A
Maximum Length	6.1m
Minimum Length	0.05m
Model Number	
Order Number	
Stock Name	P-ERW-CS_05.0_120_A53-A
User Number	

Ends

End 1 End Treatment	PL 5"
End 1 Nominal Size	5"
End 1 Pressure Rating	ASME B36.10 120
End 1 Size Definition	P" ASME B36.10 120

Properties

In this example, the properties with the white background are the properties which are editable. There are general properties as well as part specific properties. User-defined attributes that are assigned to the stock or part, can be seen here. The part user-defined attributes can be edited through the OPM. The ShipConstructor entities have logically categorized properties according to the specific part's properties for easy navigation.

Weight

There are 4 different types of weight listed for pipes in the OPM and available in the BOM's: water weight, fluid weight, dry weight, and wet weight.

Water Weight – This is the weight of the water in the pipe if the pipe was completely filled.

Fluid Weight – This is the weight of the fluid actually in the pipe. It is calculated as the water weight * Fill Ratio * System Density. The fill ratio and the system density are defined in the system the part is in.

Dry Weight – This is the weight of the pipe part with no fluid.

Wet Weight – This is the overall weight of the pipe. It is calculated as the dry weight + fluid weight.

Activate UCS from Parts


This is a ShipConstructor Utility function that is accessed through either the SC Utilities > Activate UCS... menu command or through the Utilities toolbar button. This utility behaves differently depending on what type of ShipConstructor parts are selected while using the command.

This document describes the command if you select a Distributed Systems part. For information on this command while selecting other ShipConstructor parts, please refer to the respective parts' documentation.

To activate a UCS from a part

1. Choose SC Utilities > Activate UCS...


The Activate UCS window appears. For more information about the options in this window, please see the Structure manual.



2. Click on the Activate from Object button.
3. Select a Distributed Systems part such as Pipe.

Note: Xref'd objects and dimensions are also selectable.

The Select UCS Options window appears.



4. Select the options for the UCS and click OK. See [Select UCS Options Reference](#) (page 272) for more information.

The UCS will now be activated based on the options selected. To see a list of all the UCSs in your drawing, open up the Activate UCS window again and you should see the UCS that you just created.


Pipe-UCS Intersection

The UCS Intersection utility is useful when trying to place Elbows and other fittings at corner points with pipes that transcend the current UCS.

Add Pipe-UCS Intersection

To add a Pipe-UCS Intersection

1. Choose [SC Pipe > Pipe-UCS Intersection > Add Pipe-UCS Intersection](#) (page 240).
2. Select the end on the pipe part that you want to create an intersection for.
3. If the end direction intersects the current UCS a circle will be drawn at the intersection point and a dotted line will be drawn between the center of the circle and the selected end.



Toggle UCS Intersection Line

To toggle displaying the dotted line drawn from the Pipe part to the intersection circle choose [SC Pipe > Pipe-UCS Intersection > Toggle Highlight on all HEP-UCS Intersection](#) (page 241).

Erase Pipe-UCS Intersection

The UCS intersection can be erased by modifying the pipe end that contains the intersection or by manually deleting the intersection.

To manually erase a Pipe-UCS Intersection

1. Choose [SC Pipe > Pipe-UCS Intersection > Erase HEP-UCS Intersection](#) (page 241).
2. Select the pipe end with the UCS intersection that you want to erase.
3. If an UCS intersection exists on the end it will be deleted.

Erase All Pipe-UCS Intersections

To erase all Pipe-UCS intersections in the current drawing choose [SC Pipe > Pipe-UCS Intersection > Erase All HEP-UCS Intersection](#) (page 241).

Hanger Modeling

This section of the manual explains how to use the tools provided in the hanger module to take the stocks you defined in the hanger library and place them in a model drawing to create a hanger model.

Hanger Drawings

You model hangers within hanger or pipe drawings.

For more information on drawings, see Drawings in the Structure manual.

Create an Hanger Drawing

To create a Hanger drawing

1. Choose ShipConstructor > Navigator to open Navigator.

Note: To create a drawing for a unit other than the current unit, select the project at the top of the component list (for example, SC2009Demo), then select the unit in the Unit list.

2. Select Hanger in the component list.
3. Select the Hanger folder in the drawing list.
4. Click New Hanger.

The New Drawing window appears.

5. Enter a File name for the drawing.

Note: To open the new drawing, check the Open new drawing check box.

6. Click OK.

Upon Opening an Hanger Drawing

When opening a hanger model drawing, if connected to the database, synchronization occurs between the drawing and the database. If there are parts that are not in the database but are in the drawing they will be deleted from the drawing.


Note: This synchronization process does not happen with production drawings. For production drawings, you must choose to update it with the Update command in the respective production drawing menu.

Set Up Hanger Defaults, Display, and Performance

Display Options for Hangers

To change the hanger and support display options

1. Choose SC Supports & Hangers > Hanger And Support Drawing Options to open the Hanger & Support Drawing Options window.




2. Set the display options. See [Hanger & Support Drawing Options](#) (page 275) for a description of each option.
3. Click OK to close the Hanger Options window.

NavAid Options

When you are placing hangers that require directional input, a visual aid called the NavAid appears to help you orient the component. You can adjust the size and snap behavior of the NavAid. The NavAid settings are adjusted in the drawing options of the part type that is being hung.

To change the NavAid options

1. Choose SC Pipe > Pipe Options to open the Pipe Drawing Options window.
2. Click the NavAid tab.



3. Set the options. See [The NavAid Tab](#) (page 261) for details.
4. Click OK to save changes and close the Pipe Drawing Options window.

Insert Hangers

You create a hanger model by inserting hangers into a hanger drawing.

There are seventeen different types of distinctly modeled hangers that can be inserted into a hanger drawing. The different types of hangers are defined in the Hanger Stock Catalog in Manager.

Placing a hanger typically involves selecting a pipe part to place the hanger on and then providing geometric input that determines where the hanger is located and how it is oriented. You will provide geometric input by clicking points in the model and using the command line options.

Note: The hangable part types are pipe straights, pipe bents, and pipe elbows.

Information about the current stock that you are routing will appear on the command line.


Selecting a Hanger Part to Place

To place a hanger you must first select the part that the hanger will hang. If this is the first hanger you are placing the Hanger Stock Selection window will be displayed to let you select a hanger stock to place. The Hanger Stock Selection window will let you select a hanger stock that you made in the Hanger Stocks Catalog.


To select a stock to insert

1. From the SC Supports & Hanger menu or the Hanger toolbar, choose the New Hanger command. Select the hangable parts you wish to place hangers on. The Hanger Stock Selection window will appear. See [Hanger Stock Selection Window Reference](#) (page 274) for more information.

Note: If there are no stocks shown clear all the filters and make sure that there are stocks of the type selected created and assigned to the nominal size and material of the selected hangable.



2. Select a hanger type and a stock and click OK.
3. If there are available accessory packages on the stock selected the Select Accessory Package window will be displayed, allowing you to pick an accessory package to assign to the hanger part.




NavAid

The NavAid is a tool intended to help you with several aspects of hanger placing. It can be helpful for two things:


- Visualizing the current UCS
- Snapping input points to fixed angles

When visible, the NavAid is located at the current UCS origin, aligned to the UCS XY plane. The angle displayed by the NavAid is the polar angle of the current input point. The center of the NavAid is indicated by a small cross, with the longer axis in the X direction (0° angle).



Place Hanger

To place a hanger, you will select a stock and then provide a position on the hangable part and an orientation point and rod height (if the hanger type has a rod).



To place a hanger

1. Choose SC Supports & Hanger > New Hanger.
2. You are prompted to select parts to hang the hangers on. Select any number of hangable parts to place hangers on. The hangable parts can either be in the current drawing or MLinked into the current drawing.
3. If this is the first hanger you are placing on the selected type of hangable part, the Hanger Stock Selection Window will appear to select a stock. If you have placed hangers on the type of hangable part, the previous selection will be automatically selected.
4. You are prompted to pick the position of the hanger along the first hangable part selected. The hanger part will slide along the centerline of the hangable part to display where the hanger will be placed.

Please pick point along pipe for first hanger location : or [Change stock/Distance between hangers <0.00>]:

If desired, choose one of the available options:

5. Click anywhere along the hangable part where to select the position where the hanger will be placed.
6. You are prompted to pick an orientation and a rod length for the hanger.

Choose an orientation and rod length : or [ZRotate/Snap<on>/Distance between hanger <0.00>]

If desired, choose one of the available options:

7. Click anywhere in the model to select the orientation for the hanger. If the hanger has a rod the rod length will be determined by the point specified or up to its maximum length specified when creating the stock.
8. Another hanger of the same stock will automatically start routing along the same hangable part once the previous hanger has been placed. Press Enter to stop placing hangers or if multiple hangable parts were selected to start hanging on the next hangable part.

Hanger Routing Options

Several routing options are available in many different routing cases and serve more or less the same use in each case. To use the options, type their shortcuts (the letters that are capitalized when the options are displayed on the command line). Descriptions of each follow.

Hanger General options

- Change stock – Opens the Hanger Stock Selection window, allowing you select a different hanger stock.
- Distance between hangers <0.00> – Places hangers the distance specified apart in the direction specified.

The following options affect the [The NavAid](#) (page 91)s behavior or orientation.


- Snap – Toggles snapping of picked points to fixed angles (shown as spikes on the NavAid). The current setting is displayed in the command line in <angle brackets>.
- ZRotate –Rotates the NavAid (or equivalently, the current UCS) about the z-axis according to the right-hand rule.

Object Snaps

Hangers have several Object snap points that you may find useful when placing other parts in the drawing. The Object snaps can be enabled or disabled by clicking the OSNAP button on the AutoCAD status bar, by pressing F3, or by right clicking on the OSNAP button and clicking On or Off. To enable or disable the Object snaps types, right click on the OSNAP button and click Settings.


Endpoint Object Snaps

The Endpoint OSNAPS will snap to the ends of the hanger. If the hanger has a rod the snap point will be at the top of the hanger. If the hanger does not have a rod the snap point will be at the edge of the hanger.




Center Object Snaps

The center OSNAPS will snap to the point at the center of the hanger. This is the position on the centerline of the part the hanger is hung on where the hanger was placed.



Nearest Object snap

The nearest OSNAP will snap to the nearest point along the 2d line used to define the hanger. The 2d line can be seen when the hanger is set to Show 2D Geom in the Hanger Drawing Options.



Modify Hangers

Name Hangers

The Name Hangers command will rename the hangers that are selected in order based on their position on the parts they are hung on and order that the hangable parts are connected together. The hangers will be named using the current naming convention defined for hangers.

Warning: This command cannot be undone once it has run.

To Rename Hangers

1. Choose SC Supports & Hangers > Name Hangers.
2. You are prompted to select the hangers you would like to rename.

Select hangers to rename [All/Pipe/Selection]:

 - All – Will select all the hangers in the current drawing.
 - Pipe – You will be prompted to select one or more pipes that have hangers and those hangers will be renamed.
 - Selection – You will be prompted to select one or more hangers to be renamed.
3. You will be notified that the command cannot be undone. Click Yes to continue.
4. The selected hanger parts will be automatically renamed and the drawing will be automatically saved when it is finished.

Move Hangers to Drawing

The Move Hangers to Drawing command will move the selected hangers to a drawing specified. The hangers being moved can be both hangers in the current drawing and hangers that have been MLinked in.

To Move Hangers to Drawing

1. Choose SC Supports & Hangers > Move Hangers to Drawing
2. Select the hangers that you wish to move to a different drawing.
3. You will be notified that the command cannot be undone. Click Yes to continue.
4. In the Select Single Drawing window select the drawing you want the hangers to move to.
5. A log file will be displayed showing which hangers were moved and which drawing they were originally in.

Move Attached Hangers to Current Drawing


The Move Attached Hangers to Current Drawing command will move all hangers that are hung on the selected hangable part to the current drawing. The hangers do not need to be MLinked in to bring them into the drawing. This command can be used if you want to modify the hangable part. The hangable part can only be modified if all the hangers are present in the current drawing so that they can be properly updated.

To Move Attached Hangers to Current Drawing

1. Choose SC Supports & Hangers > Move Attached Hangers to Current Drawing
2. Select one or more hangable parts that hangs the hangers you would like brought to the current drawing.
3. You will be notified that the command cannot be undone. Click Yes to continue.
4. A log file will be displayed showing which hangers were moved and which drawing they were originally in.

Grip-points

There are three different types of grips for hangers: slide, length and rotate. Slide grips are arrows that point along the same direction of the hangable part, rotate grips are square, and length grips are arrows that point up from the hanger and only exist on hangers with rods. The slide grip points can be used to slide the hanger along the hangable part. The rotate grip points can be used to rotate the hanger around the hangable part, the rotate grip points will also change the length of the rod if the hanger has a rod. The length grips will change the length of the rod up to its maximum length.



OPM

The Object Properties Manager (OPM) in AutoCAD is a very powerful tool when used with ShipConstructor entities. Each ShipConstructor entity has properties which can be seen in the OPM, many of which can be modified directly through the OPM without running separate commands.

SConPipeHanger

General

TrueColor	ByLayer
Layer	0
Linetype	ByLayer
LinetypeScale	1.0000
PlotStyleName	ByColor
Lineweight	ByLayer
Hyperlinks	
Material	ByLayer

Data

Entity Status	OK
---------------	----

Hangers

Accessory Package	None
Part Name	Hanger - 313

CG Point

X	748.1894
Y	412.5890
Z	121.0156

Rod

Has Rod	No
---------	----

Stock

Edge To Bolt Center	5.0000
Hole Diameter	4.0000
Overall Width	75.0000
Stock Name	PipeStrap
Stock Thickness	2.0000
Stock Width	20.0000

In this example, the properties with the white background are the properties which are editable. There are general properties as well as part-specific properties. User-defined attributes that are assigned to the stock or part can be seen here. The part user-defined attributes can be edited through the OPM. The ShipConstructor entities have logically categorized properties according to the specific part's properties for easy navigation.

Support Modeling

This section of the manual explains how to use the tools provided in the support module to take the stocks you defined in the support library and place them in a model drawing to create a support model.

Support Drawings

You can model supports within support, pipe, or structure drawings.

For more information on drawings, see Drawings in the Structure manual.

Create a Support Drawing

To create a Support drawing

1. Choose ShipConstructor > Navigator to open Navigator

Note: To create a drawing for a unit other than the current unit, select the project at the top of the component list (for example, SC2009Demo), then select the unit in the Unit list.

2. Select Support in the component list.
3. Select the Distributed System Supports folder in the drawing list.
4. Click New

The New Drawing window appears

5. Enter a File name for the drawing

Note: To open the new drawing, check the Open new drawing check box.

6. Click OK.

Upon Opening a Support Drawing

If the project is connected to the database, and a model drawing is opened, the drawing will be automatically synchronized with the database. During the synchronization process, the database is considered to be a source of true information: modeled parts that exist in the drawing but don't have associated database records will be deleted from the drawing. At the same time, if there are database records that are not represented with modeled parts, new parts will appear in the drawing.


Note: The database synchronization doesn't apply to production drawings. To update a production drawing, one must open the drawing in ShipConstructor and manually run the Update Drawing command (SCUPDATEDWG) from the respective command menu.

Set Up Support Defaults, Display, and Performance

Display Options for Supports

To change the display options

1. Choose SC Supports & Hangers > Hanger And Support Drawing Options to open the Hanger & Support Drawing Options window.



2. Set the display options. See [Display Options for Hangers](#) (page 145) for a description of each option.
3. Click OK to close the Hanger & Support Drawing Options window.

NavAid Options

1. Choose SC Supports & Hangers > Hanger And Support Drawing Options to open the Hanger and Support Drawing Options window.
2. Set the options. See [The NavAid Tab](#) (page 261) for details

- Click OK to save the changes and close the Hanger and Support Drawing Options window.

Insert Supports

You create a supports part by inserting supports into a drawing.

There are 7 different types of support templates that can be inserted into a drawing. The different types of supports are defined in the Pipe Support Template Catalog in Manager.

There are 2 distinct ways to insert a support part into a drawing.


Note: The hangable part types are pipe straights, pipe bents, and pipe elbows.

Bare Support

A bare support is placed in the drawing without being attached to any hangable parts. The support is only constrained by Support Template and can be placed anywhere in the drawing. This is useful for placing supports before placing the pipes that it will be supporting.

To insert a bare support:

- Choose SC Supports & Hangers > Insert Bare Support.



If this is the first bare support that is being placed this session the Select Support Template window is displayed otherwise the last used support template is used again.

- Select a Support Template Type and template and click OK.


NavAid

The NavAid is a tool intended to help you with several aspects of placing the support. It can be helpful for two things:

- Visualizing the current UCS


- Snapping input points to fixed angles

When visible, the NavAid is located at the current UCS origin, aligned to the UCS XY plane. The angle displayed by the NavAid is the polar angle of the current input point. The center of the NavAid is indicated by a small cross, with the longer axis in the X direction (0° angle).




Place Bare Support

To place a bare support you will select a stock provide a position for the support, orient the support, provide a support height, and support width.



To place a bare support

1. Choose SC Support & Hangers > Insert Bare Support.
2. If this is the first bare support you are placing the Support Template Selection window will appear to select a template. If you have previously placed a bare support the previous selection will be used.



3. You are prompted to pick the position of the support.

Please pick point to place support : or [Change stock/inTersection mode/Place by next Foot/pLace by next Level/Align to part/plaNE/XRotate/YRotate/ZRotate/SNap<on>/Mirror/Flip supporting profile]:

If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):

- Change stock – Displays the Support Template Selection window to choose a new template to use.
 - Intersection Mode – Changes the placement mode to intersection. Instead of placing by the corner of the profile it's placed on the corner of flange and web of the profile. After placing a lap distance is entered. This option is only available if there is no base plate on the support template.
 - Place by next foot – If the support template contains more than one vertical then the next vertical will be used for placing and orienting the support.
 - Place by next level – If the support template contains any cross tiers then the next cross tier will be used for placing and orienting the support.
 - Align to part – Ask you to select a part and displays the Select UCS Options window to define the UCS based off the selected part.
 - Mirror – Mirrors the part causing the supporting directions to be reversed.
 - Flip supporting profile – Flips the flange directions of the cross tier levels. This is useful if the support will be hanging from a part so that the supported pipes will sit on the support profiles. This option is only available if the supporting profile directions are opposite.
4. Click anywhere to place the support. If the support is being placed by a level other then the base of the support and the point picked is a snap point on a hangable part. You will be asked if you want to align the support to the part.
If desired, choose one of the available options (see [General Options](#) (page 103) for options not listed here):
 5. Click anywhere in the model to select the orientation for the support.
 6. Click anywhere to specify the height of the support. The height will be specified by the point picked or up to the maximum height specified in the support template.
 7. If the support has multiple cross tiers click in the model to place the cross tier at the desired position.

8. Click anywhere in the drawing to specify the width of the support. The width will be specified by the point picked or up to the maximum width specified in the support template.
9. If the support has more than 2 vertical levels click in the model to place the other vertical levels.

Auto Support

The auto support is used to place a support attached to a selection of hangable parts. To use the auto support you will select some hangable parts, a stock, and hangers for each type hangable stock. The Insert Auto Support command will allow you to insert any type of support; the specific auto support commands will allow you to insert only that type of support.


To place an auto support

1. Choose SC Support & Hangers > Insert Auto Support.
2. Select the hangable parts you would like to support.

Please select hangable objects to auto-support: or [Tolerance]:

If desired, choose one of the available options:

- Tolerance – The tolerance is the maximum allowable distance between the support and the hangable part. The initial tolerance value is specified in the Pipe to Support Distance Tolerance project setting. The tolerance can only be overridden if the user has the appropriate permission.
3. The Select Support Template window is displayed with support templates that can be used to support the selected hangable parts.



4. Select the support template you wish to use and the hangers and accessory packages for each type of hangable stock selected and click OK.
5. The support will slide along the available length of the hangable parts. Click anywhere to place the support on the hangable parts.

Please pick location of support: or [Next Section/Rotate/Mirror]:

If desired, choose one of the available options:

- Next Section – Will move the support to the next section of the selected hangable parts. This option is only available if multiple sections of the selected hangable parts can be used to place the selected support.
 - Rotate – Will rotate the support around the hangable parts to the next available orientation.
 - Mirror – Mirrors the part causing the supporting directions to be reversed.
6. Click anywhere to adjust the length of the support to the desired height.

Modify Hangers

Name Supports

The Name Supports command will rename the supports that are selected in order based on the hangers attached to the support and the position that the hangers are hung on the hangable parts. The supports will be renamed using the current naming convention defined for supports.

Warning: This command cannot be undone once it has run.

To Rename Supports

1. Choose SC Supports & Hangers > Name Supports in Order.
2. You are prompted to select the supports you would like to rename.

Select supports to rename [All/Selection]:

- All – Will select all the supports in the current drawing.
 - Selection – You will be prompted to select one or more supports to be renamed.
3. You will be notified that the command cannot be undone. Click Yes to continue.
 4. The selected support parts will be automatically renamed and the drawing will be automatically saved when the command was finished.

Move Supports to Drawing

The Move Supports to drawing command will move the selected supports to the specified drawing. The supports that are moved can be both supports in the current drawing and supports that have been MLinked in. If the supports being moved are attached to hangers the attached hangers will also be moved to the specified drawing.

To Move Supports to Drawing

1. Choose SC Supports & Hangers > Move Supports to Drawing.
2. Select the support that you wish to move to a different drawing.
3. You will be notified the command cannot be undone. Click Yes to continue.
4. In the Select Single Drawing window select the drawing you would like to move the supports to.
5. A log file will be displayed showing which supports were moved and which drawing they were originally in.

Attach Pipes to Supports

The Attach pipes to supports command will attach a selection of pipes to the specified supports with appropriate hangers. The selected pipes may be in the current drawing or have been MLinked in. The selected supports must be in the current drawing.

To Attach Pipes to Supports

1. Choose SC Supports & Hangers > Attach Pipes to Supports.
2. Select the hangable parts that you would like to attach to the supports.

Please select hangable objects to support: or [Tolerance]:

If desired, choose one of the available options:

- Tolerance – The tolerance is the maximum allowable distance between the support and the hangable part. The initial tolerance value is specified in the Pipe to Support Distance Tolerance project setting. The tolerance can only be overridden if the user has the appropriate permission.
3. Select the support parts to attach the hangable parts to.
 4. If the supports and hangable parts can be attached together the Hanger Stock Selection window will be displayed to select which hanger to use to attach the parts together. The Hanger Stock Selection window will be displayed once for each type of hangable stock being attached.
 5. Select the appropriate hanger and accessory package and click OK.

Copy Supports along Supported Objects

The Copy supports along supported objects command will copy a selected support and you place the copied support along the same hangable that the original support was attached to.

To Copy Supports along supported objects

1. Choose SC Supports & Hangers > Copy Supports along Supported Objects.
2. Select the supports to copy.


Please pick location of support: or [Next Section]:

If desired, choose one of the available options:





- Next Section – Moves the support to the next available section on the hangable parts.
3. Select the point on the hangable parts where to place the copied support.

Grip Points

The grip points for supports can be used to adjust the length and width of the support and to adjust the cross tier heights. The grip points to adjust the length of the support are the square grip points at the bottom of the vertical levels. The vertical levels will be adjusted individually. The arrow grip points on the cross tiers are used to adjust the height of the level. The cross tiers levels are restricted to be between the cross tiers above and below the cross tier. The cross tiers will only have grip points if that cross tier is not attached to a hangable part. The arrow grip points that point away from the support can be used to adjust the width of the support.



OPM

SConSupport    

General	
TrueColor	<input type="checkbox"/> ByLayer
Layer	0
Linetype	ByLayer
LinetypeScale	1.0000
PlotStyleName	ByColor
Lineweight	ByLayer
Hyperlinks	
Material	ByLayer

Data	
Entity Status	OK

Supports	
Assembly Full Name	PROJECT/BW-1/Unassigned Supports
Assembly Name	Unassigned Supports
Number Of Hangers	2
Part Name	Support - 14
Weight	81.0328

Base Plate	
Base Plate Length	220.0000
Base Plate Radius	20.0000
Base Plate Stock Name	PL10
Base Plate Type	Rectangle
Base Plate Width	220.0000

CG Point	
X	50917.2619
Y	-83571.6089
Z	-578.4703

Horizontal Profiles	
Horizontal Stock Name	E.A 100X100x10
Horizontals Tiers	2

Locks	
Locked Reasons	<None>
User Lock	No

Stock	
Angle	0.0000
Max Height	2000.0000
Max Length	3000.0000
Stock Name	Two By N

Vertical Profiles	
Vertical Stock Name	E.A 100X100x10
Vertical Tiers	2

In this example, the properties with the white background are the properties which are editable. There are general properties as well as part-specific properties. User-defined attributes that are assigned to the stock or part can be seen here. The part user-defined attributes can be edited through the OPM. The ShipConstructor entities have logically categorized properties according to the specific part's properties for easy navigation.

Distributed Systems Production Drawings

There are two different types of production output drawings that you can create using the Distributed Systems modules. You can create spool drawings and arrangement drawings. Spool drawings are created from HVAC or Pipe spools that are a series of interconnected ducts or pipes. Arrangement drawings can be created from Structure, Pipe, HVAC, and Equipment drawings and Pipe and HVAC systems as well as assemblies.

Creating a Spool Drawing

Several portions of ShipConstructor have to be configured correctly to produce spool drawings. The more time and effort you put into setting up the required styles, templates, and settings, the better the resulting, automatically created spool drawings will look.

To create a spool drawing

Before you can create a spool drawing, you need five things:


1. A valid, active spool naming convention.
2. A defined and approved spool.
3. An HVAC or Pipe Spool Template drawing. Template drawings should have:
 - a. Dimension and text styles pre set.
 - b. A preformatted BOM inserted in the appropriate location.
 - c. Keywords inserted in the appropriate location.
 - d. Drawing options pre set.
4. Permission to create an HVAC or Pipe spool drawing.
5. A defined spool style or permission to define one.

Set Up Spool Naming Convention

One of the first steps in creating a spool is to define a spool naming convention. Spools cannot be defined without one.

To set up a spool naming convention

1. Choose ShipConstructor > Manager to open Manager.
2. Choose General > Naming Conventions to open the Naming Conventions window.



- Under Name Conventions, select HVAC > Spool or Pipe > Spool.
- Click New.
- Set up naming convention properties. For a spool naming convention, the database items that can be used are System and Assembly. For more information on how to set up these properties see the Naming Conventions section in the Structure manual.

Note: If the selected level of database item is lower than the actual parts level, no database item will be generated. For example, if you select an Assembly level of Panel, but your spool is joined to the Unit level, an empty string appears for that element in the generated spool name.

A check mark appears beside the naming convention in the Naming Conventions tree indicating that it is the active naming convention for that category.

Set an Active Naming Convention

You can have several spool naming conventions; however, only one spool naming convention can be the active naming convention that ShipConstructor uses.

To set a naming convention active

- In the Naming Convention window, select the naming convention that you want to be active.
- Click Set Active.

Set Up a Spool Template Drawing

One of the requirements to create a spool drawing is a spool template drawing. There must be a spool template defined for the type of spool drawing you want to create. For example, if you want to create an HVAC spool drawing, you must have an HVAC Spool Template defined.

To create a spool template drawing

- Open Navigator (choose ShipConstructor > Navigator).

2. Navigate to the Templates directory.
3. Select the HVACSpool folder and click New HVACSpool.
OR
4. Select the PipeSpool folder and click New PipeSpool.
5. Enter a name for the Spool Template drawing.
6. Click OK.

Set up the template drawing with the settings that you want to see in your generated spool drawing.

Customizing the Template Drawing

The template drawing controls how the final output drawing appears. By setting up viewports, styles, and layouts in a template drawing, all the production drawings that are generated with this template look generally the same. The template drawing selected when creating a production drawing, is used as a base for the drawing. This means that most AutoCAD options that are drawing specific and setup in the template drawing, will be in the production drawing created.


In order to help you customize the appearance of the template drawing, a number of layers are created and used:

- SCDimension – Dimensions are on this layer. Re-dimensioning a drawing will delete all objects on this layer. Change the color of this layer to control the color of the dimensions in the resulting spool drawings.
- Offset – Hatches and boxes for offsets are on this layer. Re-dimensioning a drawing will delete all objects on this layer. Change the color of this layer to control the color of the hatches and offsets in the resulting spool drawings.
- Spool Layer – All HVAC and Pipe entities are placed on this layer. Change the color of this layer in combination with the Use Branch Color option in the Display Options to control the colors of the parts in the generated spool drawings.

Generally, the appearance of HVAC and Pipe parts in production drawings will adhere to the HVAC or Pipe options and native AutoCAD rendering options just as for model drawings.

Note: When plotting shaded viewports, part centerlines (if turned on) are projected in front of the part geometry such that they are easily visible. Furthermore, remember that AutoCAD allows you to override a viewport's visual style when plotting (see AutoCAD's SHADEPLOT setting for viewports).

Tip: The Pipe or HVAC drawing options you set in template drawing will be inherited in the final output drawing. We recommend that you disable all modeling aids such as free end arrows in order to produce the cleanest output drawings.



Note: In order to insert a spool BOM, there needs to be one defined in Manager.

ShipConstructor uses AutoCAD tables to present the BOM data. Tables created using the Insert Empty BOM Table command have specific properties:

- To insert an empty BOM table

1. Choose SC Spool Template > Insert BOM Table. The BOM Definition Wizard appears.

BOM Definition Wizard

Step 1 of 2
Please Select BOM Definition

BOM Definitions

Style Name	Title	Acad TableStyle	Label Style	Row# prefix
Pipe				
Pipe Arrangement				
Stocks	BOM	Standard	PipeStocks	
Spool List	Spool List	Standard	PipeStocks	SP-
No Spool It	No Spool Item L	Standard	DEFAULT	
Cutlist	Title	Standard	DEFAULT	

Fields

Field name	Alias	Visible	Sort details	Group	Field props
Item #	Item #	Yes	None	No	Integer
Stock Name	Stock	Yes	None	Yes	String
Quantity	Quantity	Yes	None	Yes	Decimal:2pl
Stock Description	Stock Description	Yes	None	Yes	String
End	End	Yes	None	Yes	String
System	System	Yes	None	Yes	String
Length	Length	Yes	None	Yes	Length;Decimal:0pl;Units:m
Area	Area	Yes	None	No	Area;Units:mm;Decimal:0pl

Collectors

Note: Collector order is important.
Position determines BOM output.

Included	Label Style
Pipe Part	<none>

Available

- Assembly
- Structure Part
- Equipment Part
- Pipe Spool
- Pipe Connection Accessories
- HVAC Spool
- HVAC Part
- HVAC Connection Accessories
- Penetration Part

Buttons: New, Default Collectors, Delete, Add/Remove, < Back, Next >, Cancel

- Select the appropriate BOM definition and click Next. The settings particular to the BOM definition are displayed for reference after BOM selection.

BOM Definition Wizard

Step 2 of 2
Set BOM and labeling options

Table Options

Column width: inches(PS units) Row height: Line(s) Maximum number of rows per table: (0 indicates no maximum)

List

☒ List All
☐ List Only Visible

Wrap

Table wrap direction: Spacing: inches(PS units)

Label Options

☐ Label in Viewport
Min. leader length: inches(PS units)

Viewport options

0 Viewports will be labeled.

Buttons: < Back, Finish, Cancel

3. Various options available for BOM and labeling may be specified in step 2. See [Insert Empty BOM Wizard](#) (page 320).
4. Click Finish.
5. Depending on the Collectors included in the BOM definition, there may be additional attributes that can be selected. If there are any such attributes, a window appears. The Pipe Part Collector that is normally included in a spool stock BOM contains such options.
6. Accept the default options to ensure that everything in the spool is listed and then click OK.
7. If the drawing is in model space it will automatically switch to paper space to place the BOM.
8. A sample table is created using the AutoCAD table style specified by the BOM Definition. Select the location for the table.
9. You may choose to prearrange more than one table if you anticipate table wrapping (BOMs with more items than specified by the Maximum number of rows property).

Spool Drawing Keywords

Spool drawing keywords consist of general keywords, spool related keywords, and module specific spool related keywords. Default keywords are updated when a spool drawing is generated to reflect each keyword's current value. For example, if you have a <LAST UPDATE DATE> keyword, when the spool drawing is generated the < LAST UPDATE DATE > changes to the current date.

Keywords are not updated again until you manually update your spool drawing or choose Update from the right-click menu of the keyword. For example, if you had a < LAST UPDATE DATE > keyword in your spool drawing that reflected the current date, this date will not change until you manually choose Update from the right-click menu or choose SC Spool Drawing > Update Drawing.


Keywords are ShipConstructor entities. If you have previous keywords from a ShipConstructor2005 or earlier template, update your template using the update template command. (See [Update a Previous Version of a Spool Template](#) (page 175).) Most of your keywords should be converted to the ShipConstructor keyword entities.

See [Keywords Reference](#) (page 336) for a list of available spool keywords and their description.

To insert keywords

Note: You must be in paper space to insert keywords.

1. Choose SC Spool Template > Insert Keywords.
The Spool Keyword window appears. (See [Keywords Reference](#) (page 336).)



2. Select set up properties for the keywords.
3. Select the keywords that you want to include.
4. Click OK.
5. If the drawing is in model space it will automatically switch to paper space to place the keywords
6. ShipConstructor prompts you to select a location for each keyword you selected.

Please select a location for <LAST UPDATE DATE>

7. Select locations for all keywords.

To delete a keyword

1. Select the keyword.
2. Press Delete.

To change the properties of a keyword

1. Select the keyword.
2. Right-click and select properties to bring up AutoCAD's OPM.
3. Change the properties in the OPM.

Note: In the OPM, you can change the text display properties as well as pre and post append text to a specific keyword.

Update a Previous Version of a Spool Template

This command updates your keywords to the new ShipConstructor keyword entities. In most cases, the default keyword text has changed. You may want to re-position these keywords slightly to accommodate the new default text.

This command also creates the three default layers used for ShipConstructor Spool Drawings, and pre sets the drawing options with more Spool specific options. See [Customizing the Template Drawing](#) (page 171).

To update a spool template

1. Copy your ShipConstructor2005 spool template into the ShipConstructor spool templates folder.
2. The template should now appear in Navigator. Open the template using Navigator. Register the drawing if asked.
3. Choose SC Spool Drawing > Update.
4. All the keywords that can be updated are updated. Three default layers are created if not already there, drawing options are preset.

Generate Spool Drawings

Before being able to create a spool drawing, the following conditions must be met.


Prerequisites for creating a spool drawing

- Created a valid, active, naming convention for HVAC or Pipe spools.
- Defined and approved a spool.
- Created a Spool Template drawing.
- Obtained permission to create a spool drawing.
- Defined a spool style or have permission to define one.

Generating spool drawings is a multi-step process. To make this process easier, there is a Create Spool Drawing Wizard (See [Create Spool Drawing Wizard Reference](#) (page 339)).


To generate a spool drawing

1. Choose ShipConstructor > Navigator to open Navigator.
2. Select HVAC Spool or Pipe Spool in the component list.




3. Click on Create.

The Create Spool Drawing Wizard appears. (See also [Create Spool Drawing Wizard Reference](#) (page 339)).




4. Select a spool template drawing and click Next.



5. In the tree, select all the spools that you want to create a spool drawing for. You should see all the spools that you have selected on the right side of the wizard.

Note: Each spool that you select will generate its own drawing.

6. Click Next.



7. Select a Spool Style and click Finish. The last used Spool Style will be selected by default.

Note: There must be a spool style defined. If you have no spool style defined, click Edit under Spool Styles to create one. (This requires that you have permission to edit spool settings.) (See [Spool Styles Reference](#) (page 341).)

Note: If a spool drawing with the same name exists already, you will be prompted to overwrite it.

You will see your spool drawings being generated. If you are in MDI mode, all the spool drawings will open after generation. If you are in SDI mode, the last spool drawing generated will be open.

Edit Spool Drawings

Rotate a Dimension

The rotate dimension command provides you with an easy way to re-orient your aligned dimensions in 3D. The axis of rotation is defined by the two points that the dimension runs between. You can drag the dimension so that it is rotated about this axis while adjusting the length of its extension lines. You can also type an exact distance for the length of the extension lines.

To re-orient a dimension

1. Choose SC Spool Drawing > Rotate Dimension.
2. You are prompted to pick an aligned dimension:

Select an aligned dimension to rotate:

3. Select one aligned dimension to rotate.
4. You are prompted to pick a point indicating the new location and orientation for the dimension.

Please pick point : [ZRotate/SNap<on>]:

If desired, do any of the following:

- ZRotate – To rotate the NavAid about the UCS Z axis (according to the right-hand rule), type ZR (for ZRotate) and press Enter.
 - Snap – To turn on or off snapping of picked points to fixed angles (the current setting appears in the command line in <angle brackets>), type SN (for SNAp) and press Enter.
5. Pick a point to set the location of the dimension. You can also type a length at the command line that will be used as the length of the dimensions extension lines while still using the rotation angle indicated by the mouse pointer.

Align Dimension Text to View


When changing the view angle of a spool viewport, you may still like the location of the dimensions but wish to re-align their text only. Choose SC Spool Drawing > Align Dimension Text to Current View to do this.

Re-dimension a Spool Drawing

After the initial creation of a spool drawing, you may re-dimension your drawing with different settings or a different view-angle.

To re-dimension a spool drawing

1. Choose SC Spool Drawing > Re-dimension.



2. If desired, click **Override Spool Style Dimensions** to make changes to the dimensioning options. (See [Spool Styles Reference](#) (page 341) for details on the dimensioning options).
3. Click **OK**.

Label Connecting Spool/Assembly

If the spool in the spool drawing is connected to one or more spools, labeling the connection ends where these spools connect is a good idea. By running the **Label Connecting Spool/Assembly** command, each end that connects a spool outside the drawing can be selected to have a label generated for it. The label just contains the name of the spool that the selected end connects to.

To show a connected spool

1. Choose **SC Spool Drawing > Label Connecting Spool/Assembly** (page 288)
2. If there are no spools which are connected to the current one, the command ends. If there are connected spools, the command will prompt to pick an end of the spool.
3. If the drawing is in paper space the largest viewport will automatically be made active.
4. Once an end is chosen that has a connected spool, a label is placed.

Update Spool Drawings


ShipConstructor spool drawings can be updated. Drawings that need updating can easily be identified in Navigator.

Identifying Drawings that Require Updating

Spool drawings that required updating because the parts contained in the spool drawing have changed are identified in Navigator.

To identify out-of-date spool drawings

1. Choose ShipConstructor > Navigator to open Navigator.
2. Select HVAC Spool or Pipe Spool in the component list.
3. Click the Show Out of Date button.



Out of date spool drawings can be identified by the exclamation mark icon (!).

Updating an Existing Spool Drawing

Spool drawings that are out of date can be updated instead of re-created. This lets you preserve all the customization work done on a spool drawing, as only the modified geometry of the spooled parts is modified.

Items that are affected during a drawing update include the following:

- All parts will be updated to reflect the latest geometry in the source model drawings.
- The Bill of Materials (BOM).
- All keywords.
- The automatically generated dimensions and offsets (optional).


Note: When ShipConstructor re-dimensions your spool drawing, it will delete all entities which reside on the dimension and offset layers. If you wish to preserve your custom dimensioning during an update, it is recommended that you place these dimensions on a different layer.

Note: You cannot update a spool drawing from a spool that is not approved.


To update a spool drawing

1. Choose SC Spool Drawing > Update Spool Drawing to start updating the drawing.
2. ShipConstructor determines all parts that need to be updated.

3. The Modified Part Information window appears. (See also [Modified Part Information Reference](#) (page 349)).



4. You can use the Modified Part Information window to inspect parts that have changed during this update. Click OK to continue the update process.
5. The Bill of Materials (BOM) in this drawing will now be updated. Depending on the size of your drawing and the BOM definition, this may take some time.
6. A window appears asking if you want to re-dimension the drawing. If you choose No, the update process is now complete. If you choose Yes, continue with Step 7.
7. The Select Dimension Attributes window appears. (See also [Spool Styles Reference](#) (page 341)).



8. You can choose to use the spool dimensioning style that was used to originally create the spool drawing or you can override the settings. Click OK to finish the drawing updating.

Create Arrangement Drawings

Set Up an Arrangement Drawing Template

One of the requirements to create an arrangement drawing is an arrangement template drawing. There must be an arrangement template defined for the type of arrangement drawing you want to create. For example, if you want to create an HVAC arrangement drawing, you must have an HVAC arrangement template defined.

The template drawing controls how the final output drawing appears. By setting up viewports, styles, and layouts in a template drawing, all the production drawings that are generated with this template look generally the same. The template drawing selected when creating a production drawing, is used as a base for the drawing. This means that most AutoCAD options that are drawing specific and setup in the template drawing will be in the production drawing created.

To create an arrangement template drawing

1. Open Navigator (choose ShipConstructor > Navigator).
2. Navigate to the Templates directory.
3. Select the HVACArrangement folder and click New HVACArrangement.
OR
Select the PipeArrangement folder and click New PipeArrangement.
4. Enter a name for the Arrangement Template drawing.
5. Click OK.

Insert a New Empty Arrangement BOM Table

Note: In order to insert an arrangement BOM, there needs to be one defined in Manager.

For a full functionality overview and instructions on creating BOM definitions, see [Bill of Materials](#) (page 311).

To insert an empty BOM table

Note: You must be in paper space to insert an arrangement table.

1. Choose SC Arrangement Template > Insert BOM Table. The BOM Definition Wizard appears.

BOM Definition Wizard

Step 1 of 2
Please Select BOM Definition

BOM Definitions

Style Name	Title	Acad TableStyle	Label Style	Row# prefix
Pipe				
Pipe Arrangement				
Stocks	BOM	Standard	PipeStocks	
Spool List	Spool List	Standard	PipeStocks	SP-
No Spool It	No Spool Item L	Standard	DEFAULT	
Cutlist	Title	Standard	DEFAULT	

Fields

Field name	Alias	Visible	Sort details	Group	Field props
Item #	Item #	Yes	None	No	Integer
Stock Name	Stock	Yes	None	Yes	String
Quantity	Quantity	Yes	None	Yes	Decimal:2pl
Stock Description	Stock Description	Yes	None	Yes	String
End	End	Yes	None	Yes	String
System	System	Yes	None	Yes	String
Length	Length	Yes	None	Yes	Length;Decimal:0pl;Units:m
Area	Area	Yes	None	No	Area;Units:mm;Decimal:0pl

Collectors

Note: Collector order is important.
Position determines BOM output.

Included	Label Style
Pipe Part	<none>

Available

- Assembly
- Structure Part
- Equipment Part
- Pipe Spool
- Pipe Connection Accessories
- HVAC Spool
- HVAC Part
- HVAC Connection Accessories
- Penetration Part

Buttons: New, Default Collectors, Delete, Add/Remove, < Back, Next >, Cancel

- Select the appropriate BOM definition and click Next. The settings particular to the BOM definition are displayed for reference after BOM selection.

BOM Definition Wizard

Step 2 of 2
Set BOM and labeling options

Table Options

Column width: 2.500 inches(PS units) Row height: 1 Line(s) Maximum number of rows per table: 25 (0 indicates no maximum)

List

☒ List All
☐ List Only Visible

Wrap

Table wrap direction: Right
Spacing: 0.25 inches(PS units)

Label Options

☐ Label in Viewport
Min. leader length: 1 inches(PS units)

Viewport options

0 Viewports will be labeled.
Select viewports
Highlight selected

Buttons: < Back, Finish, Cancel

3. Various options available for BOM and labeling are specified in Step 2 of the wizard. See [Insert Empty BOM Wizard](#) (page 320).
4. Click Finish.
5. Depending on the Collectors included in the BOM Definition, there may be additional attributes that can be selected. If there are any such attributes, a window appears. The Pipe and HVAC Part Collectors that are normally included in a stock BOM contain such options.
6. Accept or modify the default options and then click OK.
7. If the drawing is in model space it will automatically switch to paper space to insert the BOM.
8. A sample table is created using the AutoCAD table style specified by the BOM Definition. Select the location for the table.

Arrangement Drawing Keywords

Arrangement drawing keywords consist of general keywords, arrangement related keywords, and module specific arrangement related keywords. Default keywords are updated when you generate an arrangement drawing to reflect each keyword's current value. For example, if you have a <LAST UPDATE DATE> keyword, when the arrangement drawing is generated the <LAST UPDATE DATE> changes to the current date.

Keywords are not updated again until you manually update your arrangement drawing. For example, if you had a <LAST UPDATE DATE> keyword in your arrangement drawing that reflected the current date, this date will not change until you manually call update from the menu.

Keywords are ShipConstructor entities. If you have previous keywords from a ShipConstructor2005 or earlier template, update your template using the update template command. See [Update a Previous Version of an Arrangement Template](#) (page 187). Most of your keywords should be converted to the ShipConstructor keyword entities.


See [Keywords Reference](#) (page 336) for a list of available keywords and their description.

To insert keywords

Note: You must be in paper space to insert keywords.

1. Choose SC Arrangement Template > Insert Keywords.

The Insert Keyword window appears.



2. Set up the properties as you want them for the keywords.

3. Select the keywords that you want to include.
4. Click OK.
5. If the drawing is in model space it will automatically switch to paper space to insert the keywords.
6. ShipConstructor prompts you to select a location for each keyword you selected.

Please select a location for <LAST UPDATE DATE>

7. Select locations for all keywords.

To delete a keyword

1. Select the keyword.
2. Press Delete.

To change the properties of a keyword

1. Select the keyword.
2. Right-click and select properties to bring up AutoCAD's OPM.
3. Change the properties in the OPM.

Note: In the OPM, you can change the text display properties as well as pre and post append text to a specific keyword.

Update a Previous Version of an Arrangement Template

This command updates your keywords to the new ShipConstructor keyword entities. In most cases, the default keyword text has changed. You may want to re-position these keywords slightly to accommodate the new default text.

To update an arrangement template


1. Copy your ShipConstructor2005 arrangement template into the newer ShipConstructor arrangement templates folder.
2. The template should now appear in Navigator. Open the template using Navigator.
3. Choose SC Arrangement Template > Update from a previous version.
4. All the keywords that can be updated are updated.

Generate Arrangement Drawings


Generating arrangement drawings is a multi-step process. To make this process easier, there is a Create Arrangement Drawing Wizard (See [Create Arrangement Drawing Wizard Reference](#) (page 344)).

To generate an arrangement drawing

1. Choose ShipConstructor > Navigator to open Navigator.
2. Select HVAC or Pipe in the component list.
3. Select the Arrangement sub folder.




4. Click New Arrangement.
5. The Create Arrangement Drawing Wizard appears. (See also [Create Arrangement Drawing Wizard Reference](#) (page 344)).




6. Enter a name for the Arrangement drawing and click Next.

Note: You will not be able to click the Next button if the name you entered already exists.



7. Select an arrangement template drawing and click Next.



8. Choose all sources and their destination layers that you want to generate your arrangement drawing from (see also [Create Arrangement Drawing Wizard Reference](#) (page 344)). There are four possible sources:

- Drawings
- Systems
- Assemblies
- Spools

Click on any sources you want to include in your drawing and select a layer from the drop down list or enter the destination layer in the text field of the drop down box. Any number of sources can be included in an Arrangement drawing. The items in the drop down box are the layers in the template drawing that was selected plus the default value of the source name, and you can also enter any text for a destination layer as well. All selected sources and their layers appear on the right hand side of the window. You can later change these sources by updating the arrangement drawing (See [Update Arrangement Drawings](#) (page 193)).


Note: If you select different sources that include the same part, the part will only show up once in the arrangement drawing. This could happen if you include a system model drawing as well as the entire system that contains all parts in the selected system model drawing. Layer conflicts may arise in this situation, but will be dealt with in a later step.

Note: You may also choose to retain the layers of the part from its model drawing source at this step. Choosing Retain Model Drawing Layers from the dropdown in the layer column will cause the layers from all model drawings containing parts in the current source to be copied into the arrangement drawing and the parts will be moved to the copy of the layer of their source. This brings in all layers from the source, not just ones used by parts in the given source.


Note: While selecting sources, if you hold down the Alt key while checking a box, that box's children will not be checked; otherwise the children will be selected.

Note: You can optionally not show spools as a source with the Show Spools check box. You can also force spools to override any possible layer conflicts caused by parts existing in multiple selected sources with the Spool Layers override conflicts check box

9. Click Next.



10. ShipConstructor automatically determines all the drawings that it must collect parts from to populate the arrangement drawing. In addition to ShipConstructor geometry, you may also import non-ShipConstructor entities. You can later change these sources by updating the arrangement drawing (See [Update Arrangement Drawings](#) (page 193)). Select all drawings that you also want to import non-ShipConstructor geometry from and set destination layers for all non-ShipConstructor geometry. Click Finish.
11. The arrangement drawing will be generated and all Bill of Materials tables and keywords will be updated automatically. Depending on the number of sources selected and the contents of the selected sources, this process may take some time.
12. The Layer Conflict Resolution window appears if there are any conflicts between destination layers of any parts in the drawing.(see also [Layer Conflict Resolution Reference](#) (page 350)).



13. You can use the Layer Conflict Resolution window to sort out the destination layer for any conflicted parts.

Edit Arrangement Drawings

Insert a BOM into an Arrangement

You may at any time insert any extra BOM tables into one of the Arrangement Layouts. As explained in the reference section, one Master Bill of materials exists per BOM Definition, per Arrangement drawing. Each table, of a particular BOM definition, that is placed in the Arrangement, references one Master Bill of Materials. This way item numbering remains consistent across all sheets.

See section [Insert a New Empty Arrangement BOM Table](#) (page 184) for instructions in placing BOM tables.

Export a BOM from an Arrangement Drawing to a Text File

Use the AutoCAD command TABLEEXPORT. This command outputs a csv file (comma separated value) to a location that you specify.

Update Arrangement Drawings

ShipConstructor arrangement drawings can be updated. Drawings that need updating can easily be identified in Navigator.


Note: Updating of a production drawing cannot be undone.

Identifying Drawings that Require Updating

Arrangement drawings that contain parts that have been changed are identified in Navigator.

To identify out of date arrangement drawings

1. Choose ShipConstructor > Navigator to open Navigator.
2. Select HVAC or Pipe in the component list.
3. Click the Show Out of Date button.



Out-of-date arrangement drawings can be identified by the exclamation mark icon (⚠).

Updating an Existing Arrangement Drawing

Arrangement drawings can be updated in ShipConstructor. This lets you keep all the detail work done to an arrangement drawing while importing new parts and geometry, removing unneeded geometry or updating existing parts.

The following items are affected during a drawing update:

- All parts are updated to reflect the latest geometry in the source model drawings.
- The Bill of Materials (BOM).
- All keywords.
- The imported non ShipConstructor geometry

Note: When ShipConstructor updates the non-ShipConstructor entities, it only deletes and re-imports geometry that was brought in during the drawing creation to update process. Any additional geometry added by you to the arrangement drawing will be unaffected by a drawing update, regardless of which layer the geometry resides on.


Copied Parts in Arrangement Drawings

In an arrangement drawing, you can copy any number of production parts. During an update, the copies of the parts also are updated. The following rules apply while updating copied production parts.

- If the original part is deleted from the arrangement drawing by the update process, all its copies are also deleted.
- If the original part is moved or its geometry changes, the copies are also moves and have their geometry changed. They will move relative to the original part while updating.


To update an arrangement drawing

1. Choose SC Arrangement > Update Drawing to start updating the drawing.
2. The Update Drawing Wizard appears (see also [Update Arrangement Drawing Wizard Reference](#) (page 351)).




3. All sources that currently make up the arrangement drawing are selected in the various source trees with the layers specified for those sources will be remembered from creation or the last time it was updated. In addition, a summary of all sources can be seen on the right side of the screen. Add or remove sources as necessary. You also set the destination layers for where new parts from these sources will be placed. Existing parts will stay on their current layer. Conflicts arising from parts being brought in from multiple sources with different layers will be resolved later. Click Next.


Note: You can optionally not show spools as a source with the Show Spools check box. You can also force spools to override any possible layer conflicts caused by parts existing in multiple selected sources with the Spool Layers override conflicts check box



4. ShipConstructor automatically determines all the drawings to collect parts from to populate the arrangement drawing. In addition to ShipConstructor parts, you can also import non-ShipConstructor geometry. All drawings that you currently have imported non-ShipConstructor geometry from will be checked. Select all drawings that you also want to import non-ShipConstructor geometry from and set destination layers for all non-ShipConstructor geometry. Click Finish.
5. The Modified Part Information window appears (see also [Modified Part Information Reference](#) (page 349)).



6. You can use the Modified Part Information window to inspect parts that have changed during this update. Click OK to continue the update process.
7. The Bill of Materials (BOM) in this drawing will now be updated. Depending on the size of your drawing and the BOM definition, this may take some time.
8. The Layer Conflict Resolution window appears if there are any conflicts between destination layers of any parts in the drawing.(see also [Layer Conflict Resolution Reference](#) (page 350)).



9. You can use the Layer Conflict Resolution window to sort out the destination layer for any conflicted parts.

Labeling

Manual Labeling from BOM

To manual label from BOM

1. Choose [SC Arrangement > Label > Manual label from BOM](#) (page 282).
2. If there are multiple BOM tables on the current layout then you will be prompted to select a BOM table. Otherwise continue to step 3.
`Select BOM table:`
3. The command will switch to the last active model space viewport that is .has Label items in viewport set.
`Select a part to label:`
4. Select a part to label. The part must be one that is show in a BOM on the current layout.
`Specify label position (1 seg)[Multi-segment]:`
5. If multi-segment option is selected, you will be prompted for more segments for the leader.
6. Select the position in paperspace to place the label. If you label a part that is already labeled then the original label is removed.
7. The command leaves you in a loop to be able to continue to manual label.
`Select part to label [Copy]:`
8. If you select Copy then the you see
`Select part to copy label [lAbe]:`
9. Select the next part you want to label and the label geometry will be identical to the previously placed label. You can switch back to manually placing each label by selecting lAbe.

Copy Label from BOM

To create a copy of a label for another part

1. Choose [SC Arrangement > Label > Copy Label from BOM](#) (page 282)
`Select the source label:`
2. Select a label that you want to copy the style and geometry from.
`Select a part:`
3. A new label is placed.

Relabel All

This command re-labels all the parts from the BOM across all sheets and places the labels on the _ANNOTATION layer.

Labels are generated only once. Subsequent commands only update the label text to reflect the Bill of Materials.

Even though labels are placed in Paper Space, they now track the objects in Model Space so that if the user pans, zooms, or orbits in the viewport, the labels track accordingly and remain synchronized to the objects that they represent.

To re-label parts from BOMs

1. Choose [SC Arrangement > Label > Relabel All](#) (page 282) or [SC Spool Drawing > Label > Relabel All](#) (page 290).

Relabel from a selected BOM

This command only labels items from select tables and viewports. Labels are placed on the _ANNOTATION layer.

Labels are generated only once. Subsequent commands only update the label text to reflect the Bill of Materials.

Even though labels are placed in Paper Space, they now track the objects in Model Space so that if the user pans, zooms, or orbits in the viewport, the labels track accordingly and remain synchronized to the objects that they represent.

To re-label parts from BOMs

1. Choose [SC Arrangement > Label > Relabel from BOM](#) (page 283) or [SC Spool Drawing > Label > Relabel from BOM](#) (page 291).
2. Select the BOM for which to generate labels from.

Relabel from Parts

This command will label all the parts selected by the user from the selected table.

To re-label parts

1. Choose [SC Arrangement > Label > Relabel from Parts](#) (page 283) or [SC Spool Drawing > Label > Relabel from Parts](#) (page 291)
2. Select parts for which to generate labels from.

Label to part edges

This feature allows user to place labels on borders of parts instead of piece marks. Since there is only one piece mark on each part, it's easy to find the location and lay the label arrow on it. It's much more complicated to label on borders, because there could be none or many edges to be labelled on. A lot of times, it is hard to say where the best place is to put the label on. Several rules were setup in the searching algorithm trying to get the best point on borders.

For detail explanation with diagrams, please refer to the Structure help file for Assembly drawings.

Label on Visible Edge On/Off

If the value is true, all labels will be laid on HLR points (part centres), otherwise they will be on edges.

Type: Boolean.

Default: As in Project Settings

To run the command

1. Choose [SC Arrangement > Label > Label on Visible Edge On/Off](#) (page 283) or
SC Spool Drawing > Label > Label on Visible Edge On/Off
2. Set the value on command line

Adjacent Part Edge Tolerance

If the gap between a midpoint of a group edge to any other visible edge from any other objects is smaller than SCADVLABELADJACENTTOL, the midpoint will not be used as a label point.

Type: A double number in current length units.

Default: As in Project Settings

If a label arrow points to an edge of an object that has other objects close to it, it is hard to tell which object the arrow is pointing to. This setting is trying to filter out those confusing cases.

To run the command

1. Choose [SC Arrangement > Label > Label on Visible Edge On/Off](#) (page 283) or
SC Spool Drawing > Label > Label on Visible Edge On/Off
2. Set the value on command line

Curved Plates in Visible Edge Detection On/Off

If it is false, the frame of the curved plate will be used in HLR projection instead of the plate solid. As you can see, it is not very realistic since the frame won't hide anything behind it. The advantage of this is that you will get a

much faster results because otherwise the surface will be used in HLR, which might bring in hundreds of thousands more points into the calculation.

Curve plates are represented in NURBS curves and surfaces. HLR 4 medium sized (300 x 100) curve plates on my machine with this setting on took about 5 minutes to finish. A complicated drawing from Austal took very long time to finish.

Type: Boolean.

Default: As in Project Settings

To run the command

1. Choose [SC Arrangement > Label > Curved Plates in Visible Edge Detection On/Off](#) (page 283) or
SC Spool Drawing > Label > Curved Plates in Visible Edge Detection On/Off
2. Set the value on command line

Edge Length Filter

It is a percentage value calculated by dividing the length of the testing edge with the length of the longest edge in the part. The testing edge will not be picked as a qualified labeling edge if its percentage is smaller than this setting.

Type: double number in percentage.

Default: As in Project Settings

To run the command

1. Choose [SC Arrangement > Label > Edge Length Filter](#) (page 284) or
SC Spool Drawing > Label > Edge Length Filter
2. Set the value on command line

Edge Determination Minimum Angle

When Hull points were caught from HLR, we'll go through point to point with straight lines. If any 2 next lines form an angle that is bigger than this setting, the intersect point will be counted as a group line end point.

Value Type: A double number as an angle in degree.

Default: As in Project Settings

Group edge is used as the base element for a label to point. The length and the position of a group edge will be used to decide whether it can be used as a label edge.

To run the command

1. Choose [SC Arrangement > Label > Edge Determination Minimum Angle](#) (page 284) or
SC Spool Drawing > Label > Edge Determination Minimum Angle
2. Set the value on command line

Label Reset Automatic Settings

All label settings come originally from Project Settings in Manager. Once user changed a setting through a label command, the current value will be saved and used from current drawing. If you run this reset command and confirmed with a 'yes', all current label settings will be replaced back to the Project Settings again.

To run the command

1. Choose [SC Arrangement > Label > Label Reset Automatic Settings](#) (page 284) or
SC Spool Drawing > Label > Label Reset Automatic Settings
2. Confirm whether you want to reset on command line

Common Production Drawing Functions

Insert an Orientation Icon


You can insert an orientation icon into your spool template drawings. (see Insert Orientation Icon into an Assembly Drawing in the Structure manual).

Viewport Options

These are options which are viewport specific. It is best to set these options in the production drawing template, but they can be changed in the production drawing as well.

To open the viewport options window

1. Choose Viewport Options from the production drawing menu.
2. Select the viewport(s) you would like to change the options for.
3. Press Enter. The viewport options window appears.



Currently, there is only the option to label the items in the viewport. The grayed out KeyMap option is for Assembly drawings.

Note: You can also set the BOM to label the items in the viewport through the BOM wizard when inserting a BOM.

4. Set your viewport options and click OK.

Note: For information on viewport specific display options see Viewport Display Options in the Structure manual.

Update BOMs

This updates the BOMs in your production drawing. You might want to update the BOM if you:

- Have set the BOM to list only those parts that are visible through the Toggle List Only Visible command and only have some parts showing in your viewport.
- Have recently inserted a BOM table and would like it populated.
- Altered items that are contained in the drawing and are referenced by the BOM.

To update the BOM table

1. Choose [SC Arrangement > Update BOMs](#) (page 281) or [SC Spool Drawing > Update BOMs](#) (page 289).

Purge BOMs

This immediately purges erased BOMs from the drawing. Normally it takes opening and closing the drawing twice to permanently remove all references to BOMs after the last table has been erased for a BOM.

To purge erased BOMs

1. Type SCPURGEBOMS at the command line.

Clear All BOMs

This immediately erases all references to BOM definitions yet leaves the current BOM tables intact.

To remove all references to BOMs

1. Type SCCLEARALLBOMS at the command line.

Unlink All BOMS

Removes linked BOM references. Note that auto-linked BOMs will have their linkages reinstated the next time a BOM is inserted into the drawing.

To unlink all BOMs

1. Type SCCUNLINKBOMS at the command line.

To update the BOM table

1. Choose [SC Arrangement > Update BOMs](#) (page 281) or [SC Spool Drawing > Update BOMs](#) (page 289).

Edit BOM Collector Options

This command allows the user to alter a Bill of Materials Collector options. For example, the Pipe Collector allows the user to select which object types to include/exclude. By using this command you can quickly adjust the object types to suit your needs.

To change the BOM Collector options

1. Choose [SC Arrangement > Edit Collector options](#) (page 281) or [SC Spool Drawing > Edit Collector options](#) (page 289).
2. Select one representative Bill of Materials from the drawing.
3. Adjust the Collector options as necessary.

Note: you will be notified if the BOM that you selected has no configurable Collector options.

Update All Keywords

This command updates all the keywords in paper space in a production drawing.

To update only the keywords

1. Choose [SC Arrangement > Update All Keywords](#) (page 280) or [SC Spool Drawing > Update All Keywords](#) (page 288).

Viewport Display Options

List only Visible

There is smart functionality in the BOM which will either list only those parts which are visible to the user, or list all parts regardless if they are visible or not.

To toggle the list only visible variable in the BOM

1. Choose Toggle list only visible from the production drawing menu.

- Information on the command line will inform you whether the variable is set or not.


Note: You will want to run Update BOMs to see changes from this command in the BOM table. If all parts are visible, there will be no difference.

Viewport Clipping


ShipConstructor includes functionality to create precise viewport clipping planes. Unlike standard AutoCAD clip planes, ShipConstructor clipping lets you pick the front and back point to define the clip planes.

To clip a viewport


Note: Before running the command you need to switch to the viewport in which the clipping plane is to be applied.



- Choose Clip current view from the SC Utilities menu.
- If the drawing is in paper space it will prompt you to select the viewport to make active.
- The command line prompts you to: **Enter Point on Plane 1**. Choose a point on one of the clipping planes to be used (whether it is the front or back clipping plane will be determined by ShipConstructor).



Before clipping



After clipping

- The command line prompts you to enter a second point: **Enter Point on plane 2.** Choose a point on the second clipping plane (whether it is the front or back clipping plane will be determined by ShipConstructor).

Note: If the clipping planes are not to your liking you can remove them with the command **SC Utilities > Remove clip** (see below).


Remove clip

To clear a viewport clip

- Choose Remove clip from the SC Utilities menu.
- Select the viewport to clear the clip.

Support Construction Drawings

Support construction drawings are the production drawings for constructing a single distributed systems support.



Before creating a support construction drawing, make sure you have done the following:

- At least one distributed systems support created.
- At least one support construction drawing template.

Set Up Support Construction Drawings

Before creating support construction drawings, you must set up the support construction drawing template.

Set Up a Support Construction Drawing Template

You can control the layout of support construction drawings using support construction drawing templates.

Note: There must be at least one support construction drawing template defined before you can create a support construction drawing.

Create a Support Construction Drawing Template

To create a support construction drawing template

1. Choose ShipConstructor > Navigator to open the Navigator.
2. Select the Templates page.
3. Select the DistributedSystemSupportConstruction folder.
4. Click New DistributedSystemSupportConstruction to open the New Drawing window.
5. Enter a name for the drawing and click OK.
6. Insert your company title block, or create one.
7. Set up as many viewports as you need.
8. Move and size each viewport individually.
9. Double-click on a viewport and choose View > Shade to select a shading style for the support in the view.


See [Set Up Support Construction Drawing Template Viewports](#) (page 206) and [To insert keywords into an support construction drawing template](#)

Set Up Support Construction Drawing Template Viewports

A viewport displays the support, and its dimensions. The layers of the support components and dimensions are determined by the support construction drawing options that can be configured in Manager > Piping.

To set up support construction drawing template viewports

1. In the support construction drawing template, activate paper space.
2. Click in the viewports that you want to set up.
3. Choose [SC Support Const Template > Viewport Options](#) (page 308) to open the Viewport Options window.




4. To make the viewport contain automatic annotations, choose Label items in viewport.
5. Click OK.
6. Repeat Steps 2 through 5 for every viewport you want to set up.

Support Construction Drawing Keywords

You can insert various keywords into a support construction drawing template. When you generate a support construction drawing, ShipConstructor automatically replaces the keyword with the appropriate information.

To insert keywords into an support construction drawing template

1. In the support construction drawing template, activate paper space.
2. Choose [SC Support Const Template > Insert Keywords](#) (page 308) to open the Insert Keyword window.



3. Select the keywords to insert.
4. Change the text properties now in this window or later using AutoCAD. Keywords are based on AutoCAD text objects so all the properties of text objects are available.
5. Click OK.
6. Select the location for the keyword.

The keyword is created as a new ShipConstructor keyword object.

Note: To change the prefix or postfix text of the keyword, use AutoCAD's property window. When a keyword is updated, the prefix and postfix text will not change.


Insert a Support Construction BOM Table

You can now predefine a BOM definition for use within a support construction drawing template. This enables you to format an empty BOM table to your specifications (correct text style, size, and so on) before creating a support construction drawing.

Note: To insert the BOM table, there must already be a support construction BOM definition defined. See [Set Up a Support Construction Drawing BOM Style](#) (page 208).

To insert a BOM table

1. In the support construction drawing template, activate paper space.
2. Choose Format > Table Styles to customize the table style to be used for the BOM table. Be sure that the name of the table style matches the Acad TableStyle name in the BOM Definition.
3. Choose [SC Support Const Template > Insert BOM Table...](#) (page 309)



4. Select a Support Construction BOM.
5. Click Next.
6. Enter the options for the BOM table.
7. Click Finish.
8. Select the location of the empty BOM.

Set Up a Support Construction Drawing BOM Style

You can set up any number of BOM styles for use in support construction drawings, assembly drawings, plate nest drawings, arrangement drawings, and spool drawings.

To set up a BOM style

1. In Manager, choose General > Production Output > Bill of Materials to open the BOM Definitions window.
2. To create a new support construction BOM style, click on Support Construction in the left list and then click New.
3. Click Add/Remove to add fields to the BOM. See [BOM Definitions Manager](#) (page 313) for more details on BOM setup.
4. Include any relevant collectors. Make sure the collectors you want are listed under the Included list. See [Collector Functionality](#) (page 318) for more about collectors.

5. Choose a label style for each collector. This is the style used to automatically annotate the drawing if this option is selected.
6. Click OK.

Generate Support Construction Drawings


Generating Support Construction Drawings

Support Construction drawings are created for individual supports.


Once you have met the requirements outlined in [Support Construction Drawings](#) (page 205), you can create your support construction drawing. The support construction drawing will use the same name as the support that it is created for.

To create support construction drawings


1. Choose ShipConstructor > Navigator to open Navigator.
2. Select Support Construction in the component list.




3. Click Create.
The Create Support Construction Drawing wizard appears.



4. Select a support construction drawing template for all your drawings to use.
5. Click Next. Step 2 of the Create Support Construction Drawing Wizard appears.



6. Place a check in the check box next to each support that will become a support construction drawing. The Drawing Exists column indicates if a support construction drawing already exists for that support.
7. Click Next. Step 3 of the Create Support Construction Drawing Wizard appears.



Set up the settings for the dimensioning.

8. Click Finish.

ShipConstructor creates one support construction drawing for each support selected.

If you are in SDI mode, ShipConstructor will open the last support construction drawing it creates. Otherwise, all support construction drawings created will be open.

Edit Support Construction Drawings

The commands for editing support construction drawings are located in the [SC Support Const Menu](#) (page 299). Support Construction drawings are created using the same name as their support, but this is not a requirement. The support construction drawing's name may be changed at any time, using the Rename command on the right-click menu, in Navigator.


Update Support Construction Drawings

Identifying Drawings that Require Updating

ShipConstructor weld management drawings can be updated. Drawings that need updating can easily be identified in Navigator.

To identify out-of-date support construction drawings

1. Choose ShipConstructor > Navigator to open Navigator.
2. Select Support Construction in the component list.
3. Click Show Out of Date.




Out-of-date arrangement drawings can be identified by the exclamation mark icon (⚠).

Warning: Show Out of Date may take some time depending on how many drawings and parts you have.

Note: If you switch to another page in Navigator and then go back to the support construction page, the support construction page is refreshed and you will not be able to see which drawings are out of date again until you click Show Out of Date.

4. If any support construction drawing's name is different from its support's name, then a log file will be created and display listing the support and the drawing names.




Updating an Existing Support Construction Drawing

If changes are made to the support, or its component parts, after you have created support construction drawings, you must update your support construction drawings. When you update a support construction drawing, ShipConstructor automatically updates the support, parts, keywords, and dimensions, within the drawing, leaving all of your manual edits and annotations intact. Updating support construction drawings is much faster than re-creating them.

To update a support construction drawing

1. Choose [SC Support Const > Update Drawing](#) (page 299) to start updating the drawing.
2. ShipConstructor determines all parts that need to be updated.
3. The Modified Part Information window appears (see also [Modified Part Information Reference](#) (page 349)).



4. You can use the Modified Part Information window to inspect parts that have changed during this update. Click OK to continue the update process.
5. The Bill of Materials (BOM) in this drawing will now be updated. Depending on the size of your drawing and the BOM definition, this may take some time.
6. Click OK to finish the drawing updating.

Insert Keywords in a Support Construction Drawing

Usually your support construction drawing template includes the keywords that you want included in support construction drawings. However, there may be certain keywords that you want to manually insert into a few support construction drawings. Once inserted, the keywords will remain as their default text until the support construction drawing is updated.

Inserting keywords into a support construction drawing is similar to inserting keywords into a support construction drawing template, except you use [SC Support Const > Insert Keywords](#) (page 299).

To insert keywords into a support construction drawing

1. In the support construction drawing, activate paper space.
2. Choose [SC Support Const > Insert Keywords](#) (page 299) to open the Insert Keyword window.
3. Select the keywords to insert.
4. You can change the default text settings now in this window or later using AutoCAD.
5. Click OK.
6. Select the location for each keyword selected.

Note: To change the prefix or postfix text of the keyword, use AutoCAD's property window. When a keyword is updated, the prefix and postfix text will not change.

To update keywords

1. Choose [SC Support Const > Update Drawing](#) (page 299).
2. The keywords in the drawing update regardless of the status of the parts.
OR
1. Choose [SC Support Const > Update All Keywords](#) (page 299).
2. The keywords in the drawing update without updating the parts.
OR
1. Select keywords you wish to update.
2. Choose Update on the right-click menu.

Plot Support Construction Drawings

Plot a Support Construction Drawing

To plot a support construction drawing

1. In the support construction drawing, make sure you are in paper space. (If you are in model space, only the active viewport will be plotted.)
2. At the command line type MVIEW and Enter.
`[ON/OFF/Fit/Shadeplot/Lock/Object/Polygonal/Restore/2/3/4] <Fit>:`
3. Enter Shadeplot and press Enter.
`Shade plot? [As displayed/Wireframe/Hidden/Rendered] <As displayed>`
4. Enter Hidden and press Enter.
`Select Objects:`
5. Pick the viewport or viewports for which you want to hide lines.
6. PLOT the drawing.

Inspect a Plotted Support Construction Drawing


After plotting a support construction drawing, visually inspect the plotted drawing for format and content.

Appendix A: Pipe Command Reference

Manager Pipe Menu

Pipe > Pipe Benders

Opens the Pipe Bending/Cutting Machines window and lets you create, edit, and delete pipe bending and cutting machines.



Pipe Bending/Cutting Machines

Lists all pipe bending and cutting machines, and whether the machine can be used for bending, cutting, or both. Specific bending and cutting information for the selected machine is displayed in the Bending Information and Cutting Information sections of the window.

New – Shows the Edit Pipe Bending/Cutting Machine window. A new machine is created with the values set in this window.

Delete – Deletes the selected pipe bending or cutting machine.

Import – Shows the File Open window, allowing you to select which XML or PRO file you want to import bending or cutting machines from.

Export XML – Exports all of the bending and cutting machines in the Pipe Bending/Cutting Machines list that have their Export check box checked.

Bending Information

Lists bending information for the selected Pipe Bending Machine. This information includes Nominal Size, Pressure Rating, Centerline Radius, Clamp Length, Maximum Bend Angle, Distance Between Bends, and Terminating Clamp Length for each pipe stock that the bending machine can be used with.

Edit – Shows the Machine Size Definition Bend Settings window where you set values for the currently selected item in the Bend Information list.

Add – Shows the Machine Size Definition Bend Settings window where you set values for a new Bend Information entry that corresponds to the selected Pipe Bending/Cutting Machine and Size Definition.

Remove – Deletes the selected Bend Information entry.

Cutting Information

Lists cutting information for the selected pipe cutting machine. This information includes Nominal Size, Pressure Rating, and Kerf for each pipe stock that the bending machine can be used with.

Add – Creates a new entry in the Cutting Information list that corresponds to the selected Pipe Bending/Cutting Machine and Size Definition.

Remove – Deletes the selected Cutting Information entry.

Size Definitions

Lists all size definitions in a tree structure organized by nominal size and then by pressure rating. Selecting a nominal size or pressure rating from the tree will filter the Bending Information and Cutting Information lists to only show information matching the selected nominal size or the selected nominal size and pressure rating pair.

Show All – Shows all Bending Information and Cutting Information entries that correspond to the selected Pipe Bending/Cutting Machine. This lets you quickly undo any nominal size or size definition filtering that is selected in the Size Definition tree.

Pipe > Stock Catalog

Opens the Pipe Stock Catalog window and lets you create, edit, and delete pipe stocks and many of the items associated with the creation of a pipe stock.

Common Buttons and Tools

The Pipe Stock Catalog has four tabs, all of which share some buttons and tools.

Apply Changes – Saves any changes made to data in the current tab or the current tab's sub-dialogs to the database.

Discard Changes – Discards any changes made to data in the current tab or the current tab's sub-dialogs since the tab was opened or the tab's Apply Changes button was clicked.

The Import and Export XML buttons are available with each tab, but import and export different things, depending on the tab you are in, as described below.

Stock Library Grid Toolbar

The Stock Library Grid Toolbar appears on the top of most major grids in the Pipe Stock Catalog. The toolbar has two groups of buttons, which may or may not be visible depending on the properties of the grid that the toolbar belongs to.



Expand All Button

If the grid that the Grid Toolbar is associated with has a tree structure, the Expand All button is visible. Clicking the Expand All button causes all nodes in the grid to be expanded at once.



Collapse All Button

If the grid that the Grid Toolbar is associated with has a tree structure, the Collapse All button is visible. Clicking the Collapse All button causes all nodes in the grid to be collapsed at once.



Apply Filter Button

If the grid that the Grid Toolbar is associated with contains a Filter Row, the Apply Filter button is visible. Clicking the Apply Filter button reapplies the current contents of the filter row to the visible rows in the grid. This is helpful if a filter has been set up and you want to apply that filter to the children of newly expanded items.



Clear Filter Button

If the grid that the Grid Toolbar is associated with contains a Filter Row, the Clear Filter button is visible. Clicking the Clear Filter button clears all the columns in the grid's filter row, removing any filters that may have been applied and showing all the children of the expanded items in the grid.

Filter Row

At the top of all major grids in the Pipe Stock Catalog is the yellow Filter Row. The filter row lets you apply a filter to the grid by supplying a filter to the desired column in the grid, making it quick and easy to find the desired information in a grid containing any number of rows. There are several important things to note about how the filter row works:

1. The filter row executes a contains filter. This means that if you filter using the string 13, the result of the filter will contain rows with 13, 133, Stock13, and any other string containing 13 in the column you are applying the filter against.
2. The filter is only applied to the expanded rows in the grid. If you create a filter and then expand a node and wish to apply the current filter to the newly expanded node's children, use the Apply Filter button at the top of the grid to reapply the filter to the grid's new contents.

Note: Filter values are saved between sessions, if a grid is not displaying the expected rows check that the filter row doesn't contain any undesired values.

Filter Group

The Filter group has three options, Metric, Imperial, or Both. Metric causes the catalog to be filtered so that it only lists metric stocks, Imperial will filter for only imperial stocks, and Both will clear the filter showing all stocks in the project. Changes made to this group are applied to all tabs in the Pipe Stock Catalog. This can cause a change to the filter to take some time if there are a large number of stocks in the current project.

Property Units Group

The Property Units group lets you change how the units that properties are displayed, in metric or imperial. Changes to this setting are reflected in all tabs of the Pipe Stock Catalog.

Size Definitions Tab

Export	In Use	DN(mm)	ND(in)	Standard - Pressure Rating	Outer Diameter (in)	Inner Diameter (in)	Wall Thickness (in)
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.125	ASME B36.19 - 10S	0.405	0.307	0.049
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.125	ASME B36.10 - 40	0.405	0.269	0.068
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.125	ASME B36.19 - 40S	0.405	0.269	0.068
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.125	ASME B36.10 - 80	0.405	0.215	0.095
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.125	ASME B36.19 - 80S	0.405	0.215	0.095
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.25	ASME B36.19 - 10S	0.54	0.41	0.065
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.25	MILSPEC MIL-T-16420 - 200LB	0.54	0.41	0.065
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.25	ASME B36.10 - 40	0.54	0.364	0.088
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.25	ASME B36.19 - 40S	0.54	0.364	0.088
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.25	ANSI B16.11 - 2000LB	0.54	0.34	0.1
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.25	MILSPEC MIL-F-1183 - 200LB	0.54	0.34	0.1
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.25	MSS MSS SP-83 - 3000LB	0.54	0.34	0.1
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.25	ANSI B16.11 - 3000LB	0.54	0.34	0.1
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.25	ASME B36.10 - 80	0.54	0.302	0.119
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.25	ASME B36.19 - 80S	0.54	0.302	0.119
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.375	ASME B36.19 - 10S	0.675	0.545	0.065
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.375	MILSPEC MIL-T-16420 - 200LB	0.675	0.545	0.065
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.375	ASME B36.10 - 40	0.675	0.493	0.091
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.375	ASME B36.19 - 40S	0.675	0.493	0.091
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.375	ANSI B16.11 - 2000LB	0.675	0.475	0.1
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.375	MILSPEC MIL-F-1183 - 200LB	0.675	0.475	0.1
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.375	MSS MSS SP-83 - 3000LB	0.675	0.475	0.1
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.375	ANSI B16.11 - 3000LB	0.675	0.475	0.1
<input type="checkbox"/>	<input checked="" type="checkbox"/>	(-)	0.375	ASME B36.10 - 80	0.675	0.423	0.126

New – Create a new size definition. (See [Create a Size Definition](#) (page 7).)

New Next Size – Create a 'New Next Size' size definition. (See [Create a 'New Next Size' Size Definition](#) (page 7).)

Delete – Delete the selected size definition. (See [Delete a Size Definition](#) (page 8).)


Edit Nominal Sizes – Shows the Nominal Sizes window, where you can create, edit, and delete nominal sizes. (See [Nominal Sizes](#) (page 5).)

Edit Standards – Shows the Standards window, letting you create, edit, and delete international standards, geometric standards, and pressure ratings. (See [Standards](#) (page 2) or [Standards Window](#) (page 224).)

Import – Shows the File Open window, where you import size definitions from a .PRO or .XML file.

Export XML – Exports size definitions that have their Export check box checked to an .XML file.

End Treatments Tab



New – Shows the Edit End Treatments window with a newly created end treatment using the currently selected size definition or the size definition of the currently selected end treatment. (See [Create an End Treatment](#) (page 12).)

New All Sizes... – Shows the Edit End Treatments window with a newly created end treatment for each of the size definitions defined in the Size Definitions tab.

New From Range... – Shows the End Treatment Range window, letting you enter a minimum and maximum value. Next the Edit End Treatments window shows a newly created end treatment for each size definition that has a nominal size within the entered range.

Edit – Shows the Edit End Treatments window with the currently selected end treatment or end treatments available for editing. (See [Edit an End Treatment](#) (page 13).)

Delete – Deletes the selected end treatment. (See [Delete an End Treatment](#) (page 14).)

Treatment Types... – Shows the Treatment Types window, where you can create, edit, and delete end treatment types. (See [Create an End Treatment Type](#) (page 10).)

LineMode Icons... – Shows the LineMode Icon window, where you can create, edit, and delete linemode icons. (See [Create a LineMode Icon](#) (page 11).)


Edit Properties – Shows the End Treatment Properties window, where you can create, edit, and delete General, Descriptive, and Facing properties. (See [Set Up End Treatment Properties](#) (page 12).)

Usage Log – Generates a usage log file for the currently selected end treatment. This button is only enabled when a single valid end treatment is selected.

Import – Shows the Open File window, allowing you to import end treatments from a .PRO or .XML file.

Export XML – Exports end treatments that have their Export check box checked to an .XML file.

Create/Edit Pipe Tab



New – Creates a new stock of the type selected in the Pipe Stocks list or of the type selected from the New button's drop down list. (See [Create a Stock](#) (page 19).)

New Next Size – Creates a new stock, using the currently selected stock as a template and increasing the size definition to the next available size definition with the same geometric standard and pressure rating as the selected stock. (See [Create a 'New Next Size' Stock](#) (page 30).)

Edit – Shows the Stock Editor window for the currently selected stock. (See [Edit a Pipe Stock](#) (page 33).)

Delete – Deletes the currently selected stock.

Stock Usage – Shows the Drawings using stock window, allowing you to find what drawings, if any, contain instances of the selected stock. (See [Stock Usage](#) (page 34).)

End Types – Shows the End Types window, letting you specify what type of end treatments are available on a given straight, or bent, pipe stock. Currently disabled.

Assign To Spec – Shows the Assign To Spec window, letting you add or remove the currently selected stocks from any of the existing specs. (See [Add or Remove Pipe Stocks To or From a Spec](#) (page 33).)

Edit Specs – Shows the Pipe Specs window, letting you create, edit, and delete pipe specs. (See [Specifications](#) (page 16))


Assign To Cat. – Shows the Assign to Catalog window, letting you add or remove the currently selected stocks from any of the existing catalogs. (See [Add or Remove Pipe Stocks To or From a Catalog](#) (page 33).)

Edit Catalogs – Shows the Pipe Catalog window, letting you create, edit, and delete pipe catalogs. (See [Catalogs](#) (page 17))

Valve Handles – Shows the Valve Handle Editor, letting you create, edit, and delete valve handles. (See [Create a Valve Handle](#) (page 30).)

Valve Types – Shows the Valve Types window, letting you edit existing valve types. (See [Edit a Valve Type](#) (page 31).)

Connections Tab



New Type – Creates a new connection type in the Connections grid. (See [Create a Connection Type](#) (page 41))

New Connection – Creates a new connection under the selected connection type in the Connections grid. (See [Create a Connection](#) (page 41).)

New Next Size – Creates a new connection, using the currently selected connection as a template and increasing the nominal size of the new connection's end treatments. The new end treatments will maintain the end treatment type and difference in size of the template stock's end treatments. (See [Create a 'New Next Size' Connection](#) (page 42)).

Delete – Deletes the selected connection or connection type.

Import – Shows the File Open window, where you can select a .PRO or .XML file to import connections from.

Export XML – Exports the connections and connection types that have their Export check box checked to an .XML file.


Connection Accessories

The Connection Accessories grid displays all accessory packages that have been added to the connection selected in the Connections grid.

Add – Shows the Select Accessory Packages window, where you can select the accessory packages you want to add to the connection selected in the Connections grid. (See [Add an Accessory Package To a Connection](#) (page 43).)

Remove – Removes the selected accessory package from the selected connection.

Standards Window



The Standards window (accessed from the [Size Definitions Tab](#) (page 220) of the Pipe Stock Catalog) lets you create, edit, and delete international standards, geometric standards, and pressure ratings. It also allows you to associate a given geometric standard with specific pipe stock types and with specific pressure ratings. The combination of an international standard, a geometric standard, and a pressure rating is what creates a schedule. The association of a geometric standard and specific pipe stock types allows you to control which schedules are available to stocks of a given type.

Standards

The Standards grid contains the international and geometric standards that have been defined for the project and lets you create, edit, and delete the standards as necessary.

New International – Creates a new international standard.

New Geometric – Creates a new geometric standard under the selected international standard.

Delete Standard – Deletes the selected geometric or international standard.

Edit Categories – Shows the Pipe Categories window, where you can create, edit, or delete pipe categories.

Pipe Stock Types

The Pipe Stock Types grid is a list of all the various types of pipe stock that has a check box for each type. The check box is used to add and remove associations between the stock type and the currently selected geometric standard in the Standards grid.

Pressure Ratings

The Pressure Ratings grid contains the pressure ratings that have been defined for the project. This is where you create, edit, and delete pressure ratings as necessary. This is also where you add and remove associations between pressure ratings and the currently selected geometric standard in the Standards grid.

New – Creates a new pressure rating.

Delete – Deletes the selected pressure rating.

Toolbars

The most common commands are located on the Pipe toolbars.

Pipe Toolbar



Straight Pipe

See [SC Pipe > Straight Pipe](#) (page 228)



Bent Pipe

See [SC Pipe > Bent Pipe](#) (page 228)



Elbow

See [SC Pipe > Elbow](#) (page 229)



Reducer

See [SC Pipe > Reducer](#) (page 229)



Cap

See [SC Pipe > Caps](#) (page 229)



Cross

See [SC Pipe > Cross](#) (page 229)



Pipe Branch Flyout



Lateral

See [SC Pipe > Branches > Lateral](#) (page 230)



Tee

See [SC Pipe > Branches > Tee](#) (page 230)



Wye

See [SC Pipe > Branches > Wye](#) (page 230)



Misc.

See [SC Pipe > Branches > Misc](#) (page 230)



Pipe Connector Flyout



Union

See [SC Pipe > Connectors > Union](#) (page 231)



Flange

See [SC Pipe > Connectors > Flange](#) (page 231)



Coupling

See [SC Pipe > Connectors > Coupling](#) (page 231)



Weldolet

See [SC Pipe > Connectors > Weldolet](#) (page 231)



Thredolet

See [SC Pipe > Connectors > Thredolet](#) (page 232)



Adapter

See [SC Pipe > Connectors > Adapter](#) (page 232)



Misc.

See [SC Pipe > Connectors > Misc](#) (page 232)



Pipe Valve Flyout



Ball

See [SC Pipe > Valves > Ball](#) (page 232)



Butterfly

See [SC Pipe > Valves > Butterfly](#) (page 233)



Check

See [SC Pipe > Valves > Check](#) (page 233)



Diaphragm

See [SC Pipe > Valves > Diaphragm](#) (page 233)



Gate

See [SC Pipe > Valves > Gate](#) (page 233)



Globe

See [SC Pipe > Valves > Globe](#) (page 234)



Plug

See [SC Pipe > Valves > Plug](#) (page 234)



Relief

See [SC Pipe > Valves > Relief](#) (page 234)



SDNR

See [SC Pipe > Valves > SDNR](#) (page 234)



Misc.

See [SC Pipe > Valves > Misc](#) (page 235)



Insert Connector Set

See [SC Pipe > Insert Connector Set](#)



Set System From Part

See [SC Pipe > System > Set Current System From Pipe Part](#) (page 237)

Distributed Systems Utilities Toolbar



Connect Parts

See [SC Pipe > Connect](#) (page 241)



Disconnect Parts

See [SC Pipe > Disconnect](#) (page 242)



Extract Center Line

See [SC Pipe > Utilities > Extract Center Line](#) (page 240)



Anchor Part

See [SC Pipe > Anchor Part](#) (page 242)



Unanchor Part

See [SC Pipe > Unanchor Part](#) (page 242)



Toggle Transform Mode

See [SC Pipe > Toggle Transform Mode](#) (page 243)



Mark item as No-Spool

See [SC Pipe > Spools > Set No-Spool](#) (page 236)



Remove No-Spool status

See [SC Pipe > Spools > Remove No-Spool](#) (page 236)



Add Spool-break

See [SC Pipe > Spools > Add Spool Break](#) (page 236)



Remove Spool-break

See [SC Pipe > Spools > Remove Spool Break](#) (page 237)



Toggle Constrain Enforcement

See [SC Pipe > Toggle Constrain Enforcement](#) (page 243)

ShipConstructor Menu

See the Structure manual for general information on the ShipConstructor Menu.

ShipConstructor > Navigator

Button	
Ribbon	ShipConstructor tab > Navigation
Menu	ShipConstructor > Navigator
Toolbar.....	ShipConstructor >
Command	SCNAVIGATE
Permissions ...	None
Procedure.....	See Pipe Navigator Page (page 251)

Opens the Navigator, letting you create and open drawings and perform other drawing related functions.

Note: You must use the Navigator to create, open, or move drawings so that ShipConstructor can keep track of them. Do **not** use Windows Explorer, or ShipConstructor will not be able to properly associate the drawings with the projects.

ShipConstructor > Export Pipe Bending Data



Menu ShipConstructor > Export Pipe Bending Data
Toolbar None
Command SCPIPEEXPORTBENDINGDATA
Permissions ... None
Details.....See [Bending Data - XML Output](#) (page 322)

Opens the select pipes window from which you can create pipe bending data XML.

SC Pipe Menu



The SC Pipe menu appears in Pipe drawings.

SC Pipe > Straight Pipe

Button 
RibbonPipe Modeling tab > Pipe
Menu SC Pipe > Straight Pipe
Toolbar..... Pipe > 
Command SCSTRAIGHTPIPE
Permissions ... Pipe Models > Edit
Procedure..... [Straight Pipe](#) (page 93)



Inserts a straight pipe.

SC Pipe > Bent Pipe

Button 
RibbonPipe Modeling tab > Pipe
Menu SC Pipe > Bent Pipe
Toolbar..... Pipe > 
Command SCBENTPIPE
Permissions ... Pipe > Modeling > Pipe Models - Edit
Procedure..... [Bent Pipe](#) (page 94)



Inserts a bent pipe.

SC Pipe > Elbow

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Elbow
Toolbar	Pipe > 
Command	SCPIPELBOW
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a pipe elbow.

SC Pipe > Reducer

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Reducer
Toolbar	Pipe > 
Command	SCPIPEREDUCER
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a pipe reducer.

SC Pipe > Caps

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Caps
Toolbar	Pipe > 
Command	SCPIPECAP
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a pipe cap.

SC Pipe > Cross

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Cross
Toolbar	Pipe > 
Command	SCPIPECROSS
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)

Inserts a pipe cross.

SC Pipe > Branches > Lateral

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Branches > Lateral
Toolbar	Pipe > Pipe Branch Flyout > 
Command	SCPIPEBRANCH LATERAL
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)


Inserts a lateral branch.

SC Pipe > Branches > Tee

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Branches > Tee
Toolbar	Pipe > Pipe Branch Flyout > 
Command	SCPIPEBRANCH TEE
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)

Inserts a tee branch.

SC Pipe > Branches > Wye

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Branches > Wye
Toolbar	Pipe > Pipe Branch Flyout > 
Command	SCPIPEBRANCH WYE
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a wye branch.

SC Pipe > Branches > Misc

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Branches > Misc
Toolbar	Pipe > Pipe Branch Flyout > 
Command	SCPIPEBRANCH MISC
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a miscellaneous branch.

SC Pipe > Connectors > Union

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Connectors > Union
Toolbar	Pipe > Pipe Connector Flyout > 
Command	SCPIPECONNECTOR UNION
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a union connector.

SC Pipe > Connectors > Flange

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Connectors > Flange
Toolbar	Pipe > Pipe Connector Flyout > 
Command	SCPIPECONNECTOR FLANGE
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a flange connector.

SC Pipe > Connectors > Coupling

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Connectors > Coupling
Toolbar	Pipe > Pipe Connector Flyout > 
Command	SCPIPECONNECTOR COUPLING
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a coupling connector.

SC Pipe > Connectors > Weldolet

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Connectors > Weldolet
Toolbar	Pipe > Pipe Connector Flyout > 
Command	SCPIPECONNECTOR WELDOLET
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a weldolet connector.

SC Pipe > Connectors > Threadolet

Button 
 Ribbon Pipe Modeling tab > Pipe
 Menu SC Pipe > Connectors > Threadolet
 Toolbar Pipe > Pipe Connector Flyout > 
 Command SCPIPECONNECTOR THREADOLET
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Fittings](#) (page 96)



Inserts a threadolet connector.

SC Pipe > Connectors > Adapter

Button 
 Ribbon Pipe Modeling tab > Pipe
 Menu SC Pipe > Connectors > Adapter
 Toolbar Pipe > Pipe Connector Flyout > 
 Command SCPIPECONNECTOR ADAPTER
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Fittings](#) (page 96)



Inserts an adapter connector.

SC Pipe > Connectors > Misc

Button 
 Ribbon Pipe Modeling tab > Pipe
 Menu SC Pipe > Connectors > Misc
 Toolbar Pipe > Pipe Connector Flyout > 
 Command SCPIPECONNECTOR MISC
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Fittings](#) (page 96)



Inserts a miscellaneous connector.

SC Pipe > Valves > Ball

Button 
 Ribbon Pipe Modeling tab > Pipe
 Menu SC Pipe > Valves > Ball
 Toolbar Pipe > Pipe Valve Flyout > 
 Command SCPIPEVALVE BALL
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Fittings](#) (page 96)



Inserts a ball valve.

SC Pipe > Valves > Butterfly

Button 
 Ribbon Pipe Modeling tab > Pipe
 Menu SC Pipe > Valves > Butterfly
 Toolbar Pipe > Pipe Valve Flyout > 
 Command SCPIPEVALVE BUTTERFLY
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Fittings](#) (page 96)



Inserts a butterfly valve.

SC Pipe > Valves > Check

Button 
 Ribbon Pipe Modeling tab > Pipe
 Menu SC Pipe > Valves > Check
 Toolbar Pipe > Pipe Valve Flyout > 
 Command SCPIPEVALVE CHECK
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Fittings](#) (page 96)



Inserts a check valve.

SC Pipe > Valves > Diaphragm

Button 
 Ribbon Pipe Modeling tab > Pipe
 Menu SC Pipe > Valves > Diaphragm
 Toolbar Pipe > Pipe Valve Flyout > 
 Command SCPIPEVALVE DIAPHRAGM
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Fittings](#) (page 96)


Inserts a diaphragm valve.

SC Pipe > Valves > Gate

Button 
 Ribbon Pipe Modeling tab > Pipe
 Menu SC Pipe > Valves > Gate
 Toolbar Pipe > Pipe Valve Flyout > 
 Command SCPIPEVALVE GATE
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Fittings](#) (page 96)



Inserts a gate valve.

SC Pipe > Valves > Globe

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Valves > Globe
Toolbar	Pipe > Pipe Valve Flyout > 
Command	SCPIPEVALVE GLOBE
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a globe valve.

SC Pipe > Valves > Plug

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Valves > Plug
Toolbar	Pipe > Pipe Valve Flyout > 
Command	SCPIPEVALVE PLUG
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a plug valve.

SC Pipe > Valves > Relief

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Valves > Relief
Toolbar	Pipe > Pipe Valve Flyout > 
Command	SCPIPEVALVE RELIEF
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a relief valve.

SC Pipe > Valves > SDNR

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Valves > SDNR
Toolbar	Pipe > Pipe Valve Flyout > 
Command	SCPIPEVALVE SDNR
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a SDNR valve.

SC Pipe > Valves > Misc

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Valves > Misc
Toolbar	Pipe > Pipe Valve Flyout > 
Command	SCPIPEVALVE MISC
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Fittings (page 96)



Inserts a miscellaneous valve.

SC Pipe > Insert Connector Set

Button	
Ribbon	none
Menu	none
Toolbar	SC Pipe > 
Command	SCPipeInsertConnectorSet
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Insert Connector Set Command (page 103)


Inserts one or two connectors while retaining connections.

SC Pipe > Equipment

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Equipment
Toolbar	Equipment > 
Command	SCINSEQUIMENT
Permissions ...	Equipment > Equipment Models - Edit
Procedure	See the Equipment Manual for details n Equipment Parts.



Inserts an equipment part.

SC Pipe > Spools > Spool Manager

Button	
Ribbon	Pipe Modeling tab > Pipe Spool
Menu	SC Pipe > Spools > Spool Manager...
Toolbar	None
Command	SCPIPESPOOLMANAGER
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Spool Manager Reference (page 329)



Launches the Spool Manager for you to create, edit, and modify the spool breakdown for the current Pipe model.

SC Pipe > Spools > Set No-Spool

Button	
Ribbon	Pipe Modeling tab > Pipe Spool
Menu	SC Pipe > Spools > Set No-Spool
Toolbar	Distributed Systems Utilities > 
Command	SCDwgOptionsPipeNoSpool
Permissions ...	Pipe > Modeling > Pipe Modeling - Edit
Procedure	No-Spool Items (page 130)



Sets a part as a No-Spool item.

SC Pipe > Spools > Remove No-Spool

Button	
Ribbon	Pipe Modeling tab > Pipe Spool
Menu	SC Pipe > Spools > Remove No-Spool
Toolbar	Distributed Systems Utilities > 
Command	SCRemoveNoSpool
Permissions ...	Pipe > Modeling > Pipe Modeling - Edit
Procedure	No-Spool Items (page 130)



Removes the No-Spool status.

SC Pipe > Spools > Add Spool Break

Button	
Ribbon	Pipe Modeling tab > Pipe Spool
Menu	SC Pipe > Spools > Add Spool Break
Toolbar	Distributed Systems Utilities > 
Command	SCAddSpoolBrk
Permissions ...	Pipe > Modeling > Pipe Modeling - Edit
Procedure	Add and Remove Spool Breaks (page 132)



Adds a spool break to a connection. If a spool drawing already exists for the spool you are breaking then you have the possibility of making two new spools. If this is the case then the spool drawing is moved to Deleted_Spool_Drawings. You can reattach the spool drawing at a later date using the reattach command. See Reattaching a spool drawing in the Structure Manual.

SC Pipe > Spools > Remove Spool Break

Button	
Ribbon	Pipe Modeling tab > Pipe Spool
Menu	SC Pipe > Spools > Remove Spool Break
Toolbar	Distributed Systems Utilities > 
Command	SCRemoveSpoolBrk
Permissions ...	Pipe > Modeling > Pipe Modeling - Edit
Procedure	Add and Remove Spool Breaks (page 132)



Removes a spool break from a connection.

SC Pipe > System > System Manager...

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > System > System Manager...
Toolbar	SC Pipe > 
Command	SCPIPESYSMANAGER
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Set Up Pipe Systems (page 82)



Opens the System Manager, letting you create and edit Pipe systems. See [System Manager](#) (page 254).

SC Pipe > System > Set Current System From Pipe Part

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > System > Set Current System From Pipe Part
Toolbar	Pipe > 
Command	SCPipeSetSystemFromPart
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Set the Current System for Pipes (page 83)


Set the current system of the model drawing by selecting a part that is assigned to the desired system.

SC Pipe > System > Set System...

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > System > Set System...
Toolbar	Pipe > 
Command	SCDWGOPTIONSPIPEPIPESYSTEM
Permissions ...	Pipe > Modeling > Pipe Models - Edit


Lets you assign a pipe to a different system branch.

SC Pipe > Saddles > Create Saddle

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Saddles > Create Saddle
Toolbar	None
Command	SCSADDLE
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Create a Saddle (page 104)


Adds a saddle at the given location on the selected pipe.

SC Pipe > Saddles > Remove Saddle

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Saddles > Remove Saddle
Toolbar	None
Command	SCREMOVESADDLE
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Remove Saddle (page 125)


Removes the selected saddle.

SC Pipe > Insulation and Finishes > Add Insulation

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Insulation and Finishes > Add Insulation
Toolbar	None
Command	SCAPPLYINSULATION
Permissions ...	Pipe > Modeling > Pipe Models - Edit


Opens the Select Insulation window, letting you apply insulation to the selected pipe. See [Insulation Reference](#) (page 268).

SC Pipe > Insulation and Finishes > View Finishes

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Insulation and Finishes > View Finishes
Toolbar	None
Command	SCVIEWFINISHES


Opens the Select Finishes window, letting you view the finishes for the selected pipe. See [Finishes Reference](#) (page 269).

SC Pipe > Insulation and Finishes > Apply Finishes

Button	
Ribbon	Pipe Modeling tab > Pipe
Menu	SC Pipe > Insulation and Finishes > Apply Finishes
Toolbar	None
Command	SCAPPLYFINISHES
Permissions ...	Pipe > Modeling > Pipe Models - Edit



Opens the Select Finishes window, letting you apply finishes to the selected pipe. See [Finishes Reference](#) (page 269).

SC Pipe > Utilities > Merge To Bent

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Utilities > Merge To Bent
Toolbar	None
Command	SCPipeMergeToBent


Merges a selection of pipe parts into a single bent pipe.

SC Pipe > Utilities > Route on Polyline

Button	
Ribbon	none
Menu	SC Pipe > Utilities > Route on Polyline
Toolbar	Pipe > 
Command	SCPipePolyRoute



Creates a bent pipe and routes it along an existing AutoCAD polyline.

SC Pipe > Utilities > Cut to Max Length


Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Utilities > Cut to Max Length
Toolbar	None
Command	SCPipeCutToMaxLen
Permissions ...	None
Procedure	Cut to Maximum Length (page 125)

Automatically cuts all straights and bents to their maximum allowed length.

SC Pipe > Utilities > Extract Center Line


Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Utilities > Extract Center Line
Toolbar	Distributed Systems Utilities > 
Command	SCHEPEXTRACTCENTERLINE
Permissions ...	None
Procedure	Extract Center Line (page 125)

Extracts the centerlines from the selected parts and creates block references containing the segments of the centerlines and dashed lines to the corner points. The segments are placed on the SCCENTERLINES layer and the corner lines use the line style ACAD_ISO02W100.




Bent duct with extracted centerline moved for display

SC Pipe > Pipe-UCS Intersection > Add Pipe-UCS Intersection

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Pipe-UCS Intersection > Add Pipe-UCS Intersection
Toolbar	None
Command	SCPipeUCSIntersection
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Add Pipe-UCS Intersection (page 143)


Creates an intersection point where a selected pipe end and the current UCS intersect and draws a line between the intersection point and the pipe end.

SC Pipe > Pipe-UCS Intersection > Toggle Highlight on all HEP-UCS Intersection

Button 
 Ribbon Pipe Modeling tab > Pipe Modeling Utilities
 Menu SC Pipe > Pipe-UCS Intersection > Toggle Highlight on all HEP-UCS Intersection
 Toolbar None
 Command SCHePUCSIntersectionHighlight
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Toggle UCS Intersection Line](#) (page 144)


Toggles displaying the dotted line between the UCS intersection point and the pipe end.

SC Pipe > Pipe-UCS Intersection > Erase HEP-UCS Intersection

Button 
 Ribbon Pipe Modeling tab > Pipe Modeling Utilities
 Menu SC Pipe > Pipe-UCS Intersection > Erase HEP-UCS Intersection
 Toolbar None
 Command SCPipeUcsIntersectionDelete
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Erase Pipe-UCS Intersection](#) (page 144)



Erases the UCS intersection on the selected end.

SC Pipe > Pipe-UCS Intersection > Erase All HEP-UCS Intersection

Button 
 Ribbon Pipe Modeling tab > Pipe Modeling Utilities
 Menu SC Pipe > Pipe-UCS Intersection > Erase All HEP-UCS Intersection
 Toolbar None
 Command SCHePUCSIntersectionDeleteAll
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Erase all Pipe-UCS Intersections](#) (page 144)



Erases all the UCS intersections in the current drawing.

SC Pipe > Connect

Button 
 Ribbon Pipe Modeling tab > Pipe Modeling Utilities
 Menu SC Pipe > Connect
 Toolbar Distributed Systems Utilities > 
 Command SCHEPCONNECT
 Permissions ... Pipe > Modeling > Pipe Models - Edit
 Procedure [Connect Pipes](#) (page 124)



Connects two pipes together.

SC Pipe > Disconnect

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Disconnect
Toolbar	Distributed Systems Utilities > 
Command	SCHEPDisconnectAll
Permissions ...	Pipe > Modeling > Pipe Models - Edit
Procedure	Disconnect Pipes (page 124)



Disconnects two or more pipes. This command leaves the pipes at their current locations but removes the logical connection between them.

SC Pipe > Break Pipe at Point

Button	
Ribbon	Pipe Modeling tab > Modeling Utilities
Menu	SC Pipe > Break Pipe at Point
Toolbar	Utilities > 
Command	SCBAP or Break
Procedure	Break a Pipe (page 124)



Anchors the selected part.

SC Pipe > Anchor Part

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Anchor Part
Toolbar	Distributed Systems Utilities > 
Command	SCANCHOR
Procedure	Anchor Pipes (page 113)



Anchors the selected part.

SC Pipe > Unanchor Part

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Unanchor Part
Toolbar	Distributed Systems Utilities > 
Command	SCUNANCHOR
Procedure	Unanchor a Pipe (page 114)



Unanchors the selected part.

SC Pipe > Lock Part

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Lock Part
Toolbar	Distributed Systems Utilities > 
Command	SCLOCK
Permissions ...	Pipe > Modeling > Pipe Models – Lock/Unlock
Procedure	Lock a Pipe (page 114)



Locks a part.

SC Pipe > Toggle Constrain Enforcement

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Toggle Constrain Enforcement
Toolbar	Distributed Systems Utilities > 
Command	SCCONSTRAINMODE
Permissions ...	Allow bent pipe creation without bending machine
Procedure	Toggle Constraining Mode (page 124)



Toggles the Constrain Enforcement mode.

SC Pipe > Unlock Part

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Unlock Part
Toolbar	Distributed Systems Utilities > 
Command	SCUNLOCK
Permissions ...	Pipe > Modeling > Pipe Parts – Lock/Unlock
Procedure	Lock a Pipe (page 114)



Unlocks a part.

SC Pipe > Toggle Transform Mode

Button	
Ribbon	Pipe Modeling tab > Pipe Modeling Utilities
Menu	SC Pipe > Toggle Transform Mode
Toolbar	Distributed Systems Utilities > 
Command	SCTRANSFORMMODE
Procedure	Toggle Transform Mode (page 115)



Toggles the transform mode.

SC Pipe > Pipe Options

Button 
 Ribbon Pipe Modeling tab > Drawing Options
 Menu SC Pipe > Pipe Options...
 Toolbar Pipe > 
 Command SCPIPEOPTIONS
 Procedure [Pipe Options](#) (page 255)


Opens the Pipe Options window. See [Pipe Options](#) (page 255).

SC Pipe > Insert Penetration

Button 
 Ribbon Pipe Modeling tab > Penetrations
 Menu SC Pipe > Insert Penetration
 Toolbar Penetrations > 
 Command SCPENCREATE
 Permissions ... Penetrations > Create Penetrations
 Procedure See the Penetrations manual for details on Penetrations.

Creates a Penetration.

SC Pipe > Change Connection Accessory Package

Button 
 Ribbon Pipe Modeling tab > Pipe Modeling Utilities
 Menu SC Pipe > Change Connection Accessory Package
 Toolbar None
 Command SCCHANGECONACCPKG
 Permissions ... Pipe > Modeling > Pipe Modeling - Edit
 Procedure [Change Connection Accessory Package](#) (page 126)

Changes the accessory package associated with a particular connection.

Individual Drawing Display Settings Commands

Set 'Centerline Color Index'

SCDwgOptionsPipeCenterlineColor

Set 'Show Centerline' [0: false, 1: true]

SCDwgOptionsPipeShowCenterline

Set 'Show Thickness' [0: false, 1: true]

SCDwgOptionsPipeShowWallThickness

Set 'Show Insulation' [0: false, 1: true]

SCDwgOptionsPipeShowInsulation

Set 'Draw Part Using Branch Color' [0: false, 1: true]

SCDwgOptionsPipeDrawPartUsingBranchColor

Set 'Draw Line Mode Icons' [0: false, 1: true]

SCDwgOptionsPipeDrawLineModelIcons

Set 'Draw Line Edges Min Size'

SCDwgOptionsPipeDrawEdgesMinSize

Set 'Draw Line Edges' [0: always, 1: above min size only, 2: never]

SCDwgOptionsPipeDrawEdges

Set 'Show Connections' [0: false, 1: true]

SCDwgOptionsPipeShowConnections

Set 'Local Connection Color Index'

SCDwgOptionsPipeLocalConnectionColor

Set 'Local Connection Size'

SCDwgOptionsPipeLocalConnectionSize

Set 'Remote Connection Color Index'

SCDwgOptionsPipeRemoteConnectionColor

Set 'Remote Connection Size'

SCDwgOptionsPipeRemoteConnectionSize

Set 'Show Free End Arrows' [0: false, 1: true]

SCDwgOptionsPipeShowFreeEndArrows

Set 'Free End Arrows Color Index'

SCDwgOptionsPipeFreeEndArrowsColor

Set 'Free End Arrows Size'

SCDwgOptionsPipeFreeEndArrowsSize

Set 'Show Spool Break' [0: false, 1: true]

SCDwgOptionsPipeShowSpoolBreak

Set 'Spool Break Color Indescx'

SCDwgOptionsPipeSpoolBreakColor

Set 'Spool Break Size'

SCDwgOptionsPipeSpoolBreakSize

Set 'Show No Spool Icon' [0: false, 1: true]
SCDwgOptionsPipeShowNoSpoolIcon

Set 'No Spool Icon Color Index'
SCDwgOptionsPipeNoSpoolIconColor

Set 'No Spool Icon Size'
SCDwgOptionsPipeNoSpoolIconSize

Set 'End Numbers Mode' [0: Fixed Size, 1: Scaled Size, 2: None]
SCDwgOptionsPipeEndNumbersMode

Set 'End Numbers Scaled To End Size'
SCDwgOptionsPipeEndNumbersScaledToEndSize

Set 'End Numbers Fixed Height On Screen'
SCDwgOptionsPipeEndNumbersFixedHeightOnScreen

Set 'Show Elbow Icon'
Set 'Show Elbow Icon' [0: false, 1: true]
SCDwgOptionsPipeSetShowElbowIcon

Set 'Elbow Icon Color'
Set 'Elbow Icon Color Index'
SCDwgOptionsPipeSetElbowIconColor



Set 'Elbow Icon Size'
Set 'Elbow Icon Size'
SCDwgOptionsPipeSetElbowIconSize

Set 'Show Green'
SCDwgOptionsPipeSetShowGreen

Set 'Green Color'
SCDwgOptionsPipeSetGreenColor

Shared HEP Commands

SCHEPTransferPartToDrawing

Button 
Ribbon none
Menu SC Pipe >Transfer Parts
Toolbar..... Penetrations > 
Command SCHEPTRANSFERPARTODRAWING
Permissions ... None
Procedure..... [Transfer parts to another drawing / unit](#) (page 127)

Transfers selected HEP parts from one drawing/unit to another drawing/unit.



SCHEPReplicateToDrawing

Ribbon none
 Menu none
 Toolbar none
 Command SCHEPREPLICATETODRAWING
 Permissions ... None
 Procedure [Copy parts to another drawing / unit](#) (page 127)

Copies selected HEP parts from one drawing/unit to another drawing/unit.



Supports & Hanger Commands

SC Supports & Hangers > New Hanger

Button 
 Ribbon Pipe Modeling tab > Supports and Hangers
 Menu SC Supports & Hangers > New Hanger
 Toolbar Supports and Hangers > 
 Command SCHANG
 Permissions ... Pipe > Hangers > Pipe Hangers – Insert/Edit
 Procedure Inserts a new hanger



Inserts a new hanger onto the selected hangable part.

SC Supports & Hangers > Name Hangers

Button 
 Ribbon Pipe Modeling tab > Supports and Hangers
 Menu SC Supports & Hangers > Name Hangers
 Toolbar Supports and Hangers > 
 Command SCNAMEHANGERS
 Permissions ... Pipe > Hangers > Pipe Hangers – Insert/Edit
 Procedure Renames hangers in order



Renames all the selected hangers in order based on the hangable parts they are attached to.

SC Supports & Hangers > Move Hanger to Drawing

Button 
 Ribbon Pipe Modeling tab > Supports and Hangers
 Menu SC Supports & Hangers > Move Hangers to Drawing
 Toolbar Supports and Hangers > 
 Command SCMOVEHANGERSTODWG
 Permissions ... Pipe > Hangers > Pipe Hangers – Insert/Edit
 Procedure Transfer hangers to another drawing / unit



Transfers selected hangers from one drawing/unit to another drawing/unit.

SC Supports & Hangers > Move Attached Hanger to Drawing

Button	
Ribbon	Pipe Modeling tab > Supports and Hangers
Menu	SC Supports & Hangers > Move Attached Hanger to Drawing
Toolbar	Supports and Hangers > 
Command	SCMOVEATTACHEDHANGERSTODWG
Permissions ...	Pipe > Hangers > Pipe Hanges – Insert/Edit
Procedure	Transfer hangers to the current drawing



Transfers all the hangers attached to the selected hangable to the current drawing.

SC Supports & Hangers > Insert Bare Support

Button	
Ribbon	Pipe Modeling tab > Supports and Hangers
Menu	SC Supports & Hangers > Insert Bare Support
Toolbar	Supports and Hangers > 
Command	SCBARESUPPORT
Permissions ...	Supports – Insert/Edit
Procedure	Inserts a new bare support



Inserts a new support that is not attached to any hangable parts

SC Supports & Hangers > Insert Auto Support

Button	
Ribbon	Pipe Modeling tab > Supports and Hangers
Menu	SC Supports & Hangers > Insert Auto Support
Toolbar	Supports and Hangers > 
Command	SCAUTOSUPPORTT
Permissions ...	Distributed Systems Supports > Supports – Insert/Edit
Procedure	Creates a new T auto support part



Creates a new T type support attached to the selected hangable parts.

SC Supports & Hangers > Insert LF Auto Support

Button	
Ribbon	Pipe Modeling tab > Supports and Hangers
Menu	SC Supports & Hangers > Insert LF Auto Support
Toolbar	Supports and Hangers > 
Command	SCAUTOSUPPORTLF
Permissions ...	Distributed Systems Supports > Supports – Insert/Edit
Procedure	Creates a new LF auto support part



Creates a new LF type support attached to the selected hangable parts.

SC Supports & Hangers > Insert I Auto Support

Button 
 Ribbon Pipe Modeling tab > Supports and Hangers
 Menu SC Supports & Hangers > Insert I Auto Support
 Toolbar Supports and Hangers > 
 Command SCAUTOSUPPORTI
 Permissions ... Distributed Systems Supports > Supports – Insert/Edit
 Procedure Creates a new I auto support part



Creates a new I type support attached to the selected hangable parts.

SC Supports & Hangers > Insert TN Auto Support

Button 
 Ribbon Pipe Modeling tab > Supports and Hangers
 Menu SC Supports & Hangers > Insert TN Auto Support
 Toolbar Supports and Hangers > 
 Command SCAUTOSUPPORTTN
 Permissions ... Distributed Systems Supports > Supports – Insert/Edit
 Procedure Creates a new Two by N auto support part



Creates a new Two by N type support attached to the selected hangable parts.

SC Supports & Hangers > Insert MN Auto Support

Button 
 Ribbon Pipe Modeling tab > Supports and Hangers
 Menu SC Supports & Hangers > Insert MN Auto Support
 Toolbar Supports and Hangers > 
 Command SCAUTOSUPPORT
 Permissions ... Distributed Systems Supports > Supports – Insert/Edit
 Procedure Creates a new M by N auto support part



Creates a new M by N type support attached to the selected hangable parts.

SC Supports & Hangers > Attach Pipes to Support

Button 
 Ribbon Pipe Modeling tab > Supports and Hangers
 Menu SC Supports & Hangers > Attach Pipes to Support
 Toolbar Supports and Hangers > 
 Command SCATTACHPIPESTOSUPPORT
 Permissions ... Distributed Systems Supports > Supports – Insert/Edit
 Procedure Attaches pipes to supports



Attaches selected pipes to the selected supports with hangers.

SC Supports & Hangers > Transfer Supports to Drawing

Button 
 Ribbon Pipe Modeling tab > Supports and Hangers
 Menu SC Supports & Hangers > Transfer Supports to Drawing
 Toolbar Supports and Hangers > 
 Command SCMOVESUPPORTSTODWG
 Permissions ... Distributed Systems Supports > Supports – Insert/Edit
 Procedure Moves supports to a different drawing/unit



Moves the selected supports and attached hangers from one drawing/unit to another drawing/unit

SC Supports & Hangers > Name Supports In Order

Button 
 Ribbon Pipe Modeling tab > Supports and Hangers
 Menu SC Supports & Hangers > Name Supports In Order
 Toolbar Supports and Hangers > 
 Command SCNAMESUPPORTS
 Permissions ... Distributed Systems Supports > Supports – Insert/Edit
 Procedure [Name Hangers](#) (page 153)



Renames the selected supports in order based on connected hangable parts.

SC Supports & Hangers > Copy Supports Along Supported Parts

Button 
 Ribbon Pipe Modeling tab > Supports and Hangers
 Menu SC Supports & Hangers > Copy Supports Along Supported Parts
 Toolbar Supports and Hangers > 
 Command SCCOPYSUPPORTSWITHSUPPORTEDOBJECTS
 Permissions ... Distributed Systems Supports > Supports – Insert/Edit

Copies the selected support and places the new copied support to the selected point on the same hangable parts with the same hangers.

SC Supports & Hangers > Hanger and Support Drawing Options


Button 
 Ribbon Pipe Modeling tab > Drawing Options
 Menu SC Supports & Hangers > Hanger and Support Drawing Options
 Toolbar Supports and Hangers > 
 Command SCHANGDWGOPTIONS
 Permissions ... None
 Procedure [Display Options for Hangers](#) (page 145)

Displays the Support & Hanger Drawing Options.

Appendix B: Pipe Modeling Reference

Pipe Navigator Page

The Pipe Navigator page lets you create, open, and modify Pipe model drawings and Pipe arrangement drawings belonging to the registered unit. From Navigator (ShipConstructor > Navigator), choose Pipe.



Open

Opens the selected Pipe model drawing or Pipe arrangement drawing. If you check the box Read Only, you will not be able to modify or save changes to the drawing.

New Piping

Permissions ... Pipe > Modeling > Pipe Models – Create/Delete

Creates a new Pipe model drawing as long as the Piping folder was selected.

New Arrangement

Permissions ... Pipe > Pipe Arrangement – Create/Delete

Creates a new Pipe arrangement drawing as long as the Arrangement folder was selected.

Show Out of Date

Permissions ... None

Shows a warning icon beside all production drawings that are out of date. A production drawing becomes out of date when a part in a model drawing has been modified and that part is used in the production drawing.

Note: Clicking Show Out of Date may cause Navigator to take awhile to refresh the icons, as Navigator has to go through all the production drawings in your database.

Right-Click Menu

Open
New
Rename
Delete

Rename

Permissions ... Pipe > Modeling > Pipe Models - Edit

Lets you rename the selected Pipe drawing.


Delete

Permissions ... Pipe > Modeling > Pipe Models – Create/Delete

Deletes the selected Pipe drawing.

Pipe Spool Navigator Page

The Pipe Spool Navigator page lets you create, open, and modify Pipe spool drawings belonging to the registered unit. From Navigator (ShipConstructor > Navigator), choose Pipe Spool.



Open

Permissions ... Pipe > Spools > Spool Drawings – Edit

Opens the selected Pipe spool drawing. If you check the box Read Only, you will not be able to modify or save changes to the drawing.


Create

Permissions ... Pipe > Spools > Spool Drawings – Create/Delete

Creates one or more Pipe spool drawings based on the Pipe models defined in the current project.

Reattach Drawing

Permissions ... Pipe > Spools > Spool Drawings – Edit

Reattaches an existing drawing that was detached and moved to the Deleted_Spool_Drawings folder. This scenario can commonly happen as a result of adding spool breaks. The selected drawing is checked to ensure it is a Pipe spool drawing. The spool in the Navigator must not have a drawing to be able to use the Reattach drawing command (shown with the spool icon ).

Right-Click Menu



Delete

Permissions ... Pipe > Spools > Spool Drawings – Create/Delete

Deletes the selected Pipe spool drawing.

Lock/Unlock Spool

Permissions ... Pipe > Spools> Pipe Spools – Lock / Unlock

Locks or unlocks the selected Pipe spool (and its drawing).

Model Drawing Right-Click Menu

Open

Lock/Unlock Spools

Lock/Unlock Spools

Permissions ... Pipe > Spools> Pipe Spools – Lock / Unlock

Locks or unlocks all the approved Pipe spools (and their drawings) in the selected Pipe model drawing.

System Manager

System Manager

Pipe System

<Pipe Spec 1>

New Pipe System2

New Pipe Branch3

Level	Branch
Finish	
Insulation	1 - Adhesive/Solvent (System) 2 - Thermal/Self Adhesive (Branch)
Color	Red
Class	
Test Method	
Test Pressure (kPa)	0
Density	1
Parts Using System	1

New Branch

Delete

OK

Cancel

Finish
The finishes that will be applied to pipes in the selected system.

Insulation
The insulation that will be applied to pipes in the selected system.

Color
The color that pipes belonging to this system will appear.

Class
The class field on a system provides a means of associating all pipes within the system to a certain classification.

Test Method
Enter a string field here based on what method you will use for testing.

Test Pressure (kPa)

Enter a specific value in either pounds per square inch (psi) or kilopascals (kPa).


Density

The density of the pipe affects the wet weight (relative density multiplied by the weight of water). The density is entered based on each application and is entered on a branch or system level.

Pipe Options

SC Pipe > Pipe Options opens the Pipe Drawing Options window.

The Display Tab



General Display

Show Centerline

When checked, displays a line along the center of each pipe.

- Color – You can change the color of the centerline.

Note: When plotting shaded viewports, centerlines are projected in front of the part geometry such that they are easily visible.

Show Wall Thickness

When this option is checked, the pipes will accurately show their wall thickness. Unchecking this option may improve display performance.

Show Insulation

When this option is checked, the pipes display all insulations that have been applied to them. Unchecking this option may improve display performance.


Draw Part Using Branch Color

Uses the pipe's branch (system) color for display. If this option is unchecked, the pipe uses its AutoCAD color. If you want to organize your pipe colors by layer instead of system, uncheck this option, set all your pipes to use ByLayer coloring and apply the correct color to the layers that the pipes reside on. It is very useful to color parts by system in your model drawings and to color them by layer in production drawings.

End Numbers

End numbers can show up on a pipe when the mouse is hovering over the pipe. They label which end is which. This is very useful when trying to place a pipe.

- Scaled To End Size – When selected, will scale the end numbers relative to the size of the pipe's end by the amount entered.
- Fixed Height On Screen – When selected, will show the end numbers at a fixed height according to the value entered.
- None – When selected, will not display the end numbers.



The same pipe showing scaled end numbers (left) and fixed height end numbers (right).

2D/3D Wireframe Display

Draw Line Mode Icons

When checked, will display the line mode icons that are associated with the pipe's end treatments.

Override Stock

When checked the linemode icons displayed can be overridden by clicking the Edit Icon Sizes button. This checkbox is only available if the Draw Line Mode Icons is checked.

Edit Icon Sizes

When clicked the LineMode Icon dialog will be displayed and allow the user to select how they would like to override the linemode icons being displayed in the current drawing. This button is only available if the Draw Line Mode Icons is checked.

Double Line Display

Defines whether the solid is drawn for pipe parts. Parts with a profile smaller than the specified value if using the 'For Profiles Smaller Than' option or all parts if 'Never' is chosen will be drawn in a single line display and show in the part color, not the centerline color.


Note: Pipe and HVAC rendering has changed significantly since older versions of ShipConstructor 2006/2008. Instead of the old edge style options, edge style is now controlled by the AutoCAD system variables (similar to AutoCAD solids). See the ISOLINES and DISPSILH variables. Also, Pipe/HVAC models now obey AutoCAD's adaptive degradation and level of detail settings (See the native AutoCAD display options).


Connections

These are options that are related to connections.

Show Connections

Displays geometry at all connected pipe ends. A small circle is used in 2D linemode, and a line surrounding the connection in combination with small mesh covering the connection gap is used in all other shademodes.





Local Connection Color

Option to set the color and size of a local connection

- Color – You can change the color of the connection symbol.
- Size – You can change the size of the symbol. A default size of 0 indicates automatic sizing.

Remote Connection Color

Option to set the color and size of a remote connection.

- Color – You can change the color of the connection symbol.
- Size – You can change the size of the symbol. A default size of 0 indicates automatic sizing.

Show Free End Arrows


When checked, displays an arrow pointing at all free pipe ends.

- Color – You can change the color of the free end arrow.
- Size – You can change the size of the arrow. A default size of 0 indicates automatic sizing.

Spool

Show Spool Break

When checked, displays a large spoked circle at each spool break.



- Color – You can change the color of the spool break symbol.
- Size – You can change the size of the symbol. The default size of 0 indicates automatic sizing.

Show No-Spool Icon


When checked, displays a small cross at the center of each pipe that is a No Spool item.

- Color – You can change the color of the no spool icon.
- Size – You can change the size of the icon. A default size of 0 indicates automatic sizing.

Show Elbow Corner Icon

When checked, displays a small elbow icon along the tangents of each elbow part.


- Color – You can change the color of the elbow corner icon.
- Size – You can change the size of the icon. A default size of 0 indicates automatic sizing.



Restore Defaults

The restore defaults button, when clicked, will change all the display settings back to the original default values.

The NavAid Tab



Radius


Controls the size of the NavAid.

- 2x Pipe Diameter – The NavAid becomes twice the size of the pipe's diameter.
- Static Radius – The NavAid's radius is set to a constant value that you provide.

Snap

When checked, snaps the NavAid to angles based on the Tolerance and Increment settings.

- Tolerance – Controls the size of the snap zone. For example, if the Tolerance is 15 degrees, then the snap zone is 15 degrees to either side of a snap point (as in the image below).




- **Increment** – The angle between each successive snap point. Snap points appear as spikes on the NavAid. For example, if the Increment is 45 degrees, then the NavAid will have eight spikes (as in the image above).

Text

- **Relative to Screen Size** – NavAid text has a constant size relative to the screen, regardless of zoom level.
- **1/3 Pipe Dimension** – NavAid text is 1/3 the size of the pipe's diameter.

The Transform Tab



Anchors

Show Anchors

When checked, will display the anchor symbol to indicate anchored pipes.

Color

The color of the anchor symbol.

Size

- Relative to Part – The size of the anchor symbol is relative to the part.
- Fixed – The size of the anchor symbol is statically defined by you, entered in the Size field.

Anchored Points

When performing a multipart transform, an octagon-like icon is displayed at points beyond which the transform cannot affect. For example the icon is drawn where the transform is restricted by an anchored or locked part, or a part on a locked layer, etc.

Color

The color of the anchored point symbol.

Size

- Relative to Part – The size of the anchored point symbol is relative to the part.
- Fixed – The size of the anchor symbol is statically defined by you, entered in the Size field.

Locks

Show Locks

When checked, will show the lock symbol for pipes that are locked.

Color

The color of the lock symbol.

Size


- Relative to Part – The size of the lock symbol is relative to the part.
- Fixed – The size of the lock symbol is statically defined by you, entered in the Size field.

Split and Merge

Override Color for Split Part

When checked, split pipes are drawn in the selected color instead of the default split color.

The Routing Tab



Flow Direction

Show Flow Direction

When checked, will display the flow direction symbol on all bent pipes if their individual "Show Flow Direction" flag is set.

Show All

When checked, will display the flow direction symbol on all bent pipes regardless of whether or not their individual "Show Flow Direction" flag is set.


Color

The color of the flow direction symbol.

Size

The size of the flow direction symbol is statically defined by you, entered in the Size field.

The Behavior Tab



Stock Length Enforcement

Automatically cut to stock length

When selected, automatically cuts parts that exceed their stock's maximum length to that stock's maximum length.

Ask before cutting to stock length

When selected, you will be prompted before a part is cut to its stock's maximum length.


Never cut to stock length

When selected, parts will never be cut to their stock's length.

Create warning labels for items exceeding stock length on drawing save

When checked, labels will be displayed on pipes that are greater than their max length, unless the "Don't Show Max Length Warning" is set on the part.

The Constraints Tab



Bender Constraints


Highlight Violating Segments

When checked, bent pipe segments that violate bender constraints will be highlighted with the specified color. This is a per-drawing setting and is on by default..

Stock Selection Window Reference

The Stock Selection window appears when:

- Trying to insert a part of a certain type for the first time
- You select 'S' while inserting a pipe
- Trying to connect one pipe to another and the pipe you are trying to connect to cannot connect.
This can happen if you have not defined a connection for the type of ends you are trying to connect.



Apply Filter Button

This will apply all filters that you have defined in the Filter Row and the 'hidden' filter that is created if you had selected a connection using the Connects To... button.

Clear Filter Button

Will clear all filters that you have defined in the Filter Row, and it will temporarily disable the 'hidden' filter created if you had selected a connection using the Connects To... button.

The Filter Row


This is the empty row that is located just below the column headings. To use this filter, simply type in the string you would like to filter by under the correct column and click the Apply Filter button. The filter, when applied, will show only those stocks that match the string typed in for that specific column. The filter strings are remembered between sessions.

Connects To... Button

Click on this button when you want to filter all the stocks listed by an end that you could connect to. Once you click this button, you will be prompted to select an end. Once the end is selected, the list will be filtered based on if the stock shown can connect to the end selected.

Required Custom Attributes Reference

After routing the pipe if there are any required custom attributes or catalogs are assigned to the stock used the catalog and custom attributes for this part much be set. ShipConstructor will attempt to do this automatically. If there one catalog assigned to the stock it will be chosen for the part, and if all the stocks are set to be "Deferred by Default" or have been given a default value, they will be set to the default. If ShipConstructor cannot set all these values automatically the dialog below will be shown. This dialog will allow users to enter in the custom attributes and will abort the parts routing if it is cancelled. Using the arrows to select items in a drop down and enter to move to the next non-deferred attribute and the OK button after all attributes have been entered, the user can quickly enter all the values using only the keyboard.




Insulation Reference

Insulation on a pipe can be defined on a system, spool and on individual parts.

While laying down a pipe, there is an option on the command line to select insulation (see [Straight Pipe](#) (page 93) or [Bent Pipe](#) (page 94)), or while in a pipe drawing you can right-click on a part and choose Change Insulation.... This will bring up the Select Insulation window where you can select additional insulation to apply to the part or change the order of the selected insulation. By un-checking the box Inherit from System (or Inherit from Spool if your part is spooled), the existing insulation will be pre-selected and you are free to change the insulation for the part.

Note: The stock's insulation will not be shown in the insulation window while selecting insulation for a part or a system.

When defining insulation for a pipe, order matters. Please double check the order of the selected insulation. The order of the insulation applied to the pipe may show up in reports or BOMs.



Available Insulations
A list that contains the available insulation that has been defined in the library setup.

Selected Insulations

An ordered list that contains all the insulations that will be applied to the pipe.

Inherit from System (Inherit from Spool)

A box indicating whether to inherit the insulations from the system the part belongs to.

To apply an insulation

1. Select an insulation from the available list.
2. Click the right arrow.

To unselect an insulation

1. Select an insulation from the selected list.
2. Click the left arrow.

To change the order of the selected insulation

1. Select an insulation from the selected list.
2. Click the up or down arrows as necessary.

Finishes Reference


Finishes on a pipe can be defined at many levels. Finishes can be applied to a system, a branch, a spool, a hierarchy, and a part.

When defining a system or a branch in a pipe drawing, you can select finishes to be applied to that system or branch in the System Manager. See [Create a System](#) (page 82) or [Create a Branch](#) (page 83) for more details on how to set up a system or branch. For example, when finishes are selected for a system, this means that all the parts belonging to the system will have these finishes applied.

Finishes selected for a hierarchy are last in the order of selected finishes for a part. This is so you can apply a finish to an entire hierarchy level of parts as a last step.

In a part, finishes from the system can be overridden. If you do not want your part to have any of the systems or branches finishes, simply uncheck the box Inherit from System and remove all the finishes.

At any time you can see which finishes are applied to a part by right-clicking on the part and choosing Change Finishes.... This brings up the Select Finishes window.



Available Finishes

A list that contains the available finishes that has been defined in the library setup.

Selected Finishes

An ordered list that contains all the finishes that will be applied to the pipe.

Inherit from System

A box indicating whether to inherit the finishes from the system the part belongs to. To override the finishes for a part, this box must be unchecked.

Inherit From Hierarchy

A box indicating whether the finishes from the hierarchy the part belongs to will be inherited.

To apply a finish

1. Select a finish from the available list.
2. Click the right arrow.


To unselect a finish

1. Select a finish from the selected list.
2. Click the left arrow.

To change the order of the selected finish

1. Select a finish from the selected list.
2. Click the up or down arrows as necessary.

Pipe Part Right-Click Menu



Anchor

When selected, this option anchors the part. This means that the part stays where it is during a move command. This part will stay where it is even if it is connected to another part and all the parts are selected during a transformation. See [Single-Part Transforms](#) (page 115), [Multi-Part Transforms](#) (page 117) and [Anchor Pipes](#) (page 113) for more information.

Lock

When selected, will lock a part. This part will not be able to change.

Disconnect

This command disconnects the part from everything.

Change Stock...

Note: This command is not yet available in ShipConstructor.

This command lets you change the standard that the part belongs to.

Change Insulation...

Use this command to change the insulation on the part or to view the insulation that is applied to the part. See [Insulation Reference](#) (page 268) for more details.

Change Finish...

This command lets you change the finishes for the part, or the command lets you view all the finishes applied to the part. See [Finishes Reference](#) (page 269) for more details.

Extract Center Lines

This command will extract the center line from the selected part.

Merge To Bent

This command will merge a selection of pipe parts into a single bent pipe.

Show Flow Direction

Use this command to toggle the visibility of the parts flow direction arrow.

Switch Flow Direction

Use this command to toggle the flow direction of the entire pipe run, up to a branch.

Rotate Line Mode Icon

This command will rotate the line mode icons of this part by 90 degrees.

Set Line Mode Icon Size


Running this command will give you command line options to change the size of the individual parts line mode icons.

Don't Show Max Length Warning

This command will toggle the visibility of max length warnings if they are enabled in the pipe drawing options and the part is over the max length.

Select UCS Options Reference

The Select UCS Options window is an interactive window that will help you to see exactly how your new UCS will be.



UCS Plane

Depending on the part selected, and what end you are currently on, there will be different choices for the UCS Plane. The choices for the UCS Plane that could show up are as follows:

- Deck Plane – Working plane will be in the Deck plane.
- Deck Like Plane – Working plane will be in a plane that is close to the Deck plane, but not exactly in the Deck plane. This is because the part end selected is not aligned exactly to the Deck plane.
- Frame Plane – Working plane will be in the Frame plane.
- Frame Like Plane – Working plane will be in a plane that is close to the Frame plane, but not exactly in the Frame plane. This is because the part end selected is not aligned exactly to the Frame plane.
- LGBH Plane – Working plane will be in the LGBH plane.
- LGBH Like Plane – Working plane will be in a plane that is close to the LGBH plane, but not exactly in the LGBH plane. This is because the part end selected is not aligned exactly to the LGBH plane.

- **Pick 3rd Point for Plane** – This option enables you to create an arbitrary plane based on the alignment of the part and the point that you pick. When this option is selected, you will be prompted to pick a point.

UCS Origin Point


This option selects your UCS origin point.

- **Part Point** – Point on the part. The points are at the ends of the part. If there are multiple part points, you can click on the Toggle button to toggle through the list of points.
- **Origin** – Selecting this option will give you a UCS Origin at (0,0,0).

On the part itself, there is a mock plane to enable you to see where your working plane will be. You can use AutoCAD's orbit command to adjust your view of the mock plane if need be. This working plane automatically adjusts as you select different planes or toggle through the different points.

Scenario Wizard Dialog

When new pipe parts need to be inserted when using any of the new functionality and there are multiples solutions for the simplest possible scenario then the Scenario Wizard dialog is shown. The wizard has 3 modes depending on how it was initialized; insert connectors, insert same size fitting, insert different size fitting. The image below shows an example where a user wanted to insert an 8" lateral into a 6" run of pipe.



The main grid initially shows you the partial solution made up of all the items that are the same in all possible solutions for the simplest scenario that has a solution. You can switch to any of the possible solutions by pressing the arrow buttons below the grid. The columns of this grid are described below:

- **Name** – The two bounding parts are the ones that are having the parts inserted between. The white rows list the stock name to be used. Selecting this cell will allow you select a stock for this item, if you are on the partial solution,

by clicking the ellipsis button. The green rows are the allowable connections. Selecting this cell will allow you select an allowable connection for this item, if you are on the partial solution, by clicking the ellipsis button.

- **Switch Ends** – This column shows the orientation of the item by end handle from left to right as shown in the preview at the top of the dialog. You can rotate the ends by pressing the ellipsis button if you are viewing the partial solution.
- **End 1** – shows the end treatment on the left end of the stock or allowable connection.
- **End 2** – shows the end treatment on the right end of the stock or allowable connection.
- **Gap** – shows the connection gap for allowable connections.
- **Accessory Package** – shows the Accessory Package for allowable connections.

The top of the dialog shows a diagram laying out the current scenario type that is selected.

The scenario type drop down allows you to switch to solutions that contain more parts. You can select simpler scenarios than the one that is initially selected, but they will not have any possible solutions.

The connector type drop down displays which connector type will be used when selecting a connector stock via the ellipsis button in the name column.

The clear button removes all stocks and allowable connections from partial solutions. If you are inserting a fitting then it will remain.


The solution selector, which is the number field and arrow buttons below the grid, allows you to switch between all the possible solutions and the partial solution. You can do this by pressing the buttons to move one forward or back, skipping to the first or last, or by entering a number in the field.

With a valid and complete solution shown in the grid you can press enter to apply it to the model.

Hangar Stock Selection Window Reference

The Hangar Stock Selection window appears when:


- Trying to insert a hanger for the first time
- You select 'C' while inserting a hanger
- When hanging a pipe part that has a different nominal size or different material than what has been previously hung.



The column on the left will display all the different types of hangers that have valid hangers based on the pipe that was selected to be hung. Selecting a hanger type in the left column will display all the valid hangers of the selected type in the right column. Select the appropriate hanger stock and click OK to place the hanger on the pipe.

Hanger & Support Drawing Options

The hanger drawing options controls how the hangers are displayed in the current drawing.



Hangers

Hanger Display

- Show Hanger 2D Geom – Displays the 2 dimensional representation of the hanger
- Show Hanger 3D Geom – Displays the 3 dimensional representation of the hanger

Color

- Global Hanger Color – Displays all hangers using the selected color.
- Use Pipe System Color – The hangers are displayed using the same color as the system of the pipe they are attached to.
- Use Individual Colors – The hangers are displayed with the color specified in the OPM.

Supports

Support Display

- Show Support 2D Geom – Displays the 2 dimensional representation of the support.
- Show Support 3D Geom – Displays the 3 dimensional representation of the support.

Radius


Controls the size of the NavAid.

- 2x Profile Diameter – The NavAid becomes twice the size of the vertical profiles web length.
- Static Radius – The NavAid's radius is set to a constant value that you provide.

Snap

When checked, snaps the NavAid to angles based on the Tolerance and Increment settings.

- Tolerance – Controls the size of the snap zone. For example, if the Tolerance is 15 degrees, then the snap zone is 15 degrees to either side of a snap point (as in the image below).




- Increment – The angle between each successive snap point. Snap points appear as spikes on the NavAid. For example, if the Increment is 45 degrees, then the NavAid will have eight spikes (as in the image above).

Support Template Selection Window Reference

The Support Template Selection window appears when:

- Trying to insert a support for the first time
- You select 'C' while inserting as support



The column on the left will display all the different types of supports that are valid based on the command run and the hangable parts selected.. Selecting a support type in the left column will display all the valid supports of the selected type in the right column. Select the appropriate support template stock, hangers and click OK to place the support.

Appendix C: Pipe Production Command Reference

Toolbars

The most common commands are located on the Pipe toolbars.

Spool Toolbar



Rotate Dimension

See [SC Spool Drawing > Rotate Dimension](#) (page 287)



Re-dimension Spools

See [SC Spool Drawing > Re-Dimension](#) (page 287)



Insert Orientation Icon

See [SC Spool Drawing > Orientation Icon](#) (page 288)

SC Arrangement Menu

The SC Arrangement menu appears in arrangement drawings.

SC Arrangement > Update Drawing

Menu	SC Arrangement > Update Drawing
Toolbar	None
Command	SCUPDATEDWG
Permissions ...	Pipe > Pipe Arrangements - Edit
Procedure	Update Arrangement Drawings (page 193)

Update an arrangement drawing with the latest geometry from the model drawings, or change the sources of which the arrangement drawing is composed of.

SC Arrangement > Silent Update Drawing

Menu	None
Toolbar	None
Command	-SCUPDATEDWGSILENT
Permissions ...	Pipe > Pipe Arrangements - Edit
Procedure	Update Arrangement Drawings (page 193)

Update an arrangement drawing with the latest geometry from the model drawings without requesting user input.

SC Arrangement > Insert Keywords

Menu SC Arrangement > Insert Keywords
 Toolbar None
 Command SCINSERTKEYWORD
 Permissions ... Pipe > Pipe Arrangements - Edit
 Procedure [Arrangement Drawing Keywords](#) (page 186)


Inserts keywords into the drawing.

SC Arrangement > Update All Keywords

Menu SC Arrangement > Update All Keywords
 Toolbar None
 Command SCUPDATEALLKEYWORDS
 Permissions ... Pipe > Pipe Arrangements - Edit
 Procedure [Update All Keywords](#) (page 202)


Updates all keywords in paper space in the drawing.

SC Arrangement > Pipe Drawing Options

Menu SC Arrangement > Pipe Drawing Options
 Toolbar Pipe > 
 Command SCDWGOPTIONSPIPE
 Permissions ... None
 Procedure [Pipe Options](#) (page 255)


Displays the pipe drawing options.

SC Arrangement > HVAC Drawing Options

Menu SC Arrangement > HVAC Drawing Options
 Toolbar HVAC > 
 Command SCDWGOPTIONSHVAC
 Permissions ... None
 Procedure See the HVAC manual for details.

Displays the HVAC drawing options.

SC Arrangement > Equipment Drawing Options

Menu SC Arrangement > Equipment Drawing Options
 Toolbar Equipment > 
 Command SCDWGOPTIONSEQUIP
 Permissions ... None
 Procedure See the Equipment manual for details.

Displays the Equipment drawing options.

SC Arrangement > Viewport Options

Menu SC Arrangement > Viewport Options
 Toolbar None
 Command SCVPORTOPTIONS
 Permissions ... None
 Procedure [Viewport Options](#) (page 201)

Display the options for a specific viewport.

SC Arrangement > Set Viewport Display Options

Menu SC Arrangement > Set Viewport Display Options
 Toolbar None
 Command SCVIEWPORTDISOPTIONS
 Permissions ... None
 Procedure [Viewport Display Options](#) (page 202)

Configure the viewport specific display options for a specific viewport.

SC Arrangement > Insert BOM Table

Menu SC Arrangement > Insert BOM Table
 Toolbar None
 Command SCINSERTBOM
 Permissions ... Pipe > Pipe Arrangements - Edit
 Procedure [Insert a New Empty Arrangement BOM Table](#) (page 184)

Inserts a BOM table.

SC Arrangement > Update BOMs

Menu SC Arrangement > Update BOMs
 Toolbar None
 Command SCUPDATEBOMS
 Permissions ... Pipe > Pipe Arrangements - Edit
 Procedure [Update BOMs](#) (page 201)

Updates the BOM Table.

SC Arrangement > Edit Collector Options

Menu SC Arrangement > Edit Collector Options
 Toolbar None
 Command SCTWEAKBOMOPTIONS
 Permissions ... Pipe > Arrangements - Edit
 Procedure [Edit BOM Collector Options](#) (page 202)

Allows the user to change the BOM Collector options.

SC Arrangement > Toggle List Only Visible

Menu	SC Arrangement > Toggle List Only Visible
Toolbar	None
Command	SCTOGGLELISTVISIBLE
Permissions ...	Pipe > Pipe Arrangements - Edit
Procedure	List only Visible (page 202)

Toggles the variable in the BOM to list only those parts visible or not.


SC Arrangement > Label > Manual Label from BOM

Menu	SC Arrangement > Label > Manual Label from BOM
Toolbar	Assembly > 
Command	SCLABELMANUAL
Permissions ...	None
Procedure	Manual Labeling from BOM (page 198)

Let's you manually label parts from a BOM. This is an alternative method to automatic labeling. The label style and text contents are used from the selected BOM. The selection of the leader arrow is the pickpoint where you selected the part. The number of leader segments follows the label style setting.

This command can be used in conjunction with Copy Label from BOM so complete the labeling. If you select a part that has been previously labeled then the previous label is removed.

SC Arrangement > Label > Copy Label from BOM

Menu	SC Arrangement > Label > Copy Label from BOM
Toolbar	Assembly > 
Command	SCLABELCOPY
Permissions ...	None
Procedure	Manual Labeling from BOM (page 198)

Let's you create labels that are copies of an existing label with the contents changed to reflect the first BOM column of the selected part. The copied label will be created with the label text and styles from the BOM table and geometry information from the source label.

SC Arrangement > Label > Relabel All

Menu	SC Arrangement > Label > Relabel All
Toolbar	None
Command	SCRELABELALL
Permissions ...	Pipe > Pipe Arrangements - Edit
Procedure	Relabel All (page 198)

Generates labels for all new BOM items and places them on the _ANNOTATION layer.

Labels are generated only once. Subsequent commands only update the label text to reflect the Bill of Materials.

Even though labels are placed in Paper Space, they now track the objects in Model Space so that if the user pans, zooms, or orbits in the viewport, the labels track accordingly and remain synchronized to the objects that they represent.

SC Arrangement > Label > Relabel from BOM

Menu SC Arrangement > Label > Relabel from BOM
 Toolbar None
 Command SCRELABELFROMBOM
 Permissions ... Pipe > Pipe Arrangements - Edit
 Procedure [Relabel from a selected BOM](#) (page 198)

Relabels parts from a selected BOM and places them on the _ANNOTATION layer.

Labels are generated only once. Subsequent commands only update the label text to reflect the Bill of Materials.


Even though labels are placed in Paper Space, they now track the objects in Model Space so that if the user pans, zooms, or orbits in the viewport, the labels track accordingly and remain synchronized to the objects that they represent.

SC Arrangement > Label > Relabel from Parts

Menu SC Arrangement > Label > Relabel from Parts
 Toolbar None
 Command SCRELABELFROMPARTS
 Permissions ... Pipe > Pipe Arrangements - Edit
 Procedure [Relabel from Parts](#) (page 199)


Relabels selected parts from the BOMs.

SC Arrangement > Label > Label on Visible Edge On/Off

Button 
 Ribbon Production tab > Labeling panel > Label on Visible Edge On/Off
 Menu SC Arrangement > Label > Label on Visible Edge On/Off
 Toolbar None
 Command SCLABELONVISIBLEEDGE
 Permissions ... Pipe > Pipe Arrangements - Edit
 Procedure [Label on Visible Edge On/Off](#) (page 199)


Turns labels automatic label generation from label to piecemark to label on visible part edge.

SC Arrangement > Label > Curved Plates in Visible Edge Detection On/Off

Button 
 Ribbon Production tab > Labeling panel > Curved Plates in Visible Edge Detection On/Off
 Menu SC Arrangement > Label > Curved Plates in Visible Edge Detection On/Off
 Toolbar None
 Command SCLABELREMOVECURVEDPLATEHLR
 Permissions ... Pipe > Pipe Arrangements - Edit
 Procedure [Curved Plates in Visible Edge Detection On/Off](#) (page 199)


Turns on option to include curved plates in hidden line calculation when label on visible part edge is on.

SC Arrangement > Label > Adjacent Part Edge Tolerance

Button	
Ribbon	Production tab > Labeling panel > Adjacent Part Edge Tolerance
Menu	SC Arrangement > Label > Adjacent Part Edge Tolerance
Toolbar	None
Command	SCLABELADJACENTTOL
Permissions ...	Pipe > Pipe Arrangements - Edit
Procedure	Adjacent Part Edge Tolerance (page 199)


Edges will be less likely to be labeled if they are closer than this distance to an edge of another part.

SC Arrangement > Label > Edge Length Filter

Button	
Ribbon	Production tab > Labeling panel > Edge Length Filter
Menu	SC Arrangement > Label > Edge Length Filter
Toolbar	None
Command	SCLABELEDGELENGTHFILTER
Permissions ...	Pipe > Pipe Arrangements - Edit
Procedure	Edge Length Filter (page 200)


Edges shorter than this percentage will be filtered out from consideration of being pointed to by the labe.

SC Arrangement > Label > Edge Determination Minimum Angle

Button	
Ribbon	Production tab > Labeling panel > Edge Determination Minimum Angle
Menu	SC Arrangement > Label > Edge Determination Minimum Angle
Toolbar	None
Command	SCLABELEDGEDETERMINATIONANGLE
Permissions ...	Pipe > Pipe Arrangements - Edit
Procedure	Edge Determination Minimum Angle (page 200)


Line segments will be considered part of the same edge if they are less than this angle away from tangent.

SC Arrangement > Label > Label Reset Automatic Settings

Button	
Ribbon	Production tab > Labeling panel > Label Reset Automatic Settings
Menu	SC Arrangement > Label > Label Reset Automatic Settings
Toolbar	None
Command	SCLABELRESETALL
Permissions ...	Pipe > Pipe Arrangements - Edit
Procedure	Label Reset Automatic Settings (page 200)


Resets the automatic label generation settings in the current drawing to use the project settings.

SC Arrangement > BOM Revisions > New BOM Revision in Current Layout

Button 
 Ribbon Production tab > BOM Revisions panel > New BOM Revision in Current Layout
 Menu SC Arrangement > BOM Revisions > New BOM Revision in Current Layout
 Toolbar None
 Command SCPRODREVNEW
 Permissions ... Pipe > Pipe Arrangement Drawing Revisions – Add/Edit
 Procedure [New Revision](#) (page 356)


Creates a revision in the current layout.

SC Arrangement > BOM Revisions > New BOM Revision in All Layouts

Button 
 Ribbon Production tab > BOM Revisions panel > New BOM Revision in All Layouts
 Menu SC Arrangement > BOM Revisions > New BOM Revision in All Layouts
 Toolbar None
 Command SCPRODREVNEWALL
 Permissions ... Pipe > Pipe Arrangement Drawing Revisions – Add/Edit
 Procedure [New Revision](#) (page 356)


Creates a revision in all layouts.

SC Arrangement > BOM Revisions > Delete BOM Revision in Current Layout

Button 
 Ribbon Production tab > BOM Revisions panel > Delete BOM Revision in Current Layout
 Menu SC Arrangement > BOM Revisions > Delete BOM Revision in Current Layout
 Toolbar None
 Command SCPRODREVDEL
 Permissions ... Pipe > Pipe Arrangement Drawing Revisions – Remove
 Procedure [Delete Revision](#) (page 356)


Deletes the current revision in the current layout.

SC Arrangement > BOM Revisions > Delete BOM Revision in All Layouts

Button 
 Ribbon Production tab > BOM Revisions panel > Delete BOM Revision in All Layouts
 Menu SC Arrangement > BOM Revisions > Delete BOM Revision in All Layouts
 Toolbar None
 Command SCPRODREVDELALL
 Permissions ... Pipe > Pipe Arrangement Drawing Revisions – Remove
 Procedure [Delete Revision](#) (page 356)


Deletes the current revision in all layouts.

SC Arrangement > BOM Revisions > Delete All BOM Revision in Current Layout

Button	
Ribbon	Production tab > BOM Revisions panel > Delete All BOM Revision in Current Layout
Menu	SC Arrangement > BOM Revisions > Delete All BOM Revision in Current Layout
Toolbar	None
Command	SCPRODREVCLEAR
Permissions ...	Pipe > Pipe Arrangement Drawing Revisions – Remove
Procedure	Delete All Revisions (page 357)


Deletes all revisions in the current layout.

SC Arrangement > BOM Revisions > Delete All BOM Revision in All Layouts

Button	
Ribbon	Production tab > BOM Revisions panel > Delete All BOM Revision in All Layouts
Menu	SC Arrangement > BOM Revisions > Delete All BOM Revision in All Layouts
Toolbar	None
Command	SCPRODREVCLEARALL
Permissions ...	Pipe > Pipe Arrangement Drawing Revisions – Remove
Procedure	Delete All Revisions (page 357)

Deletes all revisions in all layouts.

SC Arrangement > BOM Revisions > List BOM Revisions

Button	
Ribbon	Production tab > BOM Revisions panel > List BOM Revisions
Menu	SC Arrangement > BOM Revisions > List BOM Revisions
Toolbar	None
Command	SCPRODREVLIST
Permissions ...	None
Procedure	List Revisions (page 357)

List the information about the revisions in the current layout.

SC Arrangement > Global Dimension to Point

Menu	SC Arrangement > Global Dimension to Point
Toolbar	None
Command	SCDISTANCEFROMPOINT
Permissions ...	Pipe > Pipe Arrangements - Edit
Procedure	Global Dimension to Point (page 357)

Indicates the distance from a given point to a selected plane.

SC Spool Drawing Menu


The SC Spool Drawing menu appears in spool drawings.

SC Spool Drawing > Update Spool Drawing

Menu	SC Spool Drawing > Update Spool Drawing
Toolbar.....	None
Command	SCUPDATEDWG
Permissions ...	Pipe > Spools > Spool Drawings – Edit
Procedure.....	Updating an Existing Spool Drawing (page 182)

Update the spool drawing with the latest geometry from the model drawing.

SC Spool Drawing > Rotate Dimension

Menu	SC Spool Drawing > Rotate Dimension
Toolbar.....	Spool > 
Command	SCROTATEDIM
Permissions ...	Pipe > Spools > Spool Drawings – Edit
Procedure.....	Rotate a Dimension (page 179)


Invoke a utility that aids in the fine-tuning of linear dimensions.

SC Spool Drawing > Align Dimension Text to Current View

Menu	SC Spool Drawing > Align Dimension Text to Current View
Toolbar.....	None
Command	SCALIGNDIMTEXT
Permissions ...	Pipe > Spools > Spool Drawings – Edit
Procedure.....	Align Dimension Text to View (page 180)

Rotate and orient all text labels in the drawing to face the user.


SC Spool Drawing > Re-Dimension

Menu	SC Spool Drawing > Re-Dimension
Toolbar.....	Spool > 
Command	SCREDIM
Permissions ...	Pipe > Spools > Pipe Spools – Edit
Procedure.....	Re-dimension a Spool Drawing (page 180)


Automatically regenerates the dimensions for the spool.

SC Spool Drawing > CG Point

Menu	SC Spool Drawing > CG Point
Toolbar.....	None
Command	SCINSERTCG
Permissions ...	Pipe > Spools > Pipe Spools – Edit
Procedure.....	

The command inserts a SConCGPoint object at a center of gravity (CG) position of the current assembly. The SConCGPoint is exactly like an AutoCAD POINT object except you cannot move it. The command also changes the current Point style to  (34). You can change the style of the CG point by using the point style options. The orientation of the point is based on the orientation of the current UCS. If a SConCGPoint already exists in drawing, it will be moved to the correct CG position.

SC Spool Drawing > Orientation Icon

Menu SC Spool Drawing > Orientatation Icon
 Toolbar Spool > 
 Command SCASSORIENT
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [Insert an Orientation Icon](#) (page 201)

Insert an icon displaying the orientation of the ship.

SC Spool Drawing > Label Connecting Spool/Assembly

Menu SC Spool Drawing > Connecting Spool
 Toolbar None
 Command SCCONSPPOOL
 Permissions ... Pipe > Spools > Pipe Spools – Edit
 Procedure [Label Connecting Spool/Assembly](#) (page 181)

Inserts a label where the spool connects to another spool not in the drawing.

SC Spool Drawing > Insert Keywords

Menu SC Spool Drawing > Insert Keywords
 Toolbar None
 Command SCINSERTKEYWORD
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [Spool Drawing Keywords](#) (page 174)

Inserts keywords into the drawing.

SC Spool Drawing > Update All Keywords

Menu SC Spool Drawing > Update All Keywords
 Toolbar None
 Command SCUPDATEALLKEYWORDS
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [Update All Keywords](#) (page 202)

Updates all keywords in paper space in the drawing.

SC Spool Drawing > Drawing Options

Menu SC Spool Drawing > Drawing Options
 Toolbar None
 Command SCHEPDWGOPTIONS
 Permissions ... None
 Procedure [Pipe Options](#) (page 255)

Display the drawing options.

SC Spool Drawing > Viewport Options

Menu SC Spool Drawing > Viewport Options
 Toolbar None
 Command SCVPORTOPTIONS
 Permissions ... None
 Procedure [Viewport Options](#) (page 201)

Display the options for a specific viewport.

SC Spool Drawing > Set Viewport Display Options

Menu SC Spool Drawing > Set Viewport Display Options
 Toolbar None
 Command SCVIEWPORTDISOPTIONS
 Permissions ... None
 Procedure [Viewport Display Options](#) (page 202)

Configure the viewport specific display options for a specific viewport.

SC Spool Drawing > Insert BOM Table

Menu SC Spool Drawing > Insert BOM Table
 Toolbar None
 Command SCINSERTBOM
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [Insert a New Empty Spool BOM Table](#) (page 172)

Inserts a BOM table.

SC Spool Drawing > Update BOMs

Menu SC Spool Drawing > Update BOMs
 Toolbar None
 Command SCUPDATEBOMS
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [Update BOMs](#) (page 201)

Updates the BOM Table.

SC Spool Drawing > Edit Collector Options

Menu SC Spool Drawing > Edit Collector Options
 Toolbar None
 Command SCTWEAKBOMOPTIONS
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [Edit BOM Collector Options](#) (page 202)


Allows the user to change the BOM Collector options.

SC Spool Drawing > Toggle List Only Visible

Menu SC Spool Drawing > Toggle List Only Visible
 Toolbar None
 Command SCTOGGLELISTVISIBLE
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [List only Visible](#) (page 202)

Toggles the variable in the BOM to list only those parts visible or not.


SC Spool Drawing > Label > Manual Label from BOM

Menu SC Spool Drawing > Label > Manual Label from BOM
 Toolbar Assembly > 
 Command SCLABELMANUAL
 Permissions ... None
 Procedure [Manual Labeling from BOM](#) (page 198)

Let's you manually label parts from a BOM. This is an alternative method to automatic labeling. The label style and text contents are used from the selected BOM. The selection of the leader arrow is the pickpoint where you selected the part. The number of leader segments follows the label style setting.

This command can be used in conjunction with Copy Label from BOM so complete the labeling. If you select a part that has been previously labeled then the previous label is removed.

SC Spool Drawing > Label > Copy Label from BOM

Menu SC Spool Drawing > Label > Copy Label from BOM
 Toolbar Assembly > 
 Command SCLABELCOPY
 Permissions ... None
 Procedure [Manual Labeling from BOM](#) (page 198)

Let's you create labels that are copies of an existing label with the contents changed to reflect the first BOM column of the selected part. The copied label will be created with the label text and styles from the BOM table and geometry information from the source label.

SC Spool Drawing > Label > Relabel All

Menu SC Spool Drawing > Label > Relabel All
 Toolbar None
 Command SCRELABELALL
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [Relabel All](#) (page 198)

Generates labels for all new BOM items and places them on the _ANNOTATION layer.

Labels are generated only once. Subsequent commands only update the label text to reflect the Bill of Materials.

Even though labels are placed in Paper Space, they now track the objects in Model Space so that if the user pans, zooms, or orbits in the viewport, the labels track accordingly and remain synchronized to the objects that they represent.

SC Spool Drawing > Label > Relabel from BOM

Menu SC Spool Drawing > Label > Relabel from BOM
 Toolbar None
 Command SCRELABELFROMBOM
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [Relabel from a selected BOM](#) (page 198)

Relabels parts from a selected BOM and places them on the _ANNOTATION layer.

Labels are generated only once. Subsequent commands only update the label text to reflect the Bill of Materials.


Even though labels are placed in Paper Space, they now track the objects in Model Space so that if the user pans, zooms, or orbits in the viewport, the labels track accordingly and remain synchronized to the objects that they represent.

SC Spool Drawing > Label > Relabel from Parts

Menu SC Spool Drawing > Label > Relabel from Parts
 Toolbar None
 Command SCRELABELFROMPARTS
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [Relabel from Parts](#) (page 199)


Relabels selected parts from the BOMs.

SC Spool Drawing > BOM Revisions > New BOM Revision in Current Layout

Button 
 Ribbon Production tab > BOM Revisions panel > New BOM Revision in Current Layout
 Menu SC Spool Drawing > BOM Revisions > New BOM Revision in Current Layout
 Toolbar None
 Command SCPRODREVNEW
 Permissions ... Pipe > Spools > Pipe Spool Drawing Revisions – Add/Edit
 Procedure [New Revision](#) (page 356)


Creates a revision in the current layout.

SC Spool Drawing > BOM Revisions > New BOM Revision in All Layouts

Button 
 Ribbon Production tab > BOM Revisions panel > New BOM Revision in All Layouts
 Menu SC Spool Drawing > BOM Revisions > New BOM Revision in All Layouts
 Toolbar None
 Command SCPRODREVNEWALL
 Permissions ... Pipe > Spools > Pipe Spool Drawing Revisions – Add/Edit
 Procedure [New Revision](#) (page 356)


Creates a revision in all layouts.

SC Spool Drawing > BOM Revisions > Delete BOM Revision in Current Layout

Button	
Ribbon	Production tab > BOM Revisions panel > Delete BOM Revision in Current Layout
Menu	SC Spool Drawing > BOM Revisions > Delete BOM Revision in Current Layout
Toolbar	None
Command	SCPRODREVDL
Permissions ...	Pipe > Spools > Pipe Spool Drawing Revisions – Remove
Procedure	Delete Revision (page 356)


Deletes the current revision in the current layout.

SC Spool Drawing > BOM Revisions > Delete BOM Revision in All Layouts

Button	
Ribbon	Production tab > BOM Revisions panel > Delete BOM Revision in All Layouts
Menu	SC Spool Drawing > BOM Revisions > Delete BOM Revision in All Layouts
Toolbar	None
Command	SCPRODREVDLALL
Permissions ...	Pipe > Spools > Pipe Spool Drawing Revisions – Remove
Procedure	Delete Revision (page 356)


Deletes the current revision in all layouts.

SC Spool Drawing > BOM Revisions > Delete All BOM Revision in Current Layout

Button	
Ribbon	Production tab > BOM Revisions panel > Delete All BOM Revision in Current Layout
Menu	SC Spool Drawing > BOM Revisions > Delete All BOM Revision in Current Layout
Toolbar	None
Command	SCPRODREVCLEAR
Permissions ...	Pipe > Spools > Pipe Spool Drawing Revisions – Remove
Procedure	Delete All Revisions (page 357)


Deletes all revisions in the current layout.

SC Spool Drawing > BOM Revisions > Delete All BOM Revision in All Layouts

Button	
Ribbon	Production tab > BOM Revisions panel > Delete All BOM Revision in All Layouts
Menu	SC Spool Drawing > BOM Revisions > Delete All BOM Revision in All Layouts
Toolbar	None
Command	SCPRODREVCLEARALL
Permissions ...	Pipe > Spools > Pipe Spool Drawing Revisions – Remove
Procedure	Delete All Revisions (page 357)

Deletes all revisions in all layouts.

SC Spool Drawing > BOM Revisions > List BOM Revisions

Button 
 Ribbon Production tab > BOM Revisions panel > List BOM Revisions
 Menu SC Spool Drawing > BOM Revisions > List BOM Revisions
 Toolbar None
 Command SCPRODREVLIST
 Permissions ... None
 Procedure [List Revisions](#) (page 357)

List the information about the revisions in the current layout.

SC Spool Drawing > Global Dimension to Point


Menu SC Spool Drawing > Global Dimension to Point
 Toolbar None
 Command SCDISTANCEFROMPOINT
 Permissions ... Pipe > Spools > Spool Drawings – Edit
 Procedure [Global Dimension to Point](#) (page 357)

Indicates the distance from a given point to a selected plane.

SC Arrangement Template Menu

The SC Arrangement Template menu appears in arrangement drawing templates.

SC Arrangement Template > Orientation Icon

Menu SC Arrangement Template > Orientatation Icon
 Toolbar Spool > 
 Command SCASSORIENT
 Permissions ... General - Edit Template Drawings
 Procedure [Insert an Orientation Icon](#) (page 201)

Insert an icon displaying the orientation of the ship.


SC Arrangement Template > Insert Keywords

Menu SC Arrangement Template > Insert Keywords
 Toolbar None
 Command SCINSERTKEYWORD
 Permissions ... General - Edit Template Drawings
 Procedure [Arrangement Drawing Keywords](#) (page 186)

Inserts keywords into the drawing.

SC Arrangement Template > Pipe Drawing Options

Menu SC Arrangement Template > Pipe Drawing Options

Toolbar Pipe > 

Command SCDWGOPTIONSPIPE


Permissions ... None

Procedure [Pipe Options](#) (page 255)

Displays the pipe drawing options.

SC Arrangement Template > HVAC Drawing Options

Menu SC Arrangement Template > HVAC Drawing Options

Toolbar HVAC > 

Command SCDWGOPTIONSHVAC


Permissions ... None

Procedure See the HVAC manual for details.

Displays the HVAC drawing options.

SC Arrangement Template > Equipment Drawing Options

Menu SC Arrangement Template > Equipment Drawing Options

Toolbar Equipment > 

Command SCDWGOPTIONSEQUIP

Permissions ... None

Procedure See the Equipment manual for details.

Displays the Equipment drawing options.

SC Arrangement Template > Viewport Options

Menu SC Arrangement Template > Viewport Options

Toolbar None

Command SCVPORTOPTIONS

Permissions ... None

Procedure [Viewport Options](#) (page 201)

Display the options for a specific viewport.

SC Arrangement Template > Set Viewport Display Options

Menu SC Arrangement Template > Set Viewport Display Options

Toolbar None

Command SCVIEWPORTDISOPTIONS

Permissions ... None

Procedure [Viewport Display Options](#) (page 202)

Configure the viewport specific display options for a specific viewport.

SC Arrangement Template > Insert BOM Table

Menu SC Arrangement Template > Insert BOM Table
 Toolbar None
 Command SCINSERTBOM
 Permissions ... General - Edit Template Drawings
 Procedure [Insert a New Empty Arrangement BOM Table](#) (page 184)

Inserts a BOM table.

SC Arrangement Template > Edit Collector Options

Menu SC Arrangement Template > Edit Collector Options
 Toolbar None
 Command SCTWEAKBOMOPTIONS
 Permissions ... General - Edit Template Drawings
 Procedure [Edit BOM Collector Options](#) (page 202)

Allows the user to change the BOM Collector options.

SC Arrangement Template > Toggle List Only Visible

Menu SC Arrangement Template > Toggle List Only Visible
 Toolbar None
 Command SCTOGGLELISTVISIBLE
 Permissions ... General - Edit Template Drawings
 Procedure [List only Visible](#) (page 202)

Toggles the variable in the BOM to list only those parts visible or not.


SC Arrangement Template > Update from a Previous Version

Menu SC Arrangement Template > Update from a Previous Version
 Toolbar None
 Command SCUPTATEPREVIOUSTEMP
 Permissions ... None
 Procedure [Update a Previous Version of an Arrangement Template](#) (page 187)

SC Spool Template Menu

The SC Spool Template menu appears in spool drawing templates.

SC Spool Template > Orientation Icon

Menu SC Spool Template > Orientatation Icon
 Toolbar Spool > 
 Command SCASSORIENT
 Permissions ... General - Edit Template Drawings
 Procedure [Insert an Orientation Icon](#) (page 201)

Insert an icon displaying the orientation of the ship.

SC Spool Template > Insert Keywords

Menu SC Spool Template > Insert Keywords
 Toolbar None
 Command SCINSERTKEYWORD
 Permissions ... General - Edit Template Drawings
 Procedure [Spool Drawing Keywords](#) (page 174)

Inserts keywords into the drawing.

SC Spool Template > Drawing Options

Menu SC Spool Template > Drawing Options
 Toolbar None
 Command SCHEPDWGOPTIONS
 Permissions ... None
 Procedure [Pipe Options](#) (page 255)

Displays the drawing options.

SC Spool Template > Viewport Options

Menu SC Spool Template > Viewport Options
 Toolbar None
 Command SCVPORTOPTIONS
 Permissions ... None
 Procedure [Viewport Options](#) (page 201)

Display the options for a specific viewport.

SC Spool Template > Set Viewport Display Options

Menu SC Spool Template > Set Viewport Display Options
 Toolbar None
 Command SCVIEWPORTDISOPTIONS
 Permissions ... None
 Procedure [Viewport Display Options](#) (page 202)

Configure the viewport specific display options for a specific viewport.

SC Spool Template > Insert BOM Table

Menu SC Spool Template > Insert BOM Table
 Toolbar None
 Command SCINSERTBOM
 Permissions ... General - Edit Template Drawings
 Procedure [Insert a New Empty Spool BOM Table](#) (page 172)

Inserts a BOM table.

SC Spool Template > Edit Collector Options

Menu	SC Spool Template > Edit Collector Options
Toolbar	None
Command	SCTWEAKBOMOPTIONS
Permissions ...	General - Edit Template Drawings
Procedure	Edit BOM Collector Options (page 202)

Allows the user to change the BOM Collector options.

SC Spool Template > Toggle List Only Visible

Menu	SC Spool Template > Toggle List Only Visible
Toolbar	None
Command	SCTOGGLELISTVISIBLE
Permissions ...	General - Edit Template Drawings
Procedure	List only Visible (page 202)

Toggles the variable in the BOM to list only those parts visible or not.

SC Spool Template > Update from a Previous Version

Menu	SC Spool Template > Update from a Previous Version
Toolbar	None
Command	SCUPDATEPREVIOUSTEMP
Permissions ...	None
Procedure	Update a Previous Version of a Spool Template (page 175)

Appendix D: Distributed Systems Production Command Reference

SC Support Const Menu

The SC Support Const menu appears in support construction drawings.

SC Support Const > Update Drawing

Menu	SC Support Const > Update Drawing
Toolbar	None
Command	SCUPDATEDWG
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Update Support Construction Drawings (page 213)

Update a Support Construction drawing with the latest geometry from the model drawings.

SC Support Const > Silent Update Drawing

Menu	None
Toolbar	None
Command	-SCUPDATEDWGSILENT
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Update Support Construction Drawings (page 213)

Update a Support Construction drawing with the latest geometry from the model drawings without any further user input.

SC Support Const > Insert Keywords

Menu	SC Support Const > Insert Keywords
Toolbar	None
Command	SCINSERTKEYWORD
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Support Construction Drawing Keywords (page 207)

Inserts keywords into the drawing.

SC Support Const > Update All Keywords

Menu	SC Support Const > Update All Keywords
Toolbar	None
Command	SCUPDATEALLKEYWORDS
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Update All Keywords (page 202)

Updates all keywords in paper space in the drawing.

SC Support Const > Re-Dimension

Menu

SC Support Const > Re-Dimension

Toolbar.....

None

Command

SCREDIM

Permissions ...

Distributed System Supports > Construction Drawings - Edit


Procedure.....

Re-dimension a Support Construction Drawing

Automatically regenerates the dimensions for the support based on the support construction drawing options that can be editing in Manager.

Support Construction Drawing Options

The support construction drawing options control the dimensioning of the support construction drawing.






Dimension Style – The AutoCAD dimension style used to dimension the profiles of the support. The dimension styles come from General > Production Output > Dimension Styles in Manager.

Dimension Layer Name – A string that is appended of the layer name. The dimension is formed from Horizontal or Vertical Tier Layer Prefix + <index of the horizontal or vertical> + Dimension Layer Name + Dimension Direction (Eg. H_1_DIMZ)

The index of horizontals is top down with the top being 1.

The index of the verticals is left to right with the left being 1.

Horizontal Tier Dimension Layout – The type of dimension to use.

Layout	Appearance
Continue	
Baseline	
Ordinate	

Horizontal Tier Datum Point Position – The position of the origin of the dimensions for the horizontal tiers.

Horizontal Dimension Offset – The distance from the top of the geometry to the first dimension.

Vertical Tier Dimension Layout – The type of dimension to use.

Vertical Tier Datum Point Position – The position of the origin of the dimensions for the horizontal tiers.


Vertical Dimension Offset – The distance from the top of the geometry to the first dimension.

Horizontal Tier Layer Prefix – The prefix to all horizontal related layers.

Vertical Tier Layer Prefix – The prefix to all horizontal related layers.


Hanger Layer Name – The postfix for the hanger layers. Hangers on the top horizontal profile would be on the Horizontal Tier Layer Prefix + 1 + Hanger Layer Name

SC Support Const > Structure Drawing Options

Menu SC Support Const > Structure Drawing Options
 Toolbar Structure Display > 
 Command SCSTRUCTDISPLAY
 Permissions ... None
 Procedure Structure Options

Displays the structure drawing options.

SC Support Const > Hanger Drawing Options

Menu SC Support Const > Hanger Drawing Options
 Toolbar Hangers > 
 Command SCHANGDWGOPTIONS
 Permissions ... None
 Procedure [Display Options for Hangers](#) (page 145)

Displays the hanger drawing options.

SC Support Const > Viewport Options

Menu SC Support Const > Viewport Options
 Toolbar None
 Command SCVPORTOPTIONS
 Permissions ... None
 Procedure [Viewport Options](#) (page 201)

Display the options for a specific viewport.

SC Support Const > Set Viewport Display Options

Menu SC Support Const > Set Viewport Display Options
 Toolbar None
 Command SCVIEWPORTDISPOPTIONS
 Permissions ... None
 Procedure [Viewport Display Options](#) (page 202)

Configure the viewport specific display options for a specific viewport.

SC Support Const > Insert BOM Table

Menu SC Support Const > Insert BOM Table
 Toolbar None
 Command SCINSERTBOM
 Permissions ... Distributed System Supports > Construction Drawings - Edit
 Procedure [Insert a Support Construction BOM Table](#) (page 208)

Inserts a BOM table.

SC Support Const > Update BOMs

Menu SC Support Const > Update BOMs
 Toolbar None
 Command SCUPDATEBOMS
 Permissions ... Distributed System Supports > Construction Drawings - Edit
 Procedure [Update BOMs](#) (page 201)

Updates the BOM Table(s).

SC Support Const > Edit Collector Options

Menu SC Support Const > Edit Collector Options
 Toolbar None
 Command SCTWEAKBOMOPTIONS
 Permissions ... Distributed System Supports > Construction Drawings - Edit
 Procedure [Edit BOM Collector Options](#) (page 202)


Allows the user to change the BOM Collector options.

SC Support Const > Toggle list only visible

Menu SC Support Const > Toggle list only visible
 Toolbar None
 Command SCTOGGLELISTVISIBLE
 Permissions ... Distributed System Supports > Construction Drawings - Edit
 Procedure [List only Visible](#) (page 202)

Toggles the variable in the BOM to list only those parts visible or not.

SC Support Const > Label > Manual Label from BOM

Menu SC Assembly > Label > Manual Label from BOM
 Toolbar Assembly > 
 Command SCLABELMANUAL
 Permissions ... None
 Procedure [Manual Labeling from BOM](#) (page 198)

Let's you manually label parts from a BOM. This is an alternative method to automatic labeling. The label style and text contents are used from the selected BOM. The selection of the leader arrow is the pickpoint where you selected the part. The number of leader segments follows the label style setting.


This command can be used in conjunction with Copy Label from BOM so complete the labeling. If you select a part that has been previously labeled then the previous label is removed.

SC Support Const > Label > Copy Label from BOM

Menu SC Assembly > Label > Copy Label from BOM
 Toolbar Assembly > 
 Command SCLABELCOPY
 Permissions ... None
 Procedure [Manual Labeling from BOM](#) (page 198)

Let's you create labels that are copies of an existing label with the contents changed to reflect the first BOM column of the selected part. The copied label will be created with the label text and styles from the BOM table and geometry information from the source label.

SC Support Const > Label > Relabel All


Button	
Ribbon	Production tab > Labeling panel > Relabel All
Menu	SC Arrangement > Label > Relabel All
Toolbar	None
Command	SCRELABELALL
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Relabel All (page 198)

Generates labels for all new BOM items and places them on the _ANNOTATION layer.

Labels are generated only once. Subsequent commands only update the label text to reflect the Bill of Materials.

Even though labels are placed in Paper Space, they now track the objects in Model Space so that if the user pans, zooms, or orbits in the viewport, the labels track accordingly and remain synchronized to the objects that they represent.

SC Support Const > Label > Relabel from BOM


Button	
Ribbon	Production tab > Labeling panel > Relabel from BOM
Menu	SC Arrangement > Label > Relabel from BOM
Toolbar	None
Command	SCRELABELFROMBOM
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Relabel from a selected BOM (page 198)

Relabels parts from a selected BOM and places them on the _ANNOTATION layer.

Labels are generated only once. Subsequent commands only update the label text to reflect the Bill of Materials.


Even though labels are placed in Paper Space, they now track the objects in Model Space so that if the user pans, zooms, or orbits in the viewport, the labels track accordingly and remain synchronized to the objects that they represent.

SC Support Const > Label > Relabel from Parts

Button	
Ribbon	Production tab > Labeling panel > Relabel from Parts
Menu	SC Arrangement > Label > Relabel from Parts
Toolbar	None
Command	SCRELABELFROMPARTS
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Relabel from Parts (page 199)


Relabels selected parts from the BOMs.

SC Support Const > Label > Label on Visible Edge On/Off

Button	
Ribbon	Production tab > Labeling panel > Label on Visible Edge On/Off
Menu	SC Arrangement > Label > Label on Visible Edge On/Off
Toolbar	None
Command	SCLABELONVISIBLEEDGE
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Label on Visible Edge On/Off (page 199)


Turns labels automatic label generation from label to piecemark to label on visible part edge.

SC Support Const > Label > Curved Plates in Visible Edge Detection On/Off

Button	
Ribbon	Production tab > Labeling panel > Curved Plates in Visible Edge Detection On/Off
Menu	SC Arrangement > Label > Curved Plates in Visible Edge Detection On/Off
Toolbar	None
Command	SCLABELREMOVECURVEDPLATEHLR
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Curved Plates in Visible Edge Detection On/Off (page 199)


Turns on option to include curved plates in hidden line calculation when label on visible part edge is on.

SC Support Const > Label > Adjacent Part Edge Tolerance

Button	
Ribbon	Production tab > Labeling panel > Adjacent Part Edge Tolerance
Menu	SC Arrangement > Label > Adjacent Part Edge Tolerance
Toolbar	None
Command	SCLABELADJACENTTOL
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Adjacent Part Edge Tolerance (page 199)


Edges will be less likely to be labeled if they are closer than this distance to an edge of another part.

SC Support Const > Label > Edge Length Filter

Button	
Ribbon	Production tab > Labeling panel > Edge Length Filter
Menu	SC Arrangement > Label > Edge Length Filter
Toolbar	None
Command	SCLABELEDGELENGTHFILTER
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Edge Length Filter (page 200)


Edges shorter than this percentage will be filtered out from consideration of being pointed to by the labe.

SC Support Const > Label > Edge Determination Minimum Angle

Button	
Ribbon	Production tab > Labeling panel > Edge Determination Minimum Angle
Menu	SC Arrangement > Label > Edge Determination Minimum Angle
Toolbar	None
Command	SCLABELEDGEDETERMINATIONANGLE
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Edge Determination Minimum Angle (page 200)


Line segments will be considered part of the same edge if they are less than this angle away from tangent.

SC Support Const > Label > Label Reset Automatic Settings

Button 
 Ribbon Production tab > Labeling panel > Label Reset Automatic Settings
 Menu SC Arrangement > Label > Label Reset Automatic Settings
 Toolbar None
 Command SCLABELRESETALL
 Permissions ... Distributed System Supports > Construction Drawings - Edit
 Procedure [Label Reset Automatic Settings](#) (page 200)


Resets the automatic label generation settings in the current drawing to use the project settings.

SC Support Const > BOM Revisions > New BOM Revision in Current Layout

Button 
 Ribbon Production tab > BOM Revisions panel > New BOM Revision in Current Layout
 Menu SC Support Const > BOM Revisions > New BOM Revision in Current Layout
 Toolbar None
 Command SCPRODREVNEW
 Permissions ... Distributed System Supports > DS Support Construction Dwg Revisions – Add/Edit
 Procedure [New Revision](#) (page 356)


Creates a revision in the current layout.

SC Support Const > BOM Revisions > New BOM Revision in All Layouts

Button 
 Ribbon Production tab > BOM Revisions panel > New BOM Revision in All Layouts
 Menu SC Support Const > BOM Revisions > New BOM Revision in All Layouts
 Toolbar None
 Command SCPRODREVNEWALL
 Permissions ... Distributed System Supports > DS Support Construction Dwg Revisions – Add/Edit
 Procedure [New Revision](#) (page 356)


Creates a revision in all layouts.

SC Support Const > BOM Revisions > Delete BOM Revision in Current Layout

Button 
 Ribbon Production tab > BOM Revisions panel > Delete BOM Revision in Current Layout
 Menu SC Support Const > BOM Revisions > Delete BOM Revision in Current Layout
 Toolbar None
 Command SCPRODREVDEL
 Permissions ... Distributed System Supports > DS Support Construction Dwg Revisions – Remove
 Procedure [Delete Revision](#) (page 356)


Deletes the current revision in the current layout.

SC Support Const > BOM Revisions > Delete BOM Revision in All Layouts

Button 
 Ribbon Production tab > BOM Revisions panel > Delete BOM Revision in All Layouts
 Menu SC Support Const > BOM Revisions > Delete BOM Revision in All Layouts
 Toolbar None
 Command SCPRODREVDLALL
 Permissions ... Distributed System Supports > DS Support Construction Dwg Revisions – Remove
 Procedure [Delete Revision](#) (page 356)


Deletes the current revision in all layouts.

SC Support Const > BOM Revisions > Delete All BOM Revision in Current Layout

Button 
 Ribbon Production tab > BOM Revisions panel > Delete All BOM Revision in Current Layout
 Menu SC Support Const > BOM Revisions > Delete All BOM Revision in Current Layout
 Toolbar None
 Command SCPRODREVCLEAR
 Permissions ... Distributed System Supports > DS Support Construction Dwg Revisions – Remove
 Procedure [Delete All Revisions](#) (page 357)


Deletes all revisions in the current layout.

SC Support Const > BOM Revisions > Delete All BOM Revision in All Layouts

Button 
 Ribbon Production tab > BOM Revisions panel > Delete All BOM Revision in All Layouts
 Menu SC Support Const > BOM Revisions > Delete All BOM Revision in All Layouts
 Toolbar None
 Command SCPRODREVCLEARALL
 Permissions ... Distributed System Supports > DS Support Construction Dwg Revisions – Remove
 Procedure [Delete All Revisions](#) (page 357)

Deletes all revisions in all layouts.

SC Support Const > BOM Revisions > List BOM Revisions

Button 
 Ribbon Production tab > BOM Revisions panel > List BOM Revisions
 Menu SC Support Const > BOM Revisions > List BOM Revisions
 Toolbar None
 Command SCPRODREVLIST
 Permissions ... None
 Procedure [List Revisions](#) (page 357)

List the information about the revisions in the current layout.

SC Support Const > Global Dimension to Point

Menu	SC Support Const > Global Dimension to Point
Toolbar	None
Command	SCDISTANCEFROMPOINT
Permissions ...	Distributed System Supports > Construction Drawings - Edit
Procedure	Global Dimension to Point (page 357)

Indicates the distance from a given point to a selected plane.

SC Support Const Template Menu


The SC Support Const Template menu appears in Support Construction drawing templates.

SC Support Const Template > Insert Keywords

Menu	SC Support Const Template > Insert Keywords
Toolbar	None
Command	SCINSERTKEYW
Permissions ...	General - Edit Template Drawings
Procedure	Support Construction Drawing Keywords (page 207)

Inserts keywords into the drawing.

SC Support Const Template > Structure Drawing Options

Menu	SC Support Const Template > Structure Drawing Options
Toolbar	Structure Display > 
Command	SCSTRUCTDISPLAY
Permissions ...	None
Procedure	Structure Options

Displays the structure drawing options.

SC Support Const Template > Hanger Drawing Options

Menu	SC Support Const Template > Hanger Drawing Options
Toolbar	Hangers > 
Command	SCHANGDWGOPTIONS
Permissions ...	None
Procedure	Display Options for Hangers (page 145)

Displays the hanger drawing options.

SC Support Const Template > Viewport Options

Menu	SC Support Const Template > Viewport Options
Toolbar	None
Command	SCVPOROPTIONS
Permissions ...	None
Procedure	Viewport Options (page 201)

Display the options for a specific viewport.

SC Support Const Template > Set Viewport Display Options

Menu SC Support Const Template > Set Viewport Display Options
 Toolbar None
 Command SCVIEWPORTDISPOPTIONS
 Permissions ... None
 Procedure [Viewport Display Options](#) (page 202)

Configure the viewport specific display options for a specific viewport.

SC Support Const Template > Insert BOM Table

Menu SC Support Const Template > Insert BOM Table
 Toolbar None
 Command SCINSERTEMPTYBOM
 Permissions ... General - Edit Template Drawings
 Procedure [Insert a Support Construction BOM Table](#) (page 208)

Inserts a BOM table.

SC Support Const Template > Edit Collector Options

Menu SC Support Const Template > Edit Collector Options
 Toolbar None
 Command SCTWEAKBOMOPTIONS
 Permissions ... General - Edit Template Drawings
 Procedure [Edit BOM Collector Options](#) (page 202)

Allows the user to change the BOM Collector options.

SC Support Const Template > Toggle list only visible

Menu SC Support Const Template > Toggle list only visible
 Toolbar None
 Command SCTOGGLELISTVISIBLE
 Permissions ... General - Edit Template Drawings
 Procedure [List only Visible](#) (page 202)

Toggles the variable in the BOM to list only those parts visible or not.

Appendix E: Distributed Systems Production Reference


Bill of Materials

The ShipConstructor Bill of Materials (BOM) includes customizable and convenient functions:

- Management of all production drawing BOMs is performed through a unified interface, the BOM Definitions manager.
- BOMs have full merging, sorting, and grouping capability – even on hidden columns.
- You have control of object listing order in tables.
- Column heading aliasing.
- BOM tables use standard AutoCAD tables.
- BOM Functionality is identical regardless of drawing type.
- Consistent item numbering across all sheets.
- Updating without losing formatting.

BOM Functionality Overview

ShipConstructor projects can have any number of user-customizable BOM definitions available for use in target production drawing types. As shown in the following diagram, multiple tables can be inserted in a production drawing, each referencing a master list.



One master list exists per BOM definition. The first time a BOM table is inserted in a drawing, its master list is created. Subsequent table insertions all reference the initial master list.

BOM content is determined at the time of BOM update. Collectors, specified by the BOM definition, organize the objects in the drawing into relevant groups (for example, Pipe, Accessories, and Spools) and process the BOM data into data blocks. The data blocks are then compiled into the master list with the tables being updated to reflect the master list data.

The order of the items listed in the BOM depends on primary and secondary factors. The primary order is determined by the collector. Each collector provides its own formatted data block. Within each data block, the row order is determined by the field sort order specified of the BOM definition.

Collectors process the data for their respective objects according to the format specified by the BOM definition. Therefore, each block of collector data is sorted according to the field sort order specified by the BOM definition.

Item numbering is performed on the master list at the time of BOM update. Tables inserted with the List Only Visible option retrieve their item numbering from the master list to ensure consistent numbering across all sheets. Item numbers can have user-defined prefix text (for example, SP-001).

To understand how collector use works, we will use an example: You have a Pipe arrangement drawing that contains structure, pipe, and HVAC, and you need two different bills of materials: a pipe stock BOM and spool list.

The pipe stock BOM must list all pipe items, HVAC items, and connection accessories, but not structure. This can be achieved by creating two BOM definitions, one for the stocks and one for the spool list.

The stock BOM should list the objects in a specific order: Pipe objects, HVAC objects, Pipe connection accessories, and then HVAC connection accessories.

To create a stock BOM that accomplishes the requirement, a BOM definition is created that includes the following collectors: Pipe Part, HVAC Part, Pipe Connection Accessories, and HVAC Connection Accessories. Order them as specified above; the BOM lists the items in the order specified

To create the spool list, another BOM definition is created that only includes the pipe spool collector.

Both of these BOMs can exist in the same drawing.


Virtually all other aspects of a BOM can be customized, including the following:

- Items included and their order.
- User-defined column header text.
- Each field can be sorted ascending or descending, in user-defined sequence.
- Rows can be merged dependent or independent of equivalent field data.
- Field properties such as units, display format (decimals or fractions), and rounding can be edited individually.

BOM Definitions Manager

ShipConstructor integrates all Bill of Materials management through the BOM Definitions manager. The BOM Definitions manager lets you create and edit existing BOMs for all production drawing types.

Access the BOM Definitions manager through Manager > General > Production Output > Bill of Materials.



Properties and Functions Explained

Broken down into production drawing categories, the BOM Definitions area lets you create and delete definitions and editing characteristics specific to a BOM.

- Style Name – Name of the BOM definition.
- Title – Title to display on AutoCAD tables.

Note: Only tables using table styles that contain the Title section will display the Title text.

- Acad TableStyle – AutoCAD tablestyle to use for BOM instances. If the specified tablestyle is not found at the time of insertion, then the STANDARD style is used.
- Label Style – ShipConstructor label style to use for the BOM. This style can be overridden by the Collector Label Style.

- Row # prefix text – Precedes item number with text in both table and label.

New

Creates new BOM definitions.

Default Collectors – If selected, the BOM definition includes reasonable collectors for the current production drawing type. You can modify the collectors and their order after creation.

Delete

Deletes the selected BOM definition. If the BOM definition is in use, it cannot be deleted.



Moves selected fields up in the listing order



Moves selected fields down in the listing order.

BOM Fields

Lets you customize aspects of the fields that appear in your BOM:

- Choose which fields to include in the BOM.
- Alias the field names to something appropriate for your company.
- List the order the fields will be displayed in.
- Specify sorting, merging, and visibility of the included fields.
- Specify properties specific to the type of field included, be it a decimal, length, weight, or other type of value. Fields with manageable properties are indicated by a white background in the Field Props column.

Add/Remove – Adds or removes production fields or user attribute fields. Production fields are those provided by ShipConstructor and that exist in every project. Attribute fields are special fields that are defined by the user for the project. All attribute fields are listed, regardless of whether they logically make sense for the BOM definition.

Note: The BOM Labeling procedure extracts the text contained in the first column of the table. (Typically the Item # field would be the first field but you could for instance use a field such as 'Spool Name', etc.)

Production Field	Description	Module	Numeric Type
Angle	Angle of the stock elbow	HVAC, Pipe	Angle
Arc Length	Length of arc on Bent pipe. Specific to Bending BOM only	Pipe	Length
Area	Area of one side of the part	Structure	Area
Area with Green	Area of the part, including green	Structure	Area
Assembly	The name of the assembly where the part resides	HVAC, Pipe, Structure	
Bend Angle	Angle of arc in bent pipe. Specific to Bending BOM only	Pipe	Length
Bend Radius	Radius of bend in bent pipe. Specific to Bending BOM only	Pipe	Length
Branch	The name of the system branch	HVAC, Pipe	
Catalogs	The name of the catalog	HVAC, Pipe	
Common Name	Same as part name for Structural parts, Spools, and Assemblies, same as stock for everything else	HVAC, Pipe, Structure	
Connection	The connected item	HVAC, Pipe	
CPC Catalog Number	The catalog number of the part in the Common Parts Catalog	HVAC, Pipe, Structure	
CPC Company CAGE Code	The company cage code of the part in the Common Parts Catalog	HVAC, Pipe, Structure	

Cutback Angle	The angle of the elbow fitting, less the 'cutback' amount on each end.	Pipe	
Drawing	The drawing the part is modeled in	HVAC, Pipe, Structure	
End	The end treatments for the part	HVAC, Pipe	
End 1 / Start Green	The green length on the first end of the part	Pipe, Structure	Length
End 2 / End Green	The green length on the second end of the part	Pipe, Structure	Length
End Profiles	The end profiles for the part	HVAC	
Endcut End	The name of the endcut standard applied to the second end of the part	Structure	
Endcut Start	The name of the endcut standard applied to the starting end of the part	Structure	
Finishes	All the finishes applied to the part.	HVAC, Pipe, Structure	
Flange Direction	The direction in which the flange is facing. For twisted profiles, it is the facing direction at the profile start point.	Structure	
Fluid Weight	The fluid weight of the part. Based on the relative density of the system fluid.	Pipe	Weight
Full Assembly Name	The full path of the assembly in which the part resides	HVAC, Pipe, Structure	
Inner Length	Length of straight section on bent pipe. Applies to Bending Data BOMs only	Pipe	
Insulations	All insulation applied to the part	HVAC, Pipe	
Item #	Corresponds to the numbered label in the production drawing	HVAC, Pipe, Structure	Integer
Item # (alpha-numeric)	Corresponds to the label in the production drawing	HVAC, Pipe, Structure	
LCG	The location of the longitudinal center of gravity	HVAC, Pipe, Structure	Length
Length	The length of the part. This does not include green length	HVAC, Pipe, Structure	Length
Length with Green	The length of the part including green	Pipe, Structure	
Manufacturer	The name of the manufacturer	HVAC, Pipe, Structure	
Mark Side	The mark side determines which side of the plate will face up when the part is in a nest drawing. The displayed directions are determined by the orientation of the plate in the model	Structure	
Material	The primary material the part is composed of. This is used for density calculations	HVAC, Pipe, Structure	
Maximum Extent Long	The maximum extent in the longitudinal direction	HVAC, Pipe, Structure	Length
Maximum Extent Trans	The maximum extent in the transverse direction	HVAC, Pipe, Structure	Length
Maximum Extent Vert	The maximum extent in the vertical direction	HVAC, Pipe, Structure	Length
Minimum Extent Long	The minimum extent in the longitudinal direction	HVAC, Pipe, Structure	Length
Minimum Extent	The minimum extent in the transverse direction	HVAC, Pipe,	Length

Trans		Structure	
Minimum Extent Vert	The minimum extent in the vertical direction	HVAC, Pipe, Structure	Length
Mirror Part Name	The name of the mirrored part nested on a mirrored nest.	Structure	
Nest	The nest the structure part is in	Structure	
Nominal Size	The name of the nominal size for the pipe part	Pipe	
Num Vanes	The number of vanes for the HVAC part	HVAC	Integer
OD	The outer diameter of the pipe part	Pipe	Length
Outer Length	The outer length of the bend (straight length + tangent to corners). Specific to Bending Data BOMs.	Pipe	Length
Parent Assembly Name	The name of the parent assembly for the assembly in which the part resides	HVAC, Pipe, Structure	
Part Name	The name of the part	HVAC, Pipe, Structure	
Part Side	The side of the ship in which the structure part lies (P, S, C)	Structure	
Piece Type	The type of part	HVAC, Pipe, Structure	
Pipe/Duct Length	Same as 'Length' field, but N/A for all other parts other than HVAC and Pipe	HVAC, Pipe	Length
Plot Dwg	The drawing in which the profile is plotted.	Structure	
Plot Sheet	The sheet on which the profile is plotted.	Structure	
Position	The position on the line.	Pipe	
Profile Chord Length	The chord length for the profile part	Structure	Length
Quantity	The number of parts	HVAC, Pipe, Structure	Integer
Radius	The radius of the HVAC or Pipe part elbow curvature	HVAC, Pipe	Length
Rank	The Rank (Assembly level) of the part	HVAC, Pipe, Structure	
Rotation	The rotation about centerline of the pipe. Specific to Bending Data BOMs	Pipe	
Schedule	The schedule of the pipe	Pipe	
Sheet Stock	The name of the sheet stock used for the part	HVAC	
Short Assembly Name	The name of the assembly and parent assembly in which the part resides	HVAC, Pipe, Structure	
Spec Name	The name of the specification	Pipe	
Spool Name	The name of the spool	HVAC, Pipe	
Spool UDA	User Defined Attributes of the spool	HVAC, Pipe	
Stock Description	The description of the stock	HVAC, Pipe, Structure	
Stock Name	The name of the stock	HVAC, Pipe, Structure	
Surface Area	The total surface area of the part	Structure	Area
System	The name of the system	HVAC, Pipe	
TCG	The location of the transverse center of gravity	HVAC, Pipe,	Length

Structure

Merging Rows

Rows with common field values can be merged. There are only two requirements for two rows to be merged:

1. The rows must be produced by the same Collector.
2. For each field where Merge Identical has been set to Yes, the row must have the same value as the one above.

Fields that are not marked as Merge Identical are merged appropriately e.g. Total Length is summed, quantities are summed, etc. Where values differ in merged cells, the value "Varies" will be displayed.

There is one exception to the rule of summation however, and this is for the 'Length' field. It is not summed so that the BOM can produce output like:

Item #	Quantity	Length	Stock Name
4	6	48-5/16"	P-SM-CS_00.75_40_A53-B

Where each of the six pipes is 48-5/16" long. Use the "Total Length" field (and Alias the name to your company standards) if you need to sum the lengths of the objects.

Merging Columns

It is sometimes necessary to show information that is contained in different locations within objects, in the same cell. For instance, an Assembly Bill of Materials may list assemblies, spools, structure parts, pipe parts, etc.. Rather than displaying multiple columns to display the relevant name information, you can merge the data into the same column, thereby reducing the total number of columns displayed in the BOM table.

In order to merge the columns, the columns must:

- Have the same Field Alias. Rename the field alias from the default to the required name.
- Be consecutively ordered within the BOM definition
- Contain mutually exclusive data. i.e. only one of the fields will return data. If more than one field returns values, then 'varies' will be displayed in the cell.

Collectors

Collectors are responsible for gathering objects in a drawing to be included in a BOM and then processing the object data for display in the BOM.

Note: Collector order is important because each collector returns information specific to the objects it collects. Resultant information for each collector is then compiled in the order specified by the BOM definition.

Collectors are specific for each production drawing type. The following table lists the collectors available per drawing type.

Collector Availability per Drawing Type

Module	Production Drawing Type	Collectors
General	Assembly	Assembly, Standard Assembly, Structure Part, Equipment Part, Pipe Spool, Pipe Part, HVAC Spool, HVAC Part, Penetration Component, Pipe Hanger, Distributed System Supports, General Part, Pipe Connection Accessories, HVAC Connection Accessories, Pipe Hanger Accessories, Penetration Accessories, All Accessories
Structure	Approval	To be determined
	Nest	Plate Nest
	Profile Plot	Profile Plot

Pipe	Pipe Spool	Pipe Part, Pipe Cutlist, Penetration Component, Global Point, Corner Point, Pipe Connection Accessories, Penetration Accessories, All Accessories
	Bending Tables	Bending Info
	Pipe Arrangement	Assembly, Standard Assembly, Structure Part, Equipment Part, Pipe Spool, Pipe Part, HVAC Spool, HVAC Part, Penetration Component, Pipe Hanger, Distributed System Supports, General Part, Pipe Connection Accessories, HVAC Connection Accessories, Pipe Hanger Accessories, Penetration Accessories, All Accessories
	Support Construction	Structure Part, Pipe Hanger, Pipe Hanger Accessories, All Accessories
HVAC	HVAC Spool	HVAC Part, HVAC Cutlist, Penetration Component, HVAC Connection Accessories, Penetration Accessories, All Accessories
	HVAC Arrangement	Assembly, Standard Assembly, Structure Part, Equipment Part, Pipe Spool, Pipe Part, HVAC Spool, HVAC Part, Penetration Component, Pipe Hanger, Distributed System Supports, General Part, Pipe Connection Accessories, HVAC Connection Accessories, Pipe Hanger Accessories, Penetration Accessories, All Accessories
Equipment	Equipment Arrangement	Assembly, Standard Assembly, Structure Part, Equipment Part, Pipe Spool, Pipe Part, HVAC Spool, HVAC Part, Penetration Component, Pipe Hanger, Distributed System Supports, General Part, Pipe Connection Accessories, HVAC Connection Accessories, Pipe Hanger Accessories, Penetration Accessories, All Accessories

Collector Functionality

The following table lists the collectors and their functions.

Collector	Description	Additional Functionality
Assembly	Organizes objects into primary production strategy assemblies. Returns information for each of the first level subassemblies. Main assembly and children of the subassemblies are not reported.	Include Standard Assemblies – if checked this will collect parts in standard assemblies Filter Only – Allows the collector to collect, but not display the items in the BOM. Useful if you want to only include items directly within the Assembly and not from sub assemblies.
Standard Assembly	Collects all parts that are part of standard assemblies.	
Structure Part	Finds and returns information for all structure parts.	Collector Options let you select the Part Types to collect. CorrugatedPlate, CurvedPlate, Extrusion, Penetration Components, Plank, Plate, TwistedExtrusion
Equipment Part	Finds and returns information for all equipment parts.	
Pipe Part	Finds and returns information for all pipe parts.	Lets you specify the type and spool status of the objects listed in the BOM.
Pipe Connection Accessories	Queries all pipe-pipe connections and retrieves accessory package information from them.	
Pipe Spool	Gathers all Pipe objects and organizes them into their spools. Returns information for each spool.	
HVAC Part	Finds and returns information for all HVAC parts.	Lets you specify the type and spool status of the objects listed in the BOM.

HVAC Connection Accessories	Queries all HVAC- HVAC connections and retrieves accessory package information from them.	
HVAC Spool	Gathers all HVAC objects and organizes them into their spools. Returns information for each spool.	
Penetration Accessories	Queries all penetrations in the drawing and retrieves accessory package information from them.	
Penetration Component	Gathers all Penetration component parts and reports information for the items contained in each.	
Pipe Hanger	Find and returns information for all Pipe Hanger parts.	Lets you choose from all the hanger part types
Pipe Hanger Accessories	Queries all Pipe Hangers and retrieves accessory package information from them.	
General Part	Collects all parts and returns part level information for each. Warning: The general part collector can take a significant amount of time to process data on larger projects.	
Nest	Finds and returns all objects in a Nest drawing specific to a particular nest.	
Profile Plot	Collects all objects in a Profile Plot drawing specific to a particular nest.	
Global Point	Collects free ends of Piping for listing: the distance to nearest planar group in the three primary directions, and the connectivity of the free end.	Cannot currently: include other fields or change column ordering. Typically links* to Corner Point BOM in order to maintain consistent item numbering.
Corner Point	Lists the end positions and change of direction points within a run of pipe in pipe coordinates.	Cannot currently: include other fields or change column ordering. Typically links* to Global Point BOM in order to maintain consistent item numbering.
Bending Info	Lists information necessary to cut and bend pipe	Typically links* to Cutlist BOM in order to maintain consistent item numbering.
Distributed System Supports	Collects all parts that are part of supports. This only included profiles and plates and not the pipe hangers.	
All Accessories	Collects all the different types of accessories	

* Linked BOMs are BOMs that are placed independently yet share a common set of item numbering. See Linked BOMs section for more information.

Creating a New BOM Definition

Utilizing the BOM Definition Manager, you can manage all the Bill of Material for your project. To create a new BOM:

1. Select the drawing type for which the BOM is intended.
2. Optionally, check the Default Collectors checkbox so that a reasonable subset of [Collectors](#) (page 317) is included in when you create your BOM.
3. Press the New button.
4. Set the properties for the BOM in the BOM definition grid.


- 5. Choose and order the [Collectors](#) (page 317) that are appropriate for your BOM.
- 6. Add [BOM Fields](#) (page 314) by pressing the Add/Remove button. You can choose from a predefined set of production fields or choose from any of the user-defined attributes that have been added to your project.

Note: You can modify BOM definitions after they are in use and they will be updated the next time a BOM update is performed.

Insert Empty BOM Wizard

The BOM Definition Wizard is used for inserting instances of a particular BOM into a drawing. Multiple tables can be inserted into a single drawing.

- 1. Step 1 of the wizard lets you specify which BOM definition you want to insert in the BOM. The interface is similar to the BOM Definitions window; however, it is a read-only view for selection purposes. Select a BOM definition to advance to the next page.



- 2. Step 2 lets you select BOM types. BOM functionality depends on the production drawing type. All drawing types except for Nest and Profile plots require that the BOM be inserted in paper space only. Nest and Profile Plots are inserted in model space only.

Step 2 of 2
Set BOM and labeling options

Table Options

Column width: inches(PS units) Row height: Line(s) Maximum number of rows per table: (0 indicates no maximum)

List

☒ List All
☐ List Only Visible

Wrap

Table wrap direction: Spacing: inches(PS units)

Label Options

☐ Label in Viewport
Min. leader length: inches(PS units)

Viewport options
0 Viewports will be labeled.

< Back Finish Cancel

Table Options

Specify the physical table properties:

- Column width – the initial column width of the table. You can easily adjust the widths afterwards.
- Row height – Default number of lines per row of table. Actual height varies with table style and text style.
- Maximum number of rows per table – any non-zero value will cause additional tables to be populated in the direction specified by the wrap property below.

Column width

All rows generated by the collectors are compiled into the BOM data master set. You can control the items listed in the BOM by choosing one of the two options:

- List All – Lists all items in the compiled master BOM.
- List Only Visible – Items displayed in the BOM will be based on objects' viewport visibility. Items that are visible in any of the viewports within the layout will be listed. Object layer visibility and viewport clipping are respected.

The numbering of items remains consistent across all layouts regardless of whether List All or List only visible is chosen.

Wrap Properties – Choices are enabled when a value greater than zero is entered in the Maximum number of rows per table field.

- Table wrap direction – Direction that new tables should be added.
- Spacing – Space between newly created tables.

Label Options

The labeling procedure works in conjunction with the BOM. Only objects that are referenced by a particular BOM are labeled. Label text is retrieved from the column specified by the BOM definition.

The label style used for labeling is defined in the BOM definition. You can specify one main one for the BOM definition and one for each collector. The collector label style overrides the BOM definition label style if one is specified.

ShipConstructor marks viewports that you select with AutoCAD xdata. Once selected, the objects in the viewport will be labeled every time the SCRELABELALL, SCRELABEL, SCRELABELFROMBOM command is run. You can manage selected viewports in two ways:

- Using the BOM Definitions Wizard
 - a. Select viewports – choose the viewports that you want to be labeled.
 - b. Highlight selected – Highlights viewports currently selected for labeling.
- Using the SCVPORTOPTIONS command
- Min leader length -The minimum leader length used when labeling in the layout's paper units. This value is stored on a per layout basis.

Manual Label from BOM

Let's you manually label parts from a BOM. This is an alternative method to automatic labeling. The label style and text contents are used from the selected BOM. The selection of the leader arrow is the pickpoint where you selected the part. The number of leader segments follows the label style setting.

This command can be used in conjunction with Copy Label from BOM so complete the labeling. If you select a part that has been previously labeled then the previous label is removed.

Copy Label from BOM

Lets you create labels that are copies of an existing label with the contents changed to reflect the first BOM column of the selected part. The copied label will be created with the label text and styles from the BOM table and geometry information from the source label.

Bending Data – XML Output


ShipConstructor can export XML bending data for pipes. XML was chosen as the primary intermediary for export because its format can be verified against a schema, the ability of translation through XSLT, and simply because there are a great number of readers that are able to parse XML (such as Excel).

Two target formats are currently supported for Bending information: Raw, and Formatted. The information that is contained within the files is listed as follows: Part name,


Raw

Raw indicates that the information is in its most native form. The information is highly normalized and is presented in millimeter length units and degrees angular units. The information is prepared and validated against schema that is installed in the install directory in the following path: \XMLSchemas\Output\Piping\ SC_PipeBendingDataV2011.1.xsd.


The following diagram shows the primary schema definition for the Raw bending data:



Pipe Bending Data schema outline



Schema - Arc segment node




Schema - Straight segment node

Formatted

This form of XML is different than the Raw format in that the information is flattened, and therefore imports easier into programs such as Microsoft Excel. The data is also converted into the destination units of choice by editing a settings XML file.

The schema file is located in the install directory in the following path: \XMLSchemas\Output\Piping\SC_PipeBendingData_FlattenedV2011.1.xsd. The formatted xml is the result of an XSLT transformation that is applied by MappingSC_PipeBendingData_FlattenedV2011_1.xslt and the input file SC_PipeBendingData_FormattingV2011.1.xml.


The following shows the schema diagram for the Formatted (flattened) file:



Excel Import

The information from the flattened file can be imported into Excel easily by using the Data import feature. The following example uses Excel 2007 to import a sample flattened file into Excel.

1. From the Data ribbon, choose the "From Other Sources" droplist and then select the "From XML Data Import" option.
2. Select the sheet and cell for the origin of the top left most portion of the tabular data.
3. The data is imported in columnar fashion however it is likely randomly ordered. To order the data you will specify a custom sort based on at least two columns. For this example, the data will be ordered on Name and Segment number, in that order. The order is important because the data must first be grouped a field that unites all segments from one item. Then an ascending sort is applied to the Segment Number field.




The data should now be ordered according to pipe name and the segment number.

Choosing Pipes for XML Data Generation

To choose the pipes that are required for XML data generation, run the `SCPIPEEXPORTBENDINGDATA` command.

The select pipes window is presented where you can choose pipes based on drawing, system, and assembly. Choose the output type: raw or formatted, and also choose the file location. The file name is automatically generated and a time/date stamp is appended to the name.





Once you are satisfied with the selected pipes, the file name, and the output type, choose OK and the XML file will be generated.

Bend Information and Location Tables

The information available in Spool drawings for bending tables consists of Bending Information, End/Corner Point Locations, and Global Point/Connectivity. The latter two BOMs comprise what is termed Location Tables.

The following diagram shows the arrangement in the Spool location of the BOM Definition Manager



The BOMs that define these created almost like others except the fields and Collectors are not selectable, but are chosen automatically when the BOM Definition is first created. In the above image, each of the items with the  icon is a BOM definition and the other nodes are just grouping nodes.

Corner Point

The Corner Point BOM is comprised of the Corner Point Collector and two fields: Item # (alpha numeric) and Position. The position field is broken out as X, Y, and Z coordinates in the BOM table.

The X, Y, and Z values are converted to a spool coordinate system that is defined as follows: the first pipe is aligned with the x-axis, and the z-axis is as close to the WCS z-axis as possible, while maintaining an orthogonal coordinate system.

The origin is determined to be closest to the ship coordinate system origin sorted first by x distance, then y, and then z.

There is always one main run labeled "Main A-B" and any branch lines are labeled "Br 1", "Br 2", etc
Points listed are: end points, corner points, and branch points.

Global Position

The Global Position BOM is comprised of the Global Point collector and three fields: Item # (alpha numeric), Location and Connection. Location lists the distance to the closest planar groups, similar to the Global Distance to point function. There are currently no options to override this behavior. Connection lists the spool name of the connected item.

The Global Position BOM is automatically linked to the Corner Point BOM so that the item numbers coincide.

Bending Tables

The Bending Information BOM is comprised of Bending Info Collector and six fields: Item # (alpha numeric), Outer Length, Inner Length, Rotation, Bend Radius, and Bend Angle.

The Bending Info Collector only collects straight and bent pipes, just like the Cutlist Collector. In fact since the items in both the Cutlist BOM and the Bending Info BOM are identical, the BOMs are automatically linked so that the item numbers coincide. The ordering is determined by that specified in the Cutlist BOM.

The bending fields are defined as follows:

Inner Length - the length of any straight section of pipe

Outer Length – the length from end to corner (bent end-axis intersection point) or corner to corner


Rotation – the rotation, about the previous straight run axis, that is required before the next bend can be applied.

Bend Radius – The centerline radius of the bend

Bend Angle – The angle of the bend.

Bending and Location Tables Example

The bent pipe in the following image produces the tables that follow:



Cutlist			
Item # (alpha-numeric)	Stock Name	Length	End
A	P-ER W-CS_04.0_40_A53-A	4542	4" PL


Bending Info					
Item # (alpha-numeric)	Outer Length	Inner Length	Rotation	Bend Radius	Bend Angle
A	1000	492	--	--	--
	--	--	0	508	90
	2000	984	--	--	--
	--	--	135	508	90
	1000	282	--	--	--
	--	--	270	508	45
	1000	790	--	--	--

Corner Points			
Item	X	Y	Z
Main A-B	0	0	0
	1000	0	0
	1000	0	2000
	1707	707	2000
	1707	1707	2000

Position		
Item # (alpha-numeric)	Location	Connection
A	U011000-2164 U01165+1659 U01D-1698+1698	--
B	U011000-457 U01165+3367 U01D-1698+3698	--

Spool Manager Reference

In ShipConstructor, you no longer need to click a refresh button to refresh all lists. Spool Manager dynamically refreshes. If you have the Spool Manager open while modeling and you add a part to the drawing, it appears in the Spool Manager as soon as you finish adding it. If you are in an HVAC drawing, choosing SC HVAC > Spools > Spool Manager opens the HVAC Spool Manager. If you are in a Pipe drawing, choosing SC Pipe > Spools > Spool Manager opens the Pipe Spool Manager. You must save the drawing first in order to open the spool manager.



Undefined Spools

This is where groups of interconnected parts reside that are waiting to be defined. Each grouping of parts will list all the individual parts that are contained within the grouping.

Defined Spools

This is where defined and approved spools reside.

- Lock Icon – Appears next to a spool when the spool is locked against modification.
- Unlock Icon – Appears when a spool is unlocked.
- Spool Icon – Appears when the spool does not have a drawing associated with it.
- Drawing Icon – Appears when the spool has a drawing associated with it.

No Spool

This is where all parts that are defined as No Spool in the drawing reside.

Modified Spools

This is where all the modified spools that are pending approval reside. When a spool is just created, it resides in the modified spools category because it still needs approval.

Empty Spools

This is where all the spools that have been create and had all the parts in it deleted. They are separated for ease of viewing. These can be treated much the same as modified spools, but are usually just undefined to free up the spool name.

Spool Break

A spool break is a break in the logical grouping of a run of ducts. This makes it possible for you to spool pieces of a system that are still connected together.

- Add – Adds a spool break. When clicked, the Spool Manager minimizes and lets you select all the connections that you want a spool break added for.
- Remove – Removes a spool break. When clicked, the Spool Manager minimizes and lets you select all the connections that you want a spool break removed from.

Override Colors

This is where you can override the color settings while the Spool Manager is open. Changing color settings helps you visualize which parts are Undefined, Defined, Locked, No Spool, and Modified.

To override the colors

1. Check the Override Colors check box.
2. Select a category from the drop-down list. For example, select Modified.
3. Click on the color picker (...) directly below the drop-down list and select a color. For example, if you selected Modified in the previous step, the color selected here will change the color of all parts that are in the Modified Spools category.
4. Repeat Steps 2 and 3 for all the categories you want to override colors for.

View

When any of these options are checked, if you double-click on a spool, an undefined spool group, or any part, the view will change according to the options checked and what was double-clicked on. For example, if the Zoom and Center view options are checked and you double-click on a spool, the view in the model drawing will be zoomed and centered on that spool.

Done

Closes the Spool Manager.

Properties

This button lets you toggle whether you see the properties or not. The properties will dynamically update depending on what you have selected in the tree above.

Spool Properties:

1. Naming Convention – The naming convention used to generate the spool's current name. To change the naming convention, click on the dropdown control and select a new naming convention in the list. The first available name using the new naming convention will be assigned to the spool.

2. **Spool Name** – The name of the spool. To change the spool name, click on the button (...) beside the spool name. (You may have to click on the spool name itself in order to see the button.) A list appears with some possible names. Select a new name and click OK.
3. **Is Locked** – The icon that appears here tells you whether or not the spool is locked. To change the lock status here, click on the button (...) beside the icon. (You may have to click on the icon to see the button.)
4. **Hierarchy** – The hierarchy level of the spool. To change the hierarchy level of the spool, click on the button (...) beside the hierarchy level. (You may have to click on the hierarchy level to see the button.) A hierarchy tree appears. Select a new hierarchy level and click OK. If your spool name depends on your spool's hierarchy level, you may want to re-name your spool.
5. **Finishes** – All the finishes that are applied to the spool. To change the finishes for the spool, click on the (...) button beside the finishes list. (You may have to click on the finishes list to see the button.) The select finishes window appears. Change the finishes for the spool and click OK. See [Finishes Reference](#) (page 269).
6. **Insulation** – All the insulation that are applied to the spool. To change the insulation for the spool, click on the (...) button beside the insulation list. (You may have to click on the insulation list to see the button.) The select insulation window appears. Change the insulation for the spool and click OK. See [Insulation Reference](#) (page 268).
7. **Revision History** – Shows the last revision made to the spool. To see all the revisions made to the spool click the (...) button beside the last revision. (You may have to click on the last revision in order to see the button.) A window appears showing all the revisions made to the spool in descending order. If a spool has recently been created, the last revision in the properties shows Created and the revision list window does not appear.
8. **User Defined Attributes** – Any user defined attributes that have been assigned to this spool type, will show up after the Revision History property. To change the value, simply click inside the cell and change the text.

Part Properties:

1. **Part Name** – The name of the part.
2. **Stock Name** – The name of the stock that the part was created from.
3. **Stock Description** – A description of the stock that the part was created from.

Right-Click Menu for the Spool Manager

There are many small right-click menus for the Spool Manager that are each based on what you have selected.

Undefined Spools Category Menu

1. **Define All** – Changes all the undefined spool groups into defined spools (see [Define and Undefine a Spool](#) (page 133)).
2. **Expand All** – Expands all the nodes in the tree beneath this category.
3. **Collapse All** – Collapses all the nodes to the undefined spool group level.

Undefined Spool Menu

1. **Define Spool** – Defines the spool (see [Define and Undefine a Spool](#) (page 133)).

Undefined Part Menu

1. **Set No Spool Part** – Sets the undefined part to a no-spool part (see [No-Spool Items](#) (page 130)).

Defined Spools Category Menu

1. **Expand All** – Expands all the nodes in the tree beneath this category.
2. **Collapse All** – Collapses all the nodes to the defined spool level.

Defined Spool Menu

1. **Lock Spool** (Only available if spool is unlocked.) – Locks the spool (see [Lock and Unlock Spools](#) (page 135)).
2. **Unlock Spool** (Only available if spool is locked.) – Unlocks the spool (see [Lock and Unlock Spools](#) (page 135)).
3. **Undefine Spool** (Only available if spool is unlocked.) – Undefines this spool (see [Define and Undefine a Spool](#) (page 133)).

Defined Part Menu

1. Set No Spool Part (Only available if spool is unlocked.) – Sets the part to a no-spool part (see [No-Spool Items](#) (page 130)).

No Spool Category Menu

1. Expand All – Expands all the nodes in the tree beneath this category.
2. Collapse All – Collapses all the nodes to the part category level.

No Spool Part Menu

1. Undefine Part – Undefines the no-spool part. That is, make the part a normal, undefined part (see [No-Spool Items](#) (page 130)).

Modified Spools Category Menu

1. Approve All – Approves all the modified spools (see [Approve a Spool](#) (page 134)).
2. Expand All – Expands all the nodes in the tree beneath this category.
3. Collapse All – Collapses all the nodes to the spool level.

Modified Spool Menu

1. Approve Spool – Approves the spool (see [Approve a Spool](#) (page 134)).
2. Undefine Spool – Undefines the spool (see [Define and Undefine a Spool](#) (page 133)).

Modified Part Menu

1. Set No Spool Part – Sets the part to a no-spool part (see [No-Spool Items](#) (page 130)).

Empty Spool Menu

1. Approve Spool – Approves the spool (see [Approve a Spool](#) (page 134)).
2. Undefine Spool – Undefines the spool (see [Define and Undefine a Spool](#) (page 133)).

Drag and Drop Feature for the Spool Manager

The Spool Manager has a drag-and-drop feature for defining, undefining, and setting no-spool parts.

To define a spool

Drag an undefined spool into the Defined Spools category box.

To undefine a spool

Drag a spool into the Undefined Spools category box.

To set a no-spool part


Drag a part into the No Spool category box.

To undefine a no-spool part

Drag a no-spool part into the Undefined Spools category box.

Spool Properties Reference

The Spool Properties window appears when you are defining one or more spools.




Hierarchy Tree

On the left hand side of the window is a hierarchy tree. This is where you pick which hierarchy level you want the spool to go to.

Spool Name

The list of naming conventions defined for spools are listed. If the selected naming convention uses a hierarchy level as one of its elements, the first available name will update for you when you select different hierarchy levels. If you un-check the Use next available starting at... check box, the Pick Name... button is enabled. By clicking Pick Name..., you can choose from a list of available names. The name that you select appears in the spool name label. If you leave the Use next available starting at... check box then you may chose the number to be used when generating the spool name. Changing the selected naming convention will update the preview name.



The dialog that appears after clicking the Pick Name... button give you a list of available spool names to select. You can alter the range of the displayed spool names by entering values in the text boxes. The Start At field allows you to chose where the list starts. If the number chosen is not available, then the list will start at the next available spool after the number chosen. The Number of Names field allows the user to specify the length of the displayed list. After those values are chosen click the Get Names button to generate the names from the entered fields. After highlighting a name in the list, you can click OK to use that name. Checking the Remember Range check box and clicking OK will save the value of the fields for the next time the dialog is shown.

Note: Remember Range is an option because generating a list of names with a high starting value or high number of names can take a long time.

Spool Finishes

This is a list of finishes that will be applied to the spool. To change the finishes for the spool, click the '...' button that appears when in the cell. The Select Finishes window appears letting you select finishes for the spool. See [Finishes Reference](#) (page 269).

Spool Insulation

This is a list of insulation that will be applied to the spool. To change the insulation for the spool, click the '...' button that appears when inside the cell. The Select Insulation window appears letting you select insulation for the spool. See [Insulation Reference](#) (page 268).

User Defined Attributes

Every user defined attribute that is assigned to this spool type is listed here. If the user defined attribute is required, a '*' will appear next to the attribute name to indicate that it is required to have a value. Edit the values simply by clicking inside the cell and typing.

Set From Part

This button allows the user to assign where in the product hierarchy the spool goes by choosing any part or structure that's already assigned to an assembly from within the drawing.

Keywords Reference

Depending on the type of drawing, depends on which lists of keywords are available. For instance, the HVAC Spool Drawing keyword list is made up of general ShipConstructor keywords, general spool keywords, and HVAC spool specific keywords.


Below is a table listing the keywords available, where they are available, and a short description of what they are.

Keyword Name	Type	Description
<COMPANY NAME>	General	The name of the company setup in Project Settings
<FILE NAME>	General	The name of the current file.
<FILEPATH>	General	The path of the current drawing.
<HULL NUMBER>	General	The Hull number setup in Project Settings.
<JOB NUMBER>	General	The Job Number setup in Project Settings.
<LAST UPDATE DATE AND TIME>	General	The date and time when the keyword was last updated.
<LAST UPDATE DATE>	General	The date when the keyword was last updated.
<PROJECT DESCRIPTION>	General	The Project Description setup in the Project Settings.
<PROJECT NAME>	General	The Project Name setup in the Project Settings.
<USER>	General	The User logged in that either created or updated the drawing.
<SPOOL ASSEMBLY>	Spool	The immediate assembly level of the spool
<SPOOL BRANCH>	Spool	The Branch of the system the spool belongs to.
<SPOOL CG>	Spool	The Center of Gravity point of the spool.
<SPOOL FINISHES>	Spool	The finishes assigned to the spool.
<SPOOL FULL ASSEMBLY NAME>	Spool	The entire assembly chain from the project down to the spool's assembly.
<SPOOL FULL SYSTEM>	Spool	The Spec / System / Branch of the spool.
<SPOOL LCG>	Spool	The longitudinal component of the Center of Gravity point of the spool.
<SPOOL NAME>	Spool	The Name of the spool.
<SPOOL PROPERTIES>	Spool	The Rank, immediate assembly, weight, center of gravity point, and finishes.
<SPOOL SHORT ASSEMBLY NAME>	Spool	The spool assembly and it's direct parent assembly.

<SPOOL SYSTEM>	Spool	The System that the spool belongs to. See Spool Branch keyword for the Systems' branch.
<SPOOL TCG>	Spool	The Transversal component of the Center of Gravity point of the spool.
<SPOOL VCG>	Spool	The Vertical component of the Center of Gravity point of the spool.
<SPOOL WEIGHT>	Spool	The total weight of the spool.
<SPOOL UDA>	Spool	User Defined Attributes of the spool, one keyword for each UDA
<HVAC SPOOL AIR FLOW>	HVAC Spool	The air flow of the system that the spool belongs to.
<PIPE SPOOL CLASS>	Pipe Spool	The class of the system that the spool belongs to.
<PIPE SPOOL RELATIVE DENSITY>	Pipe Spool	The relative density of the system that the spool belongs to.
<PIPE SPOOL TEST METHOD>	Pipe Spool	The Test method of the system that the spool belongs to.
<PIPE SPOOL TEST PRESSURE>	Pipe Spool	The Test pressure of the system that the system belongs to.
<ASSEMBLY CG>	Assembly	The Center of Gravity of the assembly.
<ASSEMBLY DESCRIPTION 1>	Assembly	The Description1 User Defined Attribute of the assembly.
<ASSEMBLY DESCRIPTION 2>	Assembly	The Description1 User Defined Attribute of the assembly
<ASSEMBLY LCG>	Assembly	The Longitudinal component of the Center of Gravity point of the assembly.
<ASSEMBLY LEVEL>	Assembly	The rank(level) name of the assembly.
<ASSEMBLY NAME>	Assembly	The name of the assembly.
<ASSEMBLY PROPERTIES>	Assembly	The rank name, weight, center of gravity point, and finishes of the assembly.
<ASSEMBLY TCG>	Assembly	The Transversal component of the Center of Gravity point of the assembly.
<ASSEMBLY VCG>	Assembly	The Vertical component of the Center of Gravity point of the assembly.
<ASSEMBLY WEIGHT>	Assembly	The total weight of the assembly.
<FULL ASSEMBLY NAME>	Assembly	The full path of the assembly tree that this assembly belongs to.
<LEVEL X ASSEMBLY NAME>	Assembly	X represents each rank level. These keywords produce an assembly name at the assigned level based on the path of the current assembly. As an example, a rank named UNIT would produce the keyword called <LEVEL UNIT ASSEMBLY NAME>. If an assembly was part of U01 which had a rank level of UNIT, the keyword would produce U01.
<SHORT ASSEMBLY NAME>	Assembly	The name of the assembly and it's direct parent.
<ASSEMBLY UDA>	Assembly	User Defined Attributes of the Assembly, one keyword for each UDA
<Support CG>	Support Construction	The Center of Gravity of the support.
<Support Full Assembly Name>	Support Construction	The full name of the assembly that the support is assigned to, in the primary product hierarchy.

<Support LCG>	Support Construction	The Longitudinal component of the Center of Gravity point of the support.
<Support Name>	Support Construction	The name of the support.
<Support TCG>	Support Construction	The Transversal component of the Center of Gravity point of the support.
<Support Template Type>	Support Construction	The template type of the support.
<Support Template>	Support Construction	The template name of the support.
<Support VCG>	Support Construction	The Vertical component of the Center of Gravity point of the support.
<Support Weight>	Support Construction	The combined weight of all the component parts for a support.

To insert keywords, you must be in paper space.



Keywords
The list of available keywords to place in the HVAC spool template drawing.

Text Style
The selected text style for the keywords selected under Keywords. This is a list of available text styles from within the drawing. If you created more text styles using AutoCAD for this drawing, the text styles you created appear in this list.

Text Size

The size of the text.

Rotation

The rotation of the text.


Note: If a keyword does not seem to update when you have created your spool drawing, your project settings may not be fully set up. For example, if you chose <JOB NUMBER> as one of your keywords, and this keyword still shows the same text as the template in your generated spool drawing, this means that the project settings for the job number have not yet been set. To complete the settings, go to Manager > General > Project Settings.

You can update specific keywords manually by selecting a keyword, right-clicking, and selecting Update from the right-click menu.


There are numerous options associated with keywords that are accessible through the OPM. You can now pre and post append text to a keyword, and change the display properties of keyword with ease.

Create Spool Drawing Wizard Reference


The Create Spool Drawing wizard is a tool for generating spool drawings.



The first page of the wizard is where you select your HVAC spool template drawing.



The second page of the wizard is where you select all the spools that you want to generate spool drawings for. You can select spools by navigating through your HVAC drawing, systems, or assemblies. A list of all the spools selected is shown on the right side under Selected Sources.



The last page of the wizard is where you select which spool style to use. Select a spool style under Spool Styles. When a spool style is selected, the properties of the style are shown under Spool Style Properties.


If there are no spool styles defined and you have permission to create one, click on the Edit Styles button to create a spool style. See [Spool Styles Reference](#) (page 341) for more details.

Note: Baseline Dimensioning is not yet implemented in ShipConstructor.

Spool Styles Reference

Spool styles are used in the dimensioning and labeling of spools.

Note: If you do not have permission to edit spool settings, the window controls are disabled, and the title bar displays READ ONLY.



Spool Styles

The list of spool styles. When you click on a spool style in the list, the properties are updated to reflect the properties of the selected spool style.

New

Click this button to create a new spool style.

Delete

Click this button to delete the selected spool style.

ARS and Penetration Label Style

- Label Offset – The label offset in millimeters used for penetration labels and ARS labels.
- Label Style – The label style used for penetration labels and ARS labels. This list is generated from the label styles set up in Manager.

ARS Label

- Angle – When checked the ARS label will display the angle of the corner.
- Radius – When checked the ARS label will display the radius of the corner.
- Arc Length – When checked the ARS label will display the arc length of the corner
- Label Non-Cutback Elbows – When checked the ARS label will display the arc length of the corner

Penetrations

- Show Penetrations – When checked penetrations will be marked in the drawing.

Note: All penetrations will be marked in the spool drawing if selected but only watertight component parts will be displayed in the drawing and BOM's.


Note: For watertight penetrations with component parts, the penetration mark will be placed on the penetrator where the component part and the penetrator intersect.

CG Point

- Display CG Point – When checked a point will be drawn indicating the center of gravity for the spool.

Dimensioning


- Baseline Dimensioning – Not used at this time.
- Break Dimension at Branches – When checked, will break the dimensions at branch points of fittings.
- Break Dimension at Connections – When checked, will break the dimensions at connections.
- Break Dimension at Saddles – When checked, will break connections at saddles.
- Dimension Offset – The offset of the dimension from the part's centerline.



Dimensions generated along a run of Pipe. The offset as well as each break type are shown.

- Dimension Style – The style of the dimension used. This list is generated from the dimension style names that are set up in Manager. If you have set up a dimension style in your template drawing that you want to use, make sure the name is set up in Manager under Dimension Styles.
- Orientation – The orientation selection of the dimensions.
 - Ship Coordinate System – Aligned to the world coordinate system.
 - Best Fit – ShipConstructor determines the most appropriate coordinate system to align the dimensions to.
 - UCS – Orients the dimensions to the coordinate system stored in the named UCS Spool. When you originally create the spool drawing, you have not yet had an opportunity to customize this UCS; thus this option is usually only useful for re-dimensioning.


In addition to the AutoCAD dimensions created based the above settings, ShipConstructor will also create AutoCAD text objects showing the length of straight segments of bent pipes.




Straight segment text labels generated in addition to the normal dimensions (bent pipes only).

Create Arrangement Drawing Wizard Reference


The Create Arrangement Drawing wizard is a tool for generating arrangement drawings.



The first page of the wizard is for entering a drawing name. The Next button will be disabled until a valid drawing name is entered.




The second page of the wizard is where you select your arrangement template drawing.



The third page of the wizard is where you select the various sources that you want to include in your arrangement drawing and the layers of where to put them. You can select an arbitrary number of sources to include in your arrangement drawing. A summary of all selected sources and their layers appears on the right side of the screen under Selected Sources.


While choosing sources for your drawing, selecting a root node in the tree will also select anything underneath that node. So if you want to create an arrangement drawing containing an entire system with all its branches, simply click on the system.

You may also choose to retain the layers of the part from its model drawing source at this step. Choosing Retain Model Drawing Layers from the dropdown in the layer column will cause the layers from all model drawings containing parts in the current source to be copied into the arrangement drawing and the parts will be moved to the copy of the layer of their source. This brings in all layers from the source, not just ones used by parts in the given source. If multiple model drawings to bring layers in from have layers with the same name, the first one encountered will be taken and further layers of that name will be ignored.




The last page of the arrangement drawing creation wizard lets you choose which drawings non-ShipConstructor geometry will be obtained from and the layers to put them on. The drawings presented in this tree are computed based on the sources you have selected during Step 3 of the arrangement drawing creation process. The layer column behaves similar to that of the previous step.

Note: Any geometry imported using this mechanism has a special tag attached to it for the purpose of identifying it. When the drawing is updated, only the non-ShipConstructor entities brought into the drawing with this process are updated. Any custom geometry you manually add to the arrangement drawing will be unaffected during a drawing update.



Modified Part Information Reference

The Modified Part Information window is used while updating existing production drawings. It helps you to inspect parts that will change during this update process.



The main table shows you a list of parts that are affected by updating this drawing. The parts are split into several categories. You can multi-select any of the parts in this list, and, depending on the View options, the parts will be highlighted, centered, and zoomed to.

Note: If you are in one of the Paper space layouts and you do not have a viewport selected, the largest viewport will be automatically chosen to highlight entities in. If you want to use a different viewport, simply activate it.

Reasons why parts are being updated

- **New Parts** – If an existing source (such as a system) has had parts added to it, the parts will show up here. Or, because you selected new sources in the drawing creation wizard.
- **Removed Parts** – These are parts that will be removed for any reason, including the source being removed entirely or the part being deleted out of the source.
- **Modified Parts** – Any parts that have had any of their attributes changed will show up here.
- **User Deleted Parts** – Parts that have been manually deleted out of the production drawing. Select the parts using the checkbox beside them to re-insert them. To re-insert multiple parts, select all the parts that are to be re-inserted. Click the checkbox for one of the selected parts, the checkboxes for all the selected parts will be checked. Deleted parts can be previewed using both the Show/Preview Checked Parts and the Refresh Preview controls.

View

The view options control what happens when you click on a part in the updating part list.

- **Center** – Centers on all selected parts.
- **Highlight** – Highlights all selected parts.
- **Zoom** – Zooms to all selected parts.

Part Color overrides

To visually aid in identifying parts, all parts that are not affected by the update process are temporarily displayed in a light grey color. All affected parts have custom color overrides that control how the parts appear while the Modified Part Information window is visible.

- **New** – Set the color of the parts that have been newly added to this drawing.
- **Modified** – Set the color of the parts that are being updated because any of their attributes or their geometry has changed.
- **Removed** – Set the color of the parts that are being removed from this drawing

- Deleted – Set the color of the parts that have been deleted by the user from this drawing. This corresponds to the list of User Deleted Parts from the modified parts table.
- Unchanged – Set the color of the parts that are unaffected by the update of the drawing


Show Removed Parts - If you do want to see parts that are being removed from this drawing. This is useful if you have removed an entire source and do need to know exactly what is being removed.

Show/Preview Checked Parts - If you do want to see parts that you deleted intentionally from this drawing. When enabled, all the parts with their checkboxes checked with appear in the drawing, using the User Deleted color. Unchecking will hide all checked parts.

Refresh Preview – If the list of checked parts has changed and you want to preview any parts added to that list.

Layer Conflict Resolution Reference

The Layer Conflict Resolution window is used when creating or updating arrangement or assembly drawings. It allows you to easily move any parts that were given multiple layers to go to in source selection.



The window will appear when creating or updating production drawings where layers are defined with sources if there are any parts with multiple source layers defined. The list labeled Layer Conflicts shows all the sources that contain conflicted parts, and a status icon for each conflict. You can select any of the conflict in this list, and, depending on the View options, the conflicted parts from the selected conflict will be highlighted, centered, and zoomed to. The list labeled Layers shows the possible layers for the currently selected conflict on the Layer Conflicts list. The Use for all button will assign the checked layer in the Layers list to all conflicts where that layer is an option.


Status Icons

- The X icon signifies that the conflict hasn't been resolved.
- The Check Mark icon signifies that it has been resolved.
- The Exclamation Mark icon signifies that it is resolved but was changed by the Use for all button.

Once all conflicts are resolved the OK button will be enabled and you can press it to move the conflicted parts to the selected layers.


Update Arrangement Drawing Wizard Reference

The Update Arrangement Drawing Wizard appears when an arrangement drawing is updated. It lets you add and remove sources for ShipConstructor parts as well as sources for non-ShipConstructor geometry.




All sources that are currently used to populate this drawing are summarized under the Selected Sources heading. In addition, the sources are also pre-selected in the main source trees with the layer specified entered in the Layer column, and the appropriate nodes expanded for easy visual identification.

To add or remove sources from this arrangement drawing, use the check boxes in the source trees. You may add any number of sources to one drawing. The Layers column works the same here as it does for creation of an arrangement drawing, except that parts for each source that are already in the arrangement drawing will remain on their current layer.




The second page of the wizard shows you all drawings that ShipConstructor entities will be obtained from to create the arrangement drawing. If you want to also bring in non-ShipConstructor geometry, such as lines and solids from those drawings, select them here. Any drawings that you have already obtained non-ShipConstructor entities from will be pre-selected. The Layers column behaves similar to that of the previous step.

Note: While updating non-ShipConstructor entities, only entities that were brought into the drawing with this process will be affected. If you have custom annotations or any other geometry in the arrangement drawing, it will not be affected during updating.



Label Styles

Labels are defined in Manager under General and in the Production Output fly-out.



Bubble Style
The type of outline that will be around the text of the label.


Bubble Size
Determines the size of the bubble. Generally the bubble will be sized by text + bubble size.

Leader
Whether or not the label has a leader pointing to the object that is labeled.

Acad Dimension Style
The AutoCAD dimension style to use for various aspects of the label.

Text Height
The height of the text in the label. Uses the value in the text style if it is not 0, otherwise it uses the value in the dimension style

Arrow Size
The size of the arrow for the leader.



Shown above are the various types of bubble styles for labels. They're shown with a bubble size of 8mm and a text size of 0.18 . The size of each bubble style is described below.

Circle	Diameter = Text Height + Bubble Size
Square	Length = Bubble Size
Triangle	Height = Base Length = Bubble Size
Octagon	Width = Height = Bubble Size
Rectangle	Height = Text height + 2 * Bubble Size
	Width = 2 * Text Width + Bubble Size
Bubble	Height = Text Height + Bubble Size * 1.5 * Number of Lines
	Width = Text Height + Text Width + Bubble Size * 1.5 * Number of Lines

BOM Revisions

When BOM tables are updated, they are rebuilt each time to reflect the current state of the drawing. This does not allow the user to see how the drawing changes affected the BOM tables. It also may renumber the items, causing existing labels to be incorrect.

BOM Revisions allow the user to save the current state of the Bills of Material in the drawing (or layout), so that when the BOM tables are updated, they will be able to compare the new BOM data with the old BOM data and display those changes to the user.

To prevent the original BOM tables appearance from changing, new items in the BOM are appended to the end of the table, and removed items have their text changed to use strikethrough. Any changes to existing items are simply updated into their rows. This allows the items to maintain their original item numbering, preventing the user from having to relabel everything.

To use BOM revisions best, a Revision column should be added to the BOM definitions. This column will display one of three possible values:

- nothing, for when no revisions exist
- the current revision, such as "Rev.0"
- the "modified" state, which is the current revision prepended with "*", such as "*Rev.0". This state indicated that something in this row was modified during an update.

BOM Revisions can be defined for any paperspace layout in production drawings. Alternatively, the user can define a revision for the entire drawing (all layouts), instead of for just the current layout.

An example of how the BOM table evolves is shown:

Item #	Part Name	Revision
1	PEN-008-Collar	
2	E-90LR-CS_02.0_ST-A234-001	
3	E-90LR-CS_02.0_ST-A234-002	
4	E-90LR-CS_02.0_ST-A234-005	
5	P-ERW-CS_02.0_80_A53-A-019	
6	P-ERW-CS_14.0_80_A53-A-007	

This is a BOM table in a Pipe Arrangement drawing after creation. The user defines a revision called "A". The empty Revision column is filled with this name.

Item #	Part Name	Revision
1	PEN-008-Collar	A
2	E-90LR-CS_02.0_ST-A234-001	A
3	E-90LR-CS_02.0_ST-A234-002	A
4	E-90LR-CS_02.0_ST-A234-005	A
5	P-ERW-CS_02.0_80_A53-A-019	A
6	P-ERW-CS_14.0_80_A53-A-007	A

Then they update the drawing. Some parts have been added, and others have been removed. The result looks like this:

Item #	Part Name	Revision
1	PEN-008-Collar	*A
2	E-90LR-CS_02.0_ST-A234-001	A
3	E-90LR-CS_02.0_ST-A234-002	A
4	E-90LR-CS_02.0_ST-A234-005	A
5	P-ERW-CS_02.0_80_A53-A-019	A
6	P-ERW-CS_14.0_80_A53-A-007	*A
7	P-ERW-CS_02.0_80_A53-A-010	*A
8	P-ERW-CS_02.0_80_A53-A-017	*A

The changed parts have the "*"A" identifier. The removed parts used strikethrough text. New rows are appended to the end, continuing the item numbering, and not re-ordering it.

The commands to add and remove revisions are the same for Assembly, Arrangement, Spool, and Support Construction production drawings.

New Revision

Revisions can be created at any time: the user simply needs to provide a name, and an optional description. The new revision name must not be used in the layout (or drawing, if creating a revision for all layouts). The revision saves the current user and the date and time of creation.

If this is the first revision in the drawing, the empty Revision column for all BOM tables in the layout (or drawing) are changed to the revision name. If it's not the first revision, then all the rows with in the "*" identifier are changed to the new revision. This way, only items that have changed during the BOM updating are tagged as belonging to the new revision.

To create a revision

1. Choose [SC Arrangement > BOM Revisions > New BOM Revision in Current Layout](#) (page 285) or [SC Arrangement > BOM Revisions > New BOM Revision in All Layouts](#) (page 285)

2. Provide a name for the revision

Enter a name for the new revision:

3. Provide a description for the revision (this can be left blank)

Enter a description for the new revision <none>:

4. The revision is created in the specified layouts

Revision 'Rev.A' created in layout 'Master BOM'

Or

Revision 'Rev.A' created in 2 layouts

Delete Revision

When deleting revisions, only the current revision can be deleted. Any BOM item with the current revision is changed to be the previous revision with the "*" identifier. If no previous revision exists, then the Revision column is left blank.

Using the "all layouts" command to delete revision requires that the current revision in all those layouts have the same name.

To delete a revision

1. Choose [SC Arrangement > BOM Revisions > Delete BOM Revision in Current Layout](#) (page 285) or [SC Arrangement > BOM Revisions > Delete BOM Revision in All Layouts](#) (page 285)
2. The current revision is deleted

```
Revision 'Rev.A' deleted in layout 'Master BOM'
```

Or

```
Revision 'Rev.A' deleted in 2 layouts
```

Delete All Revisions

Instead of deleting each revision one by one, the user can simply delete all revisions. The BOM tables will not be restored to the original state, but will be left as they currently appear (except that all Revision columns are reset to a blank value)

To delete a revision

1. Choose [SC Arrangement > BOM Revisions > Delete All BOM Revision in Current Layout](#) (page 286) or [SC Arrangement > BOM Revisions > Delete All BOM Revision in All Layouts](#) (page 286)

2. All revisions are deleted

```
3 revisions deleted in layout 'Master BOM'
```

Or

```
3 revisions deleted in 2 layouts
```

List Revisions

Information about the revisions in the current layout can be printed to the command line. Revisions are listed with their name, description, user and date/time of creation.

To list revisions

1. Choose [SC Arrangement > BOM Revisions > List BOM Revisions](#) (page 286)

2. Choose R (or enter) to display the revisions

```
Select what to list [Revisions/Operations/All]<Revisions>:
```


3. Choose N (or enter) to avoid seeing a long list of parts changed per revision.

```
List parts? [No/Yes]<No>:
```


4. The revisions are then listed at the command line

Global Dimension to Point

Global Dimension to Points are used to indicate the distances from a given point to selected planes. The global dimension to points can be displayed either as dimensions or as labels. The text displayed in the dimensions and labels can be customized to display the information in any format specified by the user.



The main grid will display all the available UCS's in the project, or if Current Unit Only is selected it will display all available UCS's in the current unit. Up to 3 different UCS's can be selected one in each direction X, Y, Z. If a UCS is selected that is in the same direction as an already selected UCS the previously selected UCS will be unchecked. The preview window will be updated with the newly selected UCS to indicate what will be displayed. The top yellow row can be used to filter through the grid to find the appropriate UCS.



Global Dimension to Point


To create a global dimension to point, select the Dimension or Label button. This will change the preview to display the text that will be used for the global dimension. If creating a dimension, enter the dimension offset. This value is the length of the extension line for the dimension. Select a style to be used for the global dimension. The dimension and label styles are defined in Manager. Select the UCS's to mark the dimensions to. If necessary edit the display text to display the appropriate keywords. Click OK. If a label is created, select a point for where to place the label text.

Editing the Text

The text displayed for the Global dimensions can be customized to display words or specific keywords.

The available keywords are:

- Distance – The distance in the current units between the selected point and the plane.
- Direction To – The direction from the point to the plane.
- Direction From – The direction from the plane to the point.
- +/- To – Positive if the plane point is greater than the picked point in the given direction, otherwise negative.
- +/- From – Negative if the plane point is greater than the picked point in the given direction, otherwise positive.
- UCS Name – The name of the UCS being used.



To edit the text for a global dimension first select the global dimension type Dimension or Label. The preview window will update to display the appropriate text. Then click the edit button. The preview window will change to display the keywords and text used to generate the global dimensions and a box with the available keywords will appear on the side. To add a keyword to the text place the cursor where the keyword should be inserted and then double click on the keyword in the list. Regular text can also be placed anywhere in the text. To delete a keyword, highlight the keyword and press the backspace button. To finish editing press the edit button again. This will close the keyword list and the preview will change to display the appropriate text.

The default button will place a default text in the preview box; the default text is Distance DirectTo UCSName.


To allow for multiple types of keywords to be used; the global dimension styles can be saved out. The style will save the global dimension type, the label or dimension style, and the keywords used. To save a style, click the Save Global Dimension Style button. Enter a name for the style in the dialog that is displayed and click OK. To load the style back, click the Load Global Dimension Style button. The list of stored styles will appear on the right side of the dialog. Double click on the appropriate style and the stored values will be loaded. To delete a saved style, click the Delete Global Dimension Style button. The list of available styles will be displayed, select the style to delete and click the Delete Global Dimension Style button. Click OK to confirm the deletion of the style.

To select the planes closest to the selected point click the Select Closest Planes button. The planes closest to the point will be selected and all other previously selected ones will be unselected.

The UCS's called also be saved as datum planes. These datum planes are used to store a UCS in each direction so that they can be easily reloaded and used for other global dimensions. To store a UCS as a datum plane, check the plane in the grid to use as datum planes, right click on the grid and select Save as Datum Plane. To reload the datum planes click the Select Datum Planes button.

Cut Length Dimensions

A cut length dimension uses a text style to define its appearance in a spool drawing.




The style that the cut length dimension uses is chosen by the dimension style used in the spool style for that drawing.

Spool Style Properties	
Property	Value
Dimensioning	
Baseline Dimensioning	Not used
Break Dimension at Branches	no
Break Dimension at Connections	no
Break Dimension at Saddles	no
Dimension Offset (mm)	200
Dimension Style	HVAC SPOOL
Orientation Type	Best Fit
Labeling	
ARS and Penetration Label Offset (mm)	100
ARS and Penetration Label Style	DEFAULT
Radial Dimension Angle	yes
Radial Dimension Radius	yes
Radial Dimension Arc Length	yes
Show Penetrations	yes


Elbow Radius Dimension

An elbow radius dimension's appearance is defined by the label style used in the spool style for that drawing. The information displayed in the label can be selected in the spool styles. The label can be set to display any of the 3 parts angle, radius, and arc length. To not display the label, uncheck all 3 check boxes in the spool settings when creating or updating the spool drawing, or uncheck the boxes in Select Dimension Attributes dialog when re-dimensioning the spool.



Flange Rotation Angles

If the end part of a spool is a flange which is connected to a valve outside of the spool, a rotation angle is calculated. If the end part is a flange but it is not connected to a valve, a rotation angle will be calculated if the dimension orientation used is not Ship Coordinate System. The rotation angle indicates the angle the flange needs to be rotated so that the bolt holes will be aligned when the spool is produced.



Spool Drawings – Valves Icons

The valve icons are used to represent valves in 2D line mode for spool drawings. The valve icons are made up of 3 parts: valve ends, body icons, and valve handles.

Valve Ends


The valve ends are drawn as triangles. The base of the triangle is drawn at the end of the valve with the tip pointing to the center of the valve. The plane the triangles are drawn in will adjust based on the current view direction. When the valve ends are drawn on end the ends will be drawn as a circle with an S in it.

Body Icons

The body icons will draw a 2D representation of the selected body icon used for the valve. The body icons can either be an arrow, sphere, or cone. The plane the body icons are drawn in will adjust based on the current view.


Valve Handles

The geometry used to draw the valve handles is defined by the user, see [Create a Valve Handle 2D drawing](#) (page 31). The 2D valve handles will be scaled to the same length as the valve handle.



Spool Drawings – Penetrations

Penetrations will be displayed in the spool drawing if the show penetrations option is selected in the spool styles, see [Spool Styles Reference](#) (page 341). The penetrations will be marked using an X and placed on the Pens layer. If the penetration is a watertight penetration and contains component parts the component parts will be displayed in the spool drawing the BOM's.



The penetration component parts will be included in the BOM's if either the penetration collector is added to the BOM or if the pipe collector and/or the structure collector options are edited to include penetration component parts.

The penetrations will be dimensioned from the penetration mark to the end of the pipe run to the end or to the break point selected in the spool styles. The baseline dimension height in the specified dimension style will be used to stack the overlapping dimension lines.

Index

A

Accessory Package 37, 38
 connection 43, 244
 create 37, 38, 39
 delete 39
 Anchor 113, 114, 242
 Arrangement Drawings 184, 186, 187, 193, 344

B

Bending Machine 44
 create 44
 delete 47
 import/export 47, 48
 size definition 46, 47
 BOM 193, 198, 311, 313, 314, 319
 insert 172, 184, 193, 320

C

Catalogs 17, 18, 33
 CG 287
 Collectors 317, 318
 Connect/Disconnect 124
 Connections 40, 41, 42, 43, 126, 223

D

Dimension 179, 180, 357, 361

F

Filter 8, 14, 19
 Finishes 238, 239, 269
 Flange 231, 362

G

Geometric Standard 3, 5

I

Insulation 238, 239, 268

K

Keywords 174, 186, 336

L

Labels 198, 199, 354
 Lock/Unlock 114, 243

M

Max Length 125, 239, 361
 Model Drawings 81, 181

N

NavAid 85, 91, 261
 Nominal Size 5, 6, 7
 No-Spool 236

O

OPM 140
 Options 86, 88, 201, 244, 255
 OSnaps 110, 111, 112, 113

P

Pressure Rating 4, 5

R

Routing 86, 109, 115, 117

S

Saddle 104, 125, 238
 Size Definition 7, 8, 220
 create 7, 46, 47
 edit 8, 46, 47
 Spec 16, 17, 33, 39
 Spool 9, 169, 329
 drawings 169, 174, 176, 179, 180, 181, 182,
 339, 363
 edit 333
 Spool Breaks 236, 237

Stocks 5, 19, 34, 218, 266
 create 19
 edit 33, 34
 import/export 36, 37
System 82, 83, 254

T

Templates 170, 171, 175, 184, 187

U

UCS 142, 144, 272
 Pipe-UCS 143, 144
User-Defined Attributes 48

V

Valves 29, 226, 363
Viewport 201, 203